

Preface

This user's manual explains the use and specifications of the Setup Software for AC servo amplifier "R" series.

- Notifications on this User's Manual:
 - To completely utilize all functions of the AC servo amplifier "R" series, read this manual carefully before use to ensure proper operation.
 - After reading this manual, keep it handy so that it can be referred to by anyone at anytime.
 - Contact the head office or our sales departments listed on the back cover if there is incorrect collating or missing page.
 - Make sure to follow the directions on safety cautions in this manual. We will not insure safety in the use other than specified in this manual or in the improper use.
 - This manual content may be revised without notice because of product version up or usage additions. The changes will be noticed by revising this manual.
 - Some figures in this manual may be outlined or abstract.
 - Contact the head office or our sales departments listed on the back cover in case of questions or omission.

Terms:

In this manual, "AC Servomotor" is sometimes abbreviated to "Servomotor" or "Motor",

"AC Servo Amplifiers" to "Servo Amps." or "Amps.",

"Wiring-saved incremental encoders" to "INC-E",

"Incremental Absolute encoders" to "ABS-E",

"Absolute encoder with request signal" to "ABS-E with request signal",

Also, both "Wiring-saved incremental encoders" and "Absolute encoders" to "Encoder",

and entire optical and resolver encoders are abbreviated to "Sensor".

CONTENTS

| Contents | 1 |
|---|----|
| 1. Installing and Uninstalling | 4 |
| 1.1. Hardware requirements | 4 |
| 1.2. How to Install | 5 |
| 1.2.1. Installer | 5 |
| 1.2.2. How to Install | 5 |
| 1.3. How to Uninstall | 9 |
| 2. Connecting to Servo Amplifier | 12 |
| 2.1. Connected Cable | 12 |
| 2.2. How to Connect | 12 |
| 3. How to Operate | 13 |
| 3.1. How to Activate | 13 |
| 3.2. Main Screen | 14 |
| 3.3. Communication Setting | 18 |
| 3.4. Switching Communication State | 18 |
| 3.4.1. Offline->Online | 18 |
| 3.4.2. Online>Offline | 19 |
| 3.5. Communication State Check | 19 |
| 3.6. General Parameter setting | 20 |
| 3.6.1. Parameter Display Level | 22 |
| 3.6.2. Parameter Setting of Servo Amplifier | 23 |
| 3.6.3. Parameter Setting of Amplifier File | 28 |
| 3.6.4. Transmit Parameter [Amplifier->File] | 30 |
| 3.6.5. Transmit Parameter [File->Amplifier] | 30 |
| 3.6.6. Match Parameter | 30 |
| 3.7. System Parameter Setting | 33 |
| 3.7.1. Parameter Setting of Servo Amplifier | 35 |
| 3.7.2. Parameter Setting of Amplifier File | 37 |
| 3.7.3. Transmit Parameter [Amplifier->File] | 39 |
| 3.7.4. Transmit Parameter [File->Amplifier] | 39 |
| 3.7.5. Match Parameter | 39 |
| 3.8. Motor Parameter Setting | 40 |
| 3.8.1. Parameter Setting of Servo Amplifier | 42 |
| 3.8.2. Parameter Setting of Amplifier File | 45 |

| 3.8.3. Transmit Parameter [Amplifier->File] 47 |
|--|
| 3.8.4. Transmit Parameter [File->Amplifier] 47 |
| 3.8.5. Match Parameter 47 |
| 3.9. Transmit Parameter [Amplifier->File] 48 |
| 3.10. Transmit Parameter [File->Amplifier] 49 |
| 3.11. Verification of parameter file 53 |
| 3.13. Monitor Display |
| 3.13. Multi-Monitor Display 57 |
| 3.13.1. Multi-Monitor Display Setting 58 |
| 3.14. Alarm History 59 |
| 3.14.1. Alarm Reset 60 |
| 3.14.2. Alarm History Clear 60 |
| 3.15. Jogging Operation 61 |
| 3.16. Operation for Pulse Feed Jogging 65 |
| 3.17. Automatic Notch Filter Tuning 69 |
| 3.18. Automatic Vibration Suppressor Frequency Tuning73 |
| 3.19. Fixation Excitation Operation |
| 3.20. Automatic Offset Adjustment of V-REF Terminal79 |
| 3.21. Automatic Offset Adjustment of T-COMP Terminal |
| 3.22. Save Result of Automatic Tuning83 |
| 3.23. Alarm Reset |
| 3.24. Absolute Encoder Clear |
| 3.25. Alarm Trace Clear |
| 3.26. Trace Operation |
| 3.26.1. Trace Operation Setting |
| 3.26.2. Select Contents of Trace Operation Setting 101 |
| 3.26.3. Trace Operation Display Setting 104 |
| 3.26.4. How to Use Trace Mode of Trace Operation Function |
| 3.26.5. How to Use Scroll Mode of Trace Operation Function |
| 3.26.6. Measurement of Trace Operation Function |
| 3.27. System Analysis 111 |
| 2.27.1 Date Macourament & Apolycia Start 114 |
| |
| 3.27.1. Data Measurement & Analysis Start |
| 3.27.1. Data Measurement & Analysis Start |
| 3.27.1. Data Measurement & Analysis Statt |

| 3.29. Point Data Setting | 123 |
|---|-------------------|
| 3.29.1. File Edit Mode | 124 |
| 3.29.2. Ext. Mode | 126 |
| 3.29.3. R-Setup Mode | 129 |
| 3.29.4. Test Run (R-Setup Mode) | 133 |
| 3.29.5. Move Point (R-Setup Mode) | 138 |
| 3.29.6. Alarm Reset (R-Setup Mode) | 141 |
| 3.29.7. Teaching (R-Setup / EXT. Mode) | 141 |
| 3.29.8. Copy (R-Setup / EXT. / File Edit Mode) | 142 |
| 3.29.9. New (File Edit Mode) | 143 |
| 3.30. Transmit Point Data [Amplifier->File] | 145 |
| 3.31. Transmit Point Data [File->Amplifier] | 147 |
| 4. Appendix | 150 |
| 4.1 Wiring | 150 |
| 4.1.1. Wiring when connecting 1 unit | 150 |
| 4.1.2. Wiring when connecting some units | 151 |
| 4.2. Version List | 152 |
| 4.3. Instruction Manual Revision History | 152 |
| 4.4. Trouble Shooting | 153 |
| 4.4.1. Troubles when Connecting to Servo Amplifier | 154 |
| 4.4.2. Troubles in Use | 155 |
| 4.4.3. Transmit Parameter [File -> Amplifier] Alarm | 155 |
| 4.4.4. Parameter Matching Alarm | 155 |
| 4.4.5. Test Operation and Adjustment/ Alarm Trace Clear Message | 156 |
| 4.4.6. Trace Operation Message | 158 |
| 4.5. Communication Setting of Servo Amplifier | 159 |
| 4.5.1. Parameter | 159 |
| 4.5.2. Communication Setting Procedure by Digital Operator | 160 |
| 4.4.6. Trace Operation Message4.5. Communication Setting of Servo Amplifier4.5.1. Parameter | 158 159 159 |
| 4.5.2. Communication Setting Procedure by Digital Operator | 160 |

1. Installing and Uninstalling

1.1. Hardware requirements

The following system is required to utilize R-SETUP - Setup Software.

| PC | IBM PC/AT compatible machine | | | |
|------------------|--|--|--|--|
| | (NEC PC-98x1 cannot be ensured to operate.) | | | |
| CPU | At least Pentium133MHz | | | |
| | (When using scroll mode of the operational trace function, | | | |
| | CPU operational frequency of 350MHz or 800MHz at least is | | | |
| | recommended. *1) | | | |
| Memory | At least 32MB (Minimum 64Mb is recommended) | | | |
| Hard disk | At least 10Mb free spaces | | | |
| | Complete installation: At least 30MB of space area | | | |
| | Reduced installation: At least 10MB of space capacity | | | |
| Monitor | At least 800×600 | | | |
| resolution | | | | |
| Number of colors | At least 256 colors | | | |
| Others | At least one RS-232C | | | |
| | CD-ROM drive | | | |
| | At least Internet Explorer 4.0 (Used for opening a part of | | | |
| | operational procedure explanation file) | | | |
| Corresponding | • Windows® 98 | | | |
| OS | Windows® Me | | | |
| | • Windows NT® 4.0 | | | |
| | Windows® 2000 Professional | | | |
| | Windows® Xp Home Edition/Professional | | | |
| | Windows® Vista *2) | | | |
| | • Windows® 7 *2) | | | |

*Note 1) The recommended operational conditions (CPU operational frequency) when using scroll mode of the operational trace function is as below:

- 50ms \leq Data sampling period setting<100ms: CPU operational frequency \geq 800MHz
- 100ms \leq Data sampling period setting<200ms: CPU operational frequency \geq 350MHz
- 200ms \leq Data sampling period setting: CPU operational frequency \geq 133MHz
- *Note 2) Users with administrative right (computer administrator account) or equivalent use only.

1.2. How to Install

1.2.1. Installer

There are two kinds of R-SETUP - Setup Software installers as follows. Use an appropriate one according to the customer conditions (the difference between the Complete install and the Reduced install is only with or without the system analysis function. "***-***" corresponds to the R-SETUP – Setup Software version).

- The Complete Installer [Setup_V***-***-Complete.exe] The Complete Installer/ The Reduced Installer can be selected. The Installer file size: Approximately 7MB The file sizes after installed (Complete Install): Approximately 25MB (Reduced Install): Approximately 7MB
- The Reduced Installer [Setup_V***-***-Reduced.exe] Not selectable but the Reduced Installer The Installer file size: Approximately 2MB The file size after installed (Reduced Install): Approximately 7MB

1.2.2. How to Install

Installing process of R-SETUP - Setup Software is as follows: For users of an OS Windows NT ® 4.0 or their later versions, log in with the Administrator account before starting the following procedures.

- 1. Exit all applications that are running.
- 2. Insert the installation Disk into the CD-ROM drive of PC. (Call this E drive)
- Select "<u>R</u>un..." in the start menu of Windows task bar. Click "Reference (<u>B</u>) " and Select "Setup_V***-***-Complete" or "Setup_V***-***-Reduced" in the "E:\R-Setup" folder, and click "Open (<u>O</u>)" ("***-***" is corresponding to the R-SETUP - Setup Software versions). After the completion of specifying file, click "OK". After the following screen appears, installation starts.

Also, starting Explorer and double-click "Setup_V***-***-Complete" or "Setup_V***-***-Reduced" in the "E:\R-SETUP" folder can start installation.



4. When the following screen appears, select the language for installing and click "OK".

| Select Language | × |
|-------------------------------------|----------------------|
| | |
| Please select the language that you | u would like to use. |
| | |
| Žg—p, , 錾Œê,ð'I'ð,µ,ĉ°,³,¢□B | |
| 2 | |
| | |
| | |
| | |
| | |
| | |
| English | |
| Japanese | |
| | |
| | |
| | |
| 1 | |
| | |
| OK | Cancel |
| | |
| | |

Note) If selecting "Japanese" in OS except Japanese edition, all letters in Japanese are transformed.

5. The following screen appears. After checking the contents, click "Next >".



 Select the Destination Folder. When changing the destination for default, specify the Destination Folder by clicking "Browse...". After completing it, click "Next >".



7. Select the component to be installed. The default setting is at "Complete installation". In case that the system analysis function is not necessary and the hard disk capacity is insufficient, select "Reduced installation" ("Disk Space Remaining" indicates the disk space capacity after the R-SETUP – Setup Software installation). After the selection, click "<u>N</u>ext >".

When the Reduced Installer (Setup_V***-***-Reduced) is selected, "Select Components" is invalid and always execute "the Reduced Installation".



 Select the program group to add R-SETUP - Setup Software icons. Default setting is at "AC_SERVO_SYSTEM". After the selection, click "<u>N</u>ext >".



 The following screen appears. When click "<u>Next</u> >", dialog box for entering key words appears. When reset the items for installing, click "< <u>B</u>ack".



10. The following screen appears. Click[OK] without inputting anything. File copy starts. When click [cancel], installing is interrupted.

| Key Word | x |
|--|---|
| Please input key word, Standard Products : Input nothing and click [OK], Custom-made Products : Input key word and click [OK]. | |
| key word | |
| Press the OK button to continue. Press Cancel to abort the installation. | |
| OK Cancel | |

11. Start copying file and display the process.



12. When complete copying, the following screen appears. Click "Finish (<u>F</u>)".



1.3. How to Uninstall

Uninstalling of R-SETUP - Setup Software is as follows.

1. Select "Settings" — "Control Panel" in the start menu of Windows task bar. When double-click the icon "Add/Remove Programs", the following screen appears.



2. After select "R-Setup - Setup Software", click "<u>Change/Remove</u>". (Or click " Add/<u>Remove...</u>".) The following screen appears and uninstalling starts.



3. The following screen appears. When uninstall all the files that were installed, click "<u>A</u>utomatic". When select the file to be uninstalled, click "<u>C</u>ustom" and "<u>N</u>ext >".



4. The following screen appears. When click "Finish", uninstalling starts.



5. Uninstalling of the file starts.



2. Connecting to Servo Amplifier

2.1. Connected Cable

Exclusive cable AL-00490833-01



- CN1: 3240-12P-TO-CWithout fixed hook(HIROSE ELECTRIC CO., LTD.)CN2: HDEB-9S(50)(Connector HIROSE ELECTRIC CO., LTD.)HDE-CTF(50)(Case HIROSE ELECTRIC CO., LTD.)
- Note : Connector, case, and cable may be changed into the equivalents without notice.

For wiring diagram, see the appendix.

2.2. How to Connect

Connect the serial pin (COM) to PC connector of R series servo amplifier with the exclusive cable.

3. How to Operate

3.1. How to Activate

- 1. Select "Programs" "AC_SERVO_SYSTEM" in the start menu of Windows task bar.
- 2. Click "R-SETUP". The following start screen appears.



3.2. Main Screen

After activating R-SETUP – Setup Software, the following main screen appears.



Each function of R-SETUP – Setup Software can be accessed by selecting it in the menu bar of main screen.

| R R-SETUP | _ 🗆 × |
|---|-------|
| File Communication Parameter Monitor Test Run and Adjustment Trace Operation Help | |
| Exit 🛛 🗗 🖬 🖬 💱 🕼 🧐 🧐 🗐 🕮 🗒 🕅 | R |

[<u>F</u>ile]

• Exit : Exit R-SETUP - Setup Software.

| RR | -SETUP | | |
|------|------------------------------|--|---|
| Eile | Communication Parameter Moni | tor Test Run and Adjustment Trace Operation Help | |
| | 🦀 Communication Setting | 1 🖉 🚱 🞯 🦃 🌐 🗒 🏶 🚺 🔯 | R |
| | 9 Offline->Online | | |
| | 🍇 Communication Check | | |
| | 😢 Online->Offline | | |
| | Communication Reset | | |

[Communication]

- Communication <u>Setting...</u> : Set the communication.
 - **%**Possible to select it only at offline.
- Offline->Online...: Switch from offline to online and display the confirmation dialog box of communication state.

%Possible to select it only at offline.

- Communication <u>Check...</u> : Check the communication state.
 - **%Possible to select it only at online.**
- Online->Offline : Switch from online to offline
 ***Possible to select it only at online.**
- Communication <u>R</u>eset : Reset the communication state. (This is used when communication can not be performed. Do not use this usually.)

| R | R-SETUP | | | | | | | | |
|------|---------------|-----------|------------|-------------------------|-------|-----------|------------|------|---|
| File | Communication | Parameter | Monitor | Test Run and Adjustment | Trace | Operation | Point Data | Help | |
| 45 | 1 16 🖉 🖉 | 📝 General | Paramete | r Setting | 🐉 🐯 | S 🔯 | | | R |
| | | 💕 System | Parameter | r Setting | | | | | |
| | | Motor P | arameter : | Setting | | | | | |
| | | 📲 Transmi | t Parameti | er [Amplifier->File] | | | | | |
| | | 📲 Transmi | t Parameti | er [File->Amplifier] | | | | | |
| | | File Mat | ch Parame | ter | | | | | |
| | | | | | | | | | |

[Parameter]

- <u>General Parameter Setting...</u> : Set and save general parameters of servo amplifiers.
- <u>System Parameter Setting...</u> : Set and save system parameters of servo amplifiers.
- <u>Motor Parameter Setting...</u> : Set and save motor parameters of servo amplifiers.
- Transmit Parameter [Amplifier-><u>File</u>]... : Read all parameters of servo amplifier and save them into amplifier file together.
- Transmit Parameter [File-><u>A</u>mplifier]... : Write the parameters saved in amplifier file into servo amplifier together directly.
- File Match Parameter (<u>C</u>) (Parameter verification)... : Verifies amplifier files conformity, and then shows the verification result list.

| R-SETUP | | | |
|--|--|-------------------------|---|
| $\underline{File} \underline{C} ommunication \underline{P} arameter$ | Monitor Test Run and Adjustmer | nt Trace Operation Help | |
| 45 / 16 <mark>18</mark> 18 | 😡 Monitor Display © Multi-monitor Display | | R |
| | 🔯 Alarm History Display | | |

[<u>M</u>onitor]

- Monitor <u>D</u>isplay... : Display a list of state and operation of servo amplifier.
 ※Possible to select it only at online.
- <u>M</u>ulti-monitor Display... : Display a list of state and operation of servo amplifier.
 ※Possible to select it only at online.
- <u>A</u>larm History Display... : Display the alarm history generated in servo amplifier.



[Test Run and Adjustment]

• <u>Jogging</u> Operation... : Run the motor in positive/negative feed at the velocity command set at jogging operation.

%Possible to select it only at online.

- Operation for <u>Pulse Feed Jogging...</u>: Run the motor in positive/negative feed with the number of feed pulses and movement speed at jogging operation.
 ***Possible to select it only at online.**
- Automatic <u>N</u>otch Filter Tuning... : Perform automatic notch filter tuning.
 ※Possible to select it only at online.
- A<u>u</u>tomatic Vibration Suppressor Frequency Tuning... : Perform automatic vibration suppressor frequency tuning.

※Possible to select it only at online.

- <u>System Analysis...</u>: Performs system analysis.
 ***Possible to use by selecting complete installation.**
- Fixation <u>E</u>xcitation Operation... : Perform fixation excitation operation for linear motor.

%Possible to select it only at online.

- Analog Offset Adjustment of <u>V</u>-REF Terminal... : Perform offset adjustment of analog velocity command/torque (force) command.
 ***Possible to select it only at online.**
- Analog Offset Adjustment of <u>T</u>-COMP Terminal... : Perform offset adjustment of analog torque addition command.
 - **%**Possible to select it only at online.
- Save Result of Automatic Tuning ... : Perform save result of automatic tuning function.

%Possible to select it only at online.

• Alarm <u>R</u>eset... : Reset the current alarm of servo amplifier.

%Possible to select it only at online.

• <u>Absolute Encoder Clear...</u>: Reset the multi-revolution data of absolute encoder and the alarm in it.

%Possible to select it only at online.

| R R-SETUP | |
|---|---|
| Eile Communication Parameter Monitor Test Run and Adjustment Trace Operation Help | |
| 🍇 🖋 💋 🗹 🗭 🖬 🗣 📮 📮 🖉 🦉 🧏 👫 | R |

[Trace Operation]

• Trace Operation... : Display and save the trace operation data of servo amplifier.

| R R-SETUP | |
|--|-----------|
| File Communication Parameter Monitor Test Run and Adjustment Trace Operation | Help |
| 🎄 🖉 💋 🗹 🗭 🖬 💱 💭 🖵 🖉 🥦 器 🐯 🐯 🔯 | 😵 About R |

[<u>H</u>elp]

• <u>About...</u> : Indicate the information about R-SETUP - Setup Software.



3.3. Communication Setting

When select "<u>C</u>ommunication" – "Communication <u>S</u>etting..." in the menu bar of main screen, the following screen appears. This sets communication between R-SETUP - Setup Software and servo amplifier through serial port.

| Communication Settings | X |
|---------------------------|--------------|
| Port | |
| COM1 | • |
| Baud rate | |
| 38400 bps | • |
| Axis number select | |
| 🔽 #1 🔲 #6 | ∏ #B |
| □ # 2 □ # 7 | ∏ #C |
| □ #3 □ #8 | ∏ # D |
| □ #4 □ #9 | / #E |
| □ # 5 □ #A | / |
| | |
| OK | Cancel |

- Port (COM1 to COM256) Select COM port.
- Baud rate

Select the communication speed to servo amplifier.

In case of changing the communication speed, change the communication setting of the servo amplifier as well.

• Axis Number Select

Give check mark(s) to the numbered axis of servo amplifier for communication. Multiple selection is possible according to the number of servo amplifiers to be connected. In case of changing the axis number select, change the communication setting of the servo amplifier as well.

3.4. Switching Communication State

3.4.1. Offline->Online

Select "Communication" - "Offline->Online..." on the menu bar in the main screen, and the connection of communication cable will be confirmed.

If the cable is connected correctly, confirmation dialog box of communication state will be displayed.

3.4.2. Online->Offline

Click "Online->Offline" during online state, and all the communications with the servo amplifiers currently connected by cables will terminate and switch to offline.

3.5. Communication State Check

When select "<u>C</u>ommunication" — "Offline->O<u>n</u>line…" or "Communication <u>C</u>heck…" in the menu bar of main screen, the following dialog box appears after checking the connection of communication cable. Here starts the communication with servo amplifier connected to this cable. In case the communication already starts, update current communication state of servo amplifier.



Start the communication as follows.

- Give the check mark to the numbered axis of servo amplifier for starting communication. Note) As the servo amplifier of numbered axis without check mark in "Axis Number Select" of "Communication Settings" can not be used, the check mark can not be given.
- 2. Click [Check].
- 3. Display the servo amplifier state. Contents are as follows.
 - Connected : Now communicating with servo amplifier.
 - Not connected : Servo amplifier is not connected.
 - Error : Can not communicate due to communication error.
 - Overlap : The axis number of servo amplifier overlaps.
 - Not-corresponding : The type of servo amplifier differs. Or this can not be corresponded to the software of servo amplifier. Update the R-SETUP - Setup Software version. (R-SETUP cannot be communicated with R series servo amplifier.)

3.6. General Parameter Setting

When select "<u>Parameter</u>" - "<u>G</u>eneral Parameter Setting..." in the menu bar of main screen, General parameter settings appears. The following can be operated.

- General parameter setting of servo amplifier
- General parameter setting of amplifier file
- Saving the parameters and alarm history of the servo amplifier in the amplifier file together.
- Writing the parameters from amplifier file to servo amplifier together.
- Matching the parameters of servo amplifier with that of amplifier file
- Printing a list of parameters

When click [#1] to [#F] on left side of General parameter settings, switch to the setting of corresponding servo amplifier. When click [File], switch to General parameter settings of amplifier file.

When click tab of "Group*" above parameter list, switch the parameter group.

| R General I | Parame | ter Settin | igs | | | | | | X |
|-----------------------|-----------------|--------------|---------------------------|---------------|-----------|-------------|------|------|----------------|
| <u>Eile A</u> mplifie | er <u>D</u> isk | Print | | | | | | | |
| 📽 🖬 🏷 | 4 | · • • | h 🖬 🖨 🖪 | | | | | | |
| #1 #2 | Model Mote | or : P50B0 | 7030D Amp. : RS1L01AA | Display Leve | l evel | Ch | ange | | <u>E</u> dit |
| #3 | Group | 0 Group | 1 Group 8 Group A Group B | | | | | | 1 |
| | Page | Symbol | Name | Present ∀alue | Unit | Input Value | Min. | Max. | Standard Value |
| | 00 | TUNMODE | Tuning Mode | 00:_AutoTun | | | - | - | 00:_AutoTun |
| #6 | 02 | ATRES | Automatic Tuning Response | 5 | | | 1 | 30 | 5 |
| #7 #8 #9 | | | | | | | | | |
| #A #B | | | | | | | | | |
| #C | | | | | | | | | |
| #E | | | | | | | | | - |
| File | | | | | | | | | |
| Tuning Mode | | | | | | | | | |

Each function of general parameter setting can be accessed by selecting it in the menu bar of General Parameter Setting.

| R General P | aramete | r Settings - [C:\Data\AmpFile1.ap0] | × |
|----------------|---------|-------------------------------------|-----|
| File Amplifier | Disk P | rint | |
| ൙ Open | Ctrl+0 | 軒 軒 毎 ぬ | |
| Close | Ctrl+5 | Display Level | |
| 🔚 Save As | | Amp.: j jBasic Level | dit |
| Exit | | Group 1 Group 8 Group A Group B | |

[<u>F</u>ile]

• <u>Open...</u> : Open the amplifier file to be edited.

%Possible to select it only when setting parameter of amplifier file.

• <u>Save</u> : Write the edited amplifier file over a file and save it.

%Possible to select it only when setting parameter of amplifier file.

• Save <u>A</u>s... : Save the edited amplifier file in a file as another name.

%Possible to select it only when setting parameter of amplifier file.

• Exit : Exit General Parameter Settings.

| RG | General Parameter Settings | | | | | | | |
|------|------------------------------|---|---|--|--|--|--|--|
| Eile | Amplifier Disk Print | | | | | | | |
| | 1 Read from Amplifier | D. | | | | | | |
| | Write to Amplifier | Display Level | | | | | | |
| | 🆧 Communication State Check | Amp. : RS1L01AA Basic Level Change Edit | 1 | | | | | |

[Amplifier]

• <u>R</u>ead from Amplifier : Read the parameters from servo amplifier.

%Possible to select it only when setting parameter of servo amplifier.

- <u>W</u>rite to Amplifier : Write the edited parameter to servo amplifier.
 ***Possible to select it only when setting parameter of servo amplifier.**
- Communication State <u>Check...</u> : Check the communication state.

※Possible to select it only at online.

| R General Par | rameter Settings | | × |
|------------------------|--------------------------------------|------------------------|-----|
| <u>File A</u> mplifier | Disk Print | | |
| 📽 🖪 🏷 · | Transmit Parameter [Amplifier->File] | | |
| #1 | Transmit Parameter [File->Amplihier] | Display Level | |
| #2 | 📲 Match Parameter | A Basic Level Change E | dit |

[<u>D</u>isk]

• Transmit Parameter [Amplifier-><u>F</u>ile]...: Read all parameters and alarm history of servo amplifier and save them in amplifier file together.

%Possible to select it only when setting parameter of servo amplifier.

 Transmit Parameter [File-><u>A</u>mplifier]... : Directly write the parameters saved in amplifier file to servo amplifier together.

%Possible to select it only when setting parameter of servo amplifier.

• <u>Match Parameter...</u> : Match the parameters of servo amplifier with that of amplifier file and display a list of mismatch parameters.

%Possible to select it only when setting parameter of servo amplifier.

| R General Parameter Settings | × |
|------------------------------|--|
| Eile Amplifier Disk Print | |
| 📂 🔜 🐐 🖣 🏘 Print Ctrl+P | A Contraction of the second seco |
| H1 Model Q, Print Preview | Display Level |

[Print]

- <u>Print...</u> : Print a list of parameters.
- Print Preview ... : Display the print image of parameter list.

3.6.1. Parameter Display Level

When click "Change..." of the dialog box of General Parameter Settings, the following dialog box is displayed. Here switch the parameter level displayed in general parameter settings.

| Parameter Display Level | | | | |
|-------------------------|--------|--|--|--|
| Display Level | | | | |
| Basic Level | • | | | |
| | | | | |
| OK | Cancel | | | |

[Display Level]

- Basic Level : Display only basic level parameters.
- Standard Level : Display basic level parameters and standard ones.
- Advanced Level : Display basic, standard, and advanced level parameters.

3.6.2. Parameter Setting of Servo Amplifier

When displaying the dialog box of general parameter setting at online, the following screen appears and reads the parameters from servo amplifier.

| R General I | Parameter Settings er Disk Print | | | | | | | x |
|---|-------------------------------------|-------------------------|---------------|-----------|-------------|------------|------|----------------|
| * * * | | 1 # D. | | | | | | |
| #1 #2 | Model Motor : P50B07030 | DD Amp. : RS1L01AA | Display Leve | l əvel | Ch | ange | | <u>E</u> dit |
| #3 | Group 0 Group 1 | Group 8 Group A Group B | | | | | | |
| #4 | Page Symbol | Name | Present Value | Unit | Input Value | Min. | Max. | Standard Value |
| #5 | 00 TUNMODE Tun | ing Mode Now Reading | | | | | - | 00:_AutoTun |
| #7 #7 #8 #9 #4 #0 #0 #E #File | | Now Reading. Ple | ase wait. | | | р т | 30 | |
| Tuning Mode | | | | | | | | |

When complete reading parameters from servo amplifier correctly, "Now Reading" disappears and a list of parameters to be set is displayed.

When click [Edit...] or double-click with mouse after selecting a parameter to be edited, Edit Parameter is displayed. Depending on parameter classification, the displayed screen changes.

Example 1) KP1 : When editing Position Loop Proportional Gain 1 (Group 1 - 02)

Click tab of "Group 1" of parameter setting screen to display a list of parameters of Group 1. When click [Edit...] or double-click with mouse after selecting "02 : KP1", the following Edit Parameter screen is displayed. Enter the value to be set in "Input Value :" by keyboard.

| Edit Parameter | × |
|--|---------------|
| Group 1 - 02 KP1 | |
| Position Loop Proportional Gain 1 | |
| Input Value : | |
| Position Loop Proportional Gain 1 Proportional gain of the position controller. | A |
| | V OK X Cancel |

When click [OK], the following message is indicated in case the entered value is outside the setting range. Re-enter the value within the setting range.



When the entered value is within the setting range, return to parameter setting screen. In case the entered value in "Input Value" is different from "Present Value", it is indicated in red.

| R Genera | R General Parameter Settings | | | | | | | | | |
|---------------------------|------------------------------|-------|-----------|--|---------------|----------|-----------------|------|--------|------------------|
| Elle Amplifier Disk Print | | | | | | | | | | |
| ※ 目 省 ●4 ●1 ● 1 ● 1 ● 0. | | | | | | | | | | |
| #1 | #1 Display Level | | | | | | | | | |
| #2 | | Moto | or: P50B0 | 7030D Amp. : RS1L01AA | Advanc | ed Level | Chi | ange | | <u>E</u> dit |
| #3 | i l' | | - (- | | | . 1 . | - 1 - | - 1 | | |
| ##4 | il. | Group | 0 Group | Group 2 Group 3 Group 4 Group | 8 Group 9 Gr | oupA 0 | iroup B Group | 5C | | 1 |
| | | Page | Symbol | Name | Present Value | Unit | Input Value | Min. | Max. | Standard Value 🔺 |
| #5 | | 01 | PCFIL | Position Command Filter | 0.0 | ms | | 0.0 | 2000.0 | 0.0 |
| #6 | | 02 | KP1 | Position Loop Proportional Gain 1 | 30 | 1/s | 50 | 1 | 3000 | 30 |
| #7 | | 03 | TPI1 | Position Loop Integral Time Constant 1 | 1000.0 | ms | | 0.5 | 1000.0 | 1000.0 |
| | | 04 | TRCPGN | Higher Tracking Control, Position Compensa | 0 | % | | 0 | 100 | 0 |

Example 2) When editing GER1 : Electric Gear Ratio 1 (Group 8 - 15)

Click tab of "Group 8" of parameter setting screen to display a list of parameters of Group 8. When click [Edit...] or double-click with mouse after selecting "15 : GER1", the following Edit Parameter screen is displayed. Enter the numerator and denominator in "Input Value :" by keyboard.

| Edit Parameter | × |
|--|----------|
| Group 8 - 15 GER1 | |
| Electric Gear Ratio 1 | |
| Input Value : 1 🗲 1 | |
| Electric Gear Ratio 1 Setting range : 1/32767 to 32767/1 Electronic gear setting for position command pulse. | × |
| 🗸 ок | 🗙 Cancel |

When the entered value is within the setting range, return to parameter setting screen. In case the entered value in "Input Value" is different from "Present Value", it is indicated in red.

| R General Parameter Settings | | | | | | | | | |
|------------------------------|------|-------------|--|----------------|-----------|---------------|------|------|----------------|
| File Amplifier Disk Print | | | | | | | | | |
| | | | | | | | | | |
| #1 Model Display Level | | | | | | | | | |
| #2 | Mo | tor : P50B0 | 7030D Amp. : RS1L01AA | Advanc | ed Level | Cha | ange | | <u>E</u> dit |
| #3 | Grou | | 1 Group 2 Group 3 Group 4 Group | 8 Group 9 L Gr | our A Í G | | Cl | | |
| #4 | | | | | | | | | |
| | Page | Symbol | Name | Present Value | Unit | Input Value | Min. | Max. | Standard Value |
| #b | 13 | PCPFIL | Position Command Pulse, Digital Filter | 00:_834nsec | | | - | - | 00:_834nsec |
| #6 | 14 | PCPMUL | Position Command, Pulse Multiplier | 1 | | | 1 | 63 | 1 |
| #7 | 15 | GER1 | Electric Gear Ratio 1 | 1/1 | | 1 <i>1</i> 64 | * | * | 1/1 |
| #0 | 16 | GER2 | Electric Gear Ratio 2 | 1/1 | | | * | * | 1/1 |

Example 3) MON1 : When editing "Analog Monitor 1, Output Signal Selection" (Group A-11)
Click tab of "Group A" of parameter setting screen to display a list of parameters of Group
A. When click "Edit..." or double-click with mouse after selecting "11 : MON1", the following
Edit Parameter screen is displayed. Select the value to be set in the combo box.

| Edit Parameter | × |
|--|-----------------|
| Group A - 11 MON1 | |
| Analog Monitor 1, Output Signal Selection | |
| | |
| 05:_VMON_2mV/min-1 Velocity Monitor [2mV/min-1] | ▼ |
| | |
| Analog Monitor 1, Output Signal Selection | <u> </u> |
| Select the signal that outputs to analog monitor output 1. | × |
| [| 🗸 OK 🕺 🗶 Cancel |

Note) When set the value outside the setting range, only "Reserve" is indicated in combo box. In this case, the value can not be changed.

When click [OK], return to parameter setting screen. In case the selected value in "Input Value" is different from "Present Value", it is indicated in red.

| R General | Parame | ter Settin | gs | | | | | | × | | |
|----------------------------|---|------------|--|----------------|-------|-----------------|------|------|----------------|--|--|
| <u>File</u> <u>A</u> mplif | ier <u>D</u> isk | Print | | | | | | | | | |
| 🖻 🖪 🍅 | 📲 🕴 | 1 95 9 | h 🖬 🏼 🖨 🗟 | | | | | | | | |
| #1 | Mode | l | | Display Leve | : | | | 1 | | | |
| #2 | Motor : P50807030D Amp. : RS1L01AA Advanced Level Change Edit | | | | | | | | | | |
| #3 | | | | | | | | | | | |
| #4 | Group | 0 Group | 1 Group 2 Group 3 Group 4 Group | 8 Group 9 Gr | oup A | iroup B Group | (C) | | | | |
| | Page | Symbol | Name | Present Value | Unit | Input Value | Min. | Max. | Standard Value | | |
| #5 | 01 | OUT2 | General Purpose Output 2 | 0C:_TLC_ON | | | - | - | 0C:_TLC_ON | | |
| #6 | 02 | OUT3 | General Purpose Output 3 | 02:_S-RDY_ON | | | - | - | 02:_S-RDY_ON | | |
| #7 | 03 | OUT4 | General Purpose Output 4 | 0A:_MBR-ON_ON | | | - | - | 0A:_MBR-ON_C | | |
| #0 | 04 | OUT5 | General Purpose Output 5 | 33:_ALM5_OFF | | | - | - | 33:_ALM5_OFF | | |
| ++0 | 05 | OUT6 | General Purpose Output 6 | 35:_ALM6_OFF | | | - | - | 35:_ALM6_OFF | | |
| #9 | 06 | OUT7 | General Purpose Output 7 | 37:_ALM7_OFF | | | - | - | 37:_ALM7_OFF | | |
| #A. | 07 | OUT8 | General Purpose Output 8 | 39:_ALM_OFF | | | - | - | 39:_ALM_OFF | | |
| #B | 10 | DMON | Digital Monitor 1, Output Signal Selection | 00:_Always_OFF | | | - | - | 00:_Always_OI | | |
| | 11 | MON1 | Analog Monitor 1, Output Signal Selection | 05:_VMON_2mV/r | | 04:_VMON_1π | - | - | 05:_VMON_2m | | |
| #6 | 12 | MON2 | Analog Monitor 2, Output Signal Selection | 02:_TCMON_2V/T | | | - | - | 02:_TCMON_2\ | | |
| #D | 13 | MONPOL | Analog Monitor, Output Polarity | 00:_MON1+_MON | | | - | - | 00:_MON1+_MC | | |
| #E | 20 | COMAXIS | Setup Software, Communication Axis Numb | 01:_#1 | | | - | - | 01:_#1 | | |
| #F | 21 | COMBAUD | Setup Software, Communication Baud Rate | 05:_38400bps | | | - | - | 05:_38400bps | | |

The parameters in one group can be edited together. After completing editing parameters, select "<u>A</u>mplifier" — "<u>W</u>rite to Amplifier" in the menu bar of parameter setting screen. The following screen appears and writes the parameters to servo amplifier.

| #1 | Mode | I | | | Display Level | | | | | |
|------|---|---------|--------------------------|--------------------------|----------------|------|--------------|------|--------------|----------------|
| #2 | Motor : P50B07030D Amp. : RS1L01AA Advanced Level Cha | | | | | | ange | | <u>E</u> dit | |
| #2 | 10 | | | | | | | | | 8 |
| #0 | Group | 0 Group | 1 Group 2 Group 3 | Group 4 Group | 8 Group 9 Gro | up A | Group B Grou | p C | | |
| #4 | Page | Symbol | Name | | Present Value | Unit | Input Value | Min. | Max. | Standard Value |
| #5 | 01 | OUT2 | General Purpose Output | 2 | 0E:_VLC_ON | | | | - | 0C:_TLC_ON |
| #6 | 02 | OUT3 | General Purpose Output | 3 | 06:_A-RDY_ON | | 07A-RDY_O | 2 | - | 02:_S-RDY_0 |
| #7 | 03 | OUT4 | General Purpose Output | 4 | 0A:_MBR-ON_ON | | OB:_MBR-ON_ | | - | 0A:_MBR-ON_ |
| #0 | 04 | OUT5 | General Purpose Output | General Purpose Output 5 | | | | -8 | -20 | 33:_ALM5_OF |
| #0 | 05 | OUT6 | General Purpose Output | 6 | 35:_ALM6_OFF | | | -20 | - | 35:_ALM6_OF |
| #9 | 06 | OUT7 | General Purpose Outp | iow Writing | | | | - | - | 37:_ALM7_OF |
| #A, | 07 | OUT8 | General Purpose Outp | low writing | | - | | -27 | - | 39:_ALM_OFF |
| #B | 10 | DMON | Digital Monitor 1, Outpu | Now Writing. Ple | ase wait. | | | -0 | - | 00:_Always_C |
| #17. | 11 | MON1 | Analog Monitor 1, Out; | | | | | -0 | - | 05:_VMON_2rr |
| #12 | 12 | MON2 | Analog Monitor 2, Out; | | | | | 1 | - | 02:_TCMON_2 |
| #D | 13 | MONPOL | Analog Monitor, Outpu | | | | | -8 | | 00:_MON1+_M |
| #E | 20 | COMAXIS | Setup Software, Commo | пісацон яхіз ічані | | | 1 | | -20 | 01:_#1 |
| ++17 | 21 | COMBAUD | Setup Software, Commu | inication Baud Rate | e 05:_38400bps | | | -20 | - | 05:_38400bps |

When complete writing parameters to servo amplifier correctly, "Now writing" disappears. The value in "Input Value" disappears and indicates the value entered in "Present Value".

Note) If click another Group before writing to servo amplifier or switch to the setting of another servo amplifier or amplifier file after editing parameters, the following dialog box is displayed.

| Confirm | | × |
|---------|--|--------------------------------|
| ? | The parameters were chang Do you want to write the ch | ed. anges to the amplifier? |
| | Yes <u>N</u> o | Cancel |

When click [Yes], switch the display to another Group or another servo amplifier after writing the edited parameters to servo amplifier which is now communicating.

When click [No], switch the display to another Group or another servo amplifier without writing the edited parameters. The entered value is cancelled.

When click [Cancel], switch to another Group or another servo amplifier is not conducted.

3.6.3. Parameter Setting of Amplifier File

When display general parameter setting screen at offline or click [File], the following screen is displayed. Here the saved parameters of amplifier file can be set.



When select "<u>File</u>" - "<u>Open</u>..." in the menu bar of general parameter, the following file selection dialog box is displayed.

| Open | | | ? × |
|----------------|------------------------|-------|--------|
| Look in: 🔁 | Data | - + 1 | - 📰 📩 |
| 🗋 test | | | |
| AmpFile1.a | φ0 φ0 | | |
| | | | |
| | | | |
| | | | |
| | | | |
| File name: | AmpFile1.ap0 | | Open |
| Files of type: | Amplifier file (*.ap0) | • | Cancel |
| | | | |

Select the amplifier file to be set and click [Open]. Display a list of parameters to be set.

| | Model | or: | Amp. : | Display Leve Advanc | el ced Level | Ch | ange | | <u>E</u> dit |
|-----|-------|---------|---|------------------------|-----------------|----------------|------|------|----------------|
| | Group | 0 Group | 1 Group 2 Group 3 Group 4 Group | o8 Group 9 Gr | roup A 6 | àroup B Grou | pC | | |
| -1 | Page | Symbol | Name | Present Value | Unit | Input Value | Min. | Max. | Standard Value |
| | 00 | | Luning Mode | 00:_AutoTun | | | - | - | 00:_AutoTun |
| -11 | 02 | ATRES | Automatic Tuning Characteristic | 5 | | | - 1 | - 30 | 5 |
| | 02 | ATSAVE | Automatic Tuning Automatic Parameter Sa | 00: Auto Saving | | | - | - | 00: Auto Savi |
| | 10 | ANFILTC | Automatic Notch Filter Tuning, Torque (Ford | 50 | % | | 10 | 100 | 50 |
| | 20 | ASUPTC | Automatic Vibration Suppressor Frequency | 25 | % | | 10 | 100 | 25 |
| | 21 | ASUPFC | Automatic Vibration Suppressor Frequency | y 5 | % | | 0 | 50 | 5 |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

Edit parameters as well as that of servo amplifier.

After completing editing parameters, select "<u>F</u>ile" – "<u>S</u>ave" in the menu bar of parameter setting screen and save the edited parameters in amplifier file.

When save the edited parameters in another file which is different from the amplifier file which is now running, select "<u>File</u>" – "Save <u>As...</u>" in the menu bar. The following dialog box of saving file is displayed.

| Save As | <u>? ×</u> |
|--------------------------------------|-------------|
| Savejn: 🔂 Data | - 🔁 📸 🎟 - |
| 🔁 test | |
| AmpFile1.ap0 | |
| AmpFile2.ap0 | |
| | |
| | |
| | |
| | |
| | |
| rile name: <u>jemprile Lapu</u> | <u>Save</u> |
| Save as type: Amplifier file (*.ap0) | ▼ Cancel |
| | / |

Specify the space and name of file and click [Save]. Save the amplifier file as a new name.

Note) If click another Group before saving in amplifier file or switch to the setting of another servo amplifier after editing parameters, the following dialog box is displayed.

| Confirm | | × |
|---------|--|---|
| ? | The parameters were changed. Do you want to save the changes to the file? | |
| [| Yes No Cancel | |

When click [Yes], the display is switched to another Group or another servo amplifier after saving the edited parameters to servo amplifier which is now running.

When click [No], the display is switched to another Group or another servo amplifier without saving the edited parameters. The entered value is cancelled.

When click [Cancel], switch to another Group or another servo amplifier is not conducted.

3.6.4. Transmit Parameter [Amplifier->File]

"Transmit Parameter [Amplifier->File]" reads all parameters and alarm history of servo amplifier and save them in amplifier file together. In this case, the parameters are directly saved in the disk without displaying them.

For operation, see "3.9. Transmit Parameter [Amplifier->File]"

3.6.5. Transmit Parameter [File->Amplifier]

"Transmit Parameter [File->Amplifier]" directly writes the parameters saved in amplifier file to servo amplifier together.

For operation, see "3.10. Transmit Parameter [File->Amplifier]"

3.6.6. Match Parameter

"Match Parameter" matches the parameters of servo amplifier with that of amplifier file and indicates a list of mismatches if applicable.

When select "<u>A</u>mplifier" — "<u>M</u>atch Parameter..." in the menu bar of general parameter setting, the following selection dialog box appears.

| Open | | | <u>? ×</u> |
|----------------|------------------------|-------|------------|
| Look in: 🔁 | Data | ▼ ← € | 💣 🎟 - |
| test | | | |
| AmpFile1.a | apu apu | | |
| | | | |
| | | | |
| | | | |
| File name: | AmpFile1.ap0 | | Open |
| Files of tupe: | Amplifier file (* ap0) | - | Cancel |
| r nos or type. | Authiner ne (.aho) | | |

Select the amplifier file to be matched with servo amplifier and click [Open]. When software version of servo amplifier is different from that of amplifier file or hardware differs, the following dialog box is displayed.

| Confirm | × |
|---------|---|
| ? | The software version of servo amplifier is different. Does it continue a matching? |
| | OK Cancel |

The Servo amplifier software version of the transmission source having saved the amplifier file and that of transmission destination are different, or those hardware types are different. For this reason, non-compatible parameter may exist.

Click "Yes", and match parameter starts including the incompatible parameters. Those incompatible parameters, regardless of its setting values, will be indicated their names in red as "not matching"

Click "Cancel", matching parameters are not conducted.

Note) In case this dialog box appears according to the difference of software version.

There may be some parameters without interchangeability depending on the software version. Those without interchangeability are indicated in matching results (contents of difference) regardless of their setting. Here, the parameters are indicated in red as well. Note) In case this dialog box appears according to the difference of hardware type.

There may be some parameters without interchangeability because of the difference of encoder interface circuit. Those without interchangeability are indicated in matching results (contents of difference) regardless of their setting. Take care in using multiple hardware servo amplifiers.

In case that the classification of servo amplifier is different from that of amplifier file, the following dialog box appears and matching parameters cannot be conducted.



When parameter matching starts, read the parameters from servo amplifier. When complete reading parameters from servo amplifier correctly, "Now Reading" disappears and parameter matching process starts.

| | a - m - | 89 48 - | | s | | | | | | |
|---|------------------|--------------------------------------|------------------------|-----------------------|-----------------------|----------|-------------|-------------|------|-----------------|
| 1 | Mode | Incore | | Incurrent | Display Leve | I | | 1 | | |
| 2 | Mot | Motor : P50B07030D Amp. : RS1L01AA | | | | ed Level | | ange | | <u></u> dit |
| 3 | Groun | | بادسسواه | | un al cum al cu | م أ ه | | - 01 | | |
| + | Demo | Sumbol | i i l'uroup 2 i T | blome | roup 8 Group 9 Gr | up A U | | pul Luco | May | Stepdard Value |
| 5 | Page | TUNMODE | Tuping Mode | rvanie | Present value | UTIIL | Input value | 19101. | Max. | Standard Value |
| 3 | 01 | ATCHA | Automatic Tun | Now Reading | | | | - | - | 00: Positioning |
| 7 | 02 | ATRES | Automatic Tun | Now Reading, Please | e wait. | | | 1 | 30 | 5 |
| | 03 | ATSAVE | Automatic Tun | 2 | | | | - | - 20 | 00:_Auto_Savir |
| 4 | 10 | ANFILTC | Automatic Note | | | | | 10 | 100 | 50 |
| | 20 | ASUPTC | Automatic Vibi | | | | | 10 | 100 | 25 |
| | 21 | ASUPFC | Automatic Vibra | non suppressor rreque | encys | 76 | | 0 | 50 | 5 |

When completing parameter matching process, "Now Processing" disappears and the following list of parameter matching result is displayed.

| | | 0 | | | | Diale | | | | |
|----------|------|---|---------------|------|------|---|---------------|--|--|--|
| Arlpiner | | | | | | Disk | | | | |
| Mode | Page | Name | Present Value | Mode | Page | Name | Present Value | | | |
| 1 | 02 | Position Loop Proportional Gain 1 | 50 | 1 | 02 | Position Loop Proportional Gain 1 | 30 | | | |
| 1 | 14 | Velocity Loop Integral Time Constant 1 | 50.0 | 1 | 14 | Velocity Loop Integral Time Constant 1 | 49.2 | | | |
| 0 | 02 | Automatic Tuning Response | 20 | 0 | 02 | Automatic Tuning Response | 5 | | | |
| А | 11 | Analog Monitor 1, Output Signal Selection | 06:_VMON_3n | A | 11 | Analog Monitor 1, Output Signal Selection | 05:_VMON_2n | | | |
| | | Motor Parameter | 0D30 H | | | Motor Parameter | 0C31 H | | | |
| | | Motor Parameter | 0150 H | | | Motor Parameter | 0155 H | | | |
| | | Motor Parameter | 0888 H | | | Motor Parameter | ODAC H | | | |
| | | Motor Parameter | 0000 H | | | Motor Parameter | 007B H | | | |
| | | Motor Parameter | 02EF H | | | Motor Parameter | 02ED H | | | |
| | | Motor Parameter | 02EF H | | | Motor Parameter | 02ED H | | | |
| | | Motor Parameter | 044C H | | | Motor Parameter | 04DE H | | | |
| | | Motor Parameter | 10B0 H | | | Motor Parameter | 1470 H | | | |
| | | Motor Parameter | 002B H | | | Motor Parameter | 002E H | | | |
| | | Motor Parameter | 0153 H | | | Motor Parameter | 0136 H | | | |
| | | Motor Parameter | 0033 H | | | Motor Parameter | 003C H | | | |
| | | Motor Parameter | 0055 H | | | Motor Parameter | 0052 H | | | |
| | | Motor Parameter | FFC8 H 🗨 | | | Motor Parameter | FFD0 H | | | |
| • | | | Þ | | | | | | | |
| | | 1 | | | | | Class | | | |

If match parameters in case that the software version of servo amplifier is different from that of amplifier file, other kinds of parameters are displayed. The parameters are displayed all in red.

When click [Print], print a list of parameters being displayed.

3.7. System Parameter Setting

When select "<u>P</u>arameter" - "<u>S</u>ystem Parameter Setting..." in the menu bar of main screen, System parameter settings appears. The following can be operated.

- System parameter setting of servo amplifier
- System parameter setting of amplifier file
- Saving the parameters of servo amplifier in amplifier file together
- Writing the parameters from amplifier file to servo amplifier together.
- Matching the parameters of servo amplifier with that of amplifier file
- Printing a list of parameters

When click [#1] to [#F] on left side of System parameter settings, switch to the setting of corresponding servo amplifier. When click [File], switch to System parameter settings of amplifier file.

| R System Parameter Settings | | | | | | | |
|-----------------------------|----------|--|-----------------------|-------------|--|--|--|
| File Amplifie | r Disk | k Print | | | | | |
| 🛩 🖪 🍋 | 4 | •1 71 71 71 74 49 🖪 | | | | | |
| #1 #2 #3 | Model | | | | | | |
| | Page | Name | Present Value | Input Value | | | |
| #4 | | Amplifier Capacity | 15_Ampere | | | | |
| #5 | | Motor Motion | Rotary_Motor | | | | |
| #0 | | Control Power, Input Voltage | 200V Class | | | | |
| ++0 | | Control Power, Input Type | AC Single-Phase | | | | |
| #7 | | Main Power, Input Voltage | 200V_Class | | | | |
| #8 | 00 | Main Power, Input Type | 00:_AC_3-Phase | | | | |
| | 01 | Motor Encoder Type | 00:_Incremental_ENC | | | | |
| #9 | 02 | Incremental Encoder, Function Setting | 00:_Standard | | | | |
| #A | 03 | Incremental Encoder, Resolution Setting | 2000 | | | | |
| | 04 | Absolute Encoder, Function Setting | 04:PA035C-2.5MH_Manu | | | | |
| | 05 | Absolute Encoder, Resolution Setting | 00:_2048_FMT | | | | |
| #C | 06 | Motor Type | P50B07020D(0000-0288) | | | | |
| #0 | 08 | Control Mode | 01:_Velocity | | | | |
| | 09 | Position Loop Control and Position Loop Er | 00:_Motor_Encoder | | | | |
| #E | 0A | External Encoder, Resolution Setting | 2000 | | | | |
| ΨF | 0B | Regenerative Registor Selection | 01:_Built-In_R | | | | |
| | | | | | | | |
| File | | | | | | | |

Each function of system parameter setting can be accessed by selecting it in the menu bar of System Parameter Settings.

| R System P | R System Parameter Settings - [C:\Data\AmpFile1.ap0] | | | | | | | |
|-----------------|--|---------|---------------|--------------|--|--|--|--|
| Eile Amplifier | ' <u>D</u> isk <u>P</u> r | int | | | | | | |
| 🗃 Open Close | Ctrl+0 | 都都都 魯 🛛 | | | | | | |
| Save | Ctrl+S | Amp. : | | <u>E</u> dit | | | | |
| Exit | | Name | Present Value | Input Value | | | | |

[<u>F</u>ile]

• <u>Open...</u> : Open the amplifier file to be edited.

%Possible to select it only when setting parameter of amplifier file.

• <u>Save</u> : Write the edited amplifier file over a file and save it.

%Possible to select it only when setting parameter of amplifier file.

• Save <u>As...</u> : Save the edited amplifier file in a file as another name.

 $\ensuremath{\ensuremath{\mathcal{R}}}$ Possible to select it only when setting parameter of amplifier file.

• Exit : Exit System Parameter Settings.

| Rs | R System Parameter Settings | | | | |
|-----------------------|-----------------------------|-----------------|--------------|--|--|
| Eile | Amplifier Disk Print | | | | |
| | Read from Amplifier | ۵. | | | |
| PI Write to Amplifier | | | | | |
| | K Communication State Check | Amp. : RS1L01AA | <u>E</u> dit | | |

[Amplifier]

• <u>R</u>ead from Amplifier : Read the parameters from servo amplifier.

%Possible to select it only when setting parameter of servo amplifier.

- <u>W</u>rite to Amplifier : Write the edited parameter to serve amplifier.
 - **%**Possible to select it only when setting parameter of servo amplifier.
- Communication State <u>Check...</u> : Check the communication state.
 ***Possible to select it only at online.**

| R System Parameter Settings | | | | | |
|-----------------------------|---|---------|--|--|--|
| <u>File Amplifier Disk</u> | Print | | | | |
| 📽 🖬 🐐 · 🏪 1 | ransmit Parameter [Amplifier->File] | | | | |
| | rransmit Parameter [File->Amplifier] Natch Parameter | A Edit. | | | |

[<u>D</u>isk]

• Transmit Parameter [Amplifier-><u>F</u>ile]...: Read all parameters from servo amplifier and save them in amplifier file together.

%Possible to select it only when setting parameter of servo amplifier.

• Transmit Parameter [File-><u>A</u>mplifier]... : Directly write the parameters saved in amplifier file to servo amplifier together.

%Possible to select it only when setting parameter of servo amplifier.
• <u>Match Parameter...</u> : Match the parameters of servo amplifier with that of amplifier file and display a list of mismatch parameters.

%Possible to select it only when setting parameter of servo amplifier.

| R System Parameter Settings | × |
|-----------------------------|---|
| Eile Amplifier Disk Print | |
| 🛩 🖃 🐐 🖣 Print Ctrl+P | |
| Model Q. Print Preview | |

[Print]

- <u>Print...</u> : Print a list of parameters.
- Print Preview ... : Display the print image of parameter list.

3.7.1. Parameter Setting of Servo Amplifier

When displaying the dialog box of general parameter setting at online, the following screen appears and reads the parameters from servo amplifier.

| R System | Parameter Settings | x |
|-------------|--------------------------------------|--------------|
| Eile Amplif | ier <u>D</u> isk <u>P</u> rint | |
| 学日 指 | | |
| #1 | Model | |
| #2 | Motor : JP50807030D Amp. : JRS1L01AA | <u>E</u> dit |
| #3 | | |
| #4 | | |
| #5 | Now Reading | |
| #6 | New Dearfue Diagonality | |
| #7 | Now heading. Flease wait. | |
| #8 | | |
| #9 | | |
| #4 | | |
| #B | | |
| #C | | |
| #D | | |
| #E | | |
| #F | | |
| File | | |

When complete reading parameters from servo amplifier correctly, "Now Reading" disappears and a list of parameters to be set is displayed.

When click [<u>E</u>dit...] or double-click with mouse after selecting a parameter to be edited, parameter editing screen is displayed. Depending on parameter classification, the displayed screen changes. For parameter editing, see "3.6.2 Parameter setting of servo amplifier"

After parameter editing, select "<u>A</u>mplifier" – "<u>W</u>rite to Amplifier" in the menu bar of parameter setting screen. The following dialog box appears.

| Confirm | × |
|---------|--|
| ? | The parameters are written to the amplifier. Is it all right? |
| | Cancel |

When click "OK", the parameters are written to servo amplifier.

When click "Cancel", the parameters are not written.

| R System | Paran ier Dis | neter Settings sk Print | | X |
|-----------------|------------------|---|-----------------------|-------------------|
| | | •1 9:9:9:9: 0 | | |
| #1 #2 | Mod | del otor : P50B07030D Amp. : RS1L | 01AA | Edt |
| #3 | Page | e Name | Present Value | Input Value |
| #4 | | Amplifier Capacity | 15_Ampere | |
| #5 | | Motor Motion Now Writing | | |
| #16 | | Control Power, Input Volta | | |
| #0 | | Control Power, Input Type Now Writin | g. Please wait. | |
| #7 | | Main Power, Input Voltage | | |
| #8 | 00 | Main Power, Input Type | | |
| #19 | 01 | Motor Encoder Type | | |
| | 02 | Incremental Encoder, Func | 2000 | |
| #A, | 03 | Absolute Encoder, Nesolation Setting | 04:PA035C-2 5MH_Mapu | |
| #B | 05 | Absolute Encoder, Resolution Setting | 00: 2048 FMT | |
| #0 | 06 | Motor Type | P50B07020D(0000-0288) | |
| | 08 | Control Mode | 01:_Velocity | |
| #0 | 09 | Position Loop Control and Position Loop E | n 00:_Motor_Encoder | |
| #E | 0A | External Encoder, Resolution Setting | 2000 | |
| #F | 08 | Regenerative Registor Selection | 01:_Built-In_R | 00:_Not_Connected |
| File | - | | | |

When complete writing parameters to servo amplifier correctly, "Now writing" disappears. The value in "Input Value" disappears and indicates the value entered in "Present Value".

Note) If click another Group before writing to servo amplifier or switch to the setting of another servo amplifier or amplifier file after editing parameters, the following dialog box is displayed.

| Confirm | × | < |
|---------|--|---|
| ? | The parameters were changed. Do you want to write the changes to the amplifier? | |
| | <u>Yes</u> <u>N</u> o Cancel | |

When click [Yes], the display is switched to another Group or another servo amplifier after writing the edited parameters to servo amplifier which is currently communicating.

When click [No], the display is switched to another Group or another servo amplifier without writing the edited parameters. The entered value is cancelled.

3.7.2. Parameter Setting of Amplifier File

When display System parameter setting screen at offline or click [File], the following screen is displayed. Here the saved parameters of amplifier file can be set.



When select "<u>File</u>" - "<u>Open</u>..." in the menu bar of System parameter setting, the following file selection dialog box is displayed.

| Open | | | <u>?</u> × |
|--------------------|------------------------|-------|------------|
| Look in: 🔂 | Data | - + 1 | - 🎬 🎟 |
| test AmpFile1.a | р0 р0 | | |
| File name: | AmpFile1.ap0 | | Open |
| Files of type: | Amplifier file (*.ap0) | • | Cancel |

Select the amplifier file to be set and click [Open]. Display a list of parameters to be set.

| R Syst | em P | aram | eter Settings - [C:\Data\AmpFile1.ap | 0] | X |
|----------------|---------|----------------|--|-----------------------|--------------|
| <u>File An</u> | nplifie | r <u>D</u> isk | : <u>P</u> rint | | |
| 🖻 🖬 | * | | xi 및i 및i 및i 🖨 🖸 | | |
| #1 | | Mode Mo | el tor : Amp. : | | <u>E</u> dit |
| #3 | -11 | Page | Name | Present Value | Input Value |
| #4 | | | Amplifier Capacity | 15_Ampere | |
| #5 | | | Motor Motion | Rotary_Motor | |
| | -11 | | Control Power, Input Voltage | 200V Class | |
| #6 | | | Control Power, Input Type | AC Single-Phase | |
| #7 | | | Main Power, Input Voltage | 200V_Class | |
| #8 | | 00 | Main Power, Input Type | 00:_AC_3-Phase | |
| | -11 | 01 | Motor Encoder Type | 00:_Incremental_ENC | |
| #9 | | 02 | Incremental Encoder, Function Setting | 00:_Standard | |
| #4 | | 03 | Incremental Encoder, Resolution Setting | 2000 | |
| | -11 | 04 | Absolute Encoder, Function Setting | 04:PA035C-2.5MH_Manu | |
| #B | | 05 | Absolute Encoder, Resolution Setting | 00:_2048_FMT | |
| #C | | 06 | Motor Type | P50B07030D(0000-0289) | |
| #0 | | 08 | Control Mode | 02:_Position | |
| | -11 | 09 | Position Loop Control and Position Loop En | 00:_Motor_Encoder | |
| #E | | 0A | External Encoder, Resolution Setting | 2000 | |
| #F | | 08 | Regenerative Registor Selection | 01:_Built-In_R | |
| File | | | | | |

Edit parameters as well as that of servo amplifier.

After parameter editing, select "<u>File</u>" - "<u>Save</u>" in the menu bar of parameter setting screen. The following dialog box appears.

| Confirm | X |
|---------|---|
| ? | The parameters are saved to the file. Is it all right? |
| | Cancel |

When click [OK] to save the edited parameters in amplifier file.

When click [Cancel], the parameters are not saved.

When save the edited parameters in another file which is different from the amplifier file which is now running, select "<u>File</u>" – "Save <u>As...</u>" in the menu bar. The following dialog box of saving file is displayed.

| Save As | <u>?</u> × |
|--|------------|
| Save jn: 🔁 Data 💽 🔶 📸 🎫 | |
| test | |
| MmpFile1.ap0 | |
| a AmpFile2.apU | |
| | |
| | |
| | |
| | _ |
| File <u>n</u> ame: <u>AmpFile1.ap0</u> <u>S</u> av | е |
| Save as type: Amplifier file (*.ap0) | el |
| | /// |

Specify the space and name of file and click [Save]. Save the amplifier file as a new name.

Note) If click another Group before saving in amplifier file or switch to the setting of another servo amplifier after editing parameters, the following dialog box is displayed.

| Confirm | | | | × |
|---------|--------------------------|-----------------------------------|------------------------|---------|
| ? | The parame Do you wan | ters were char t to save the c | nged. :hanges to th | e file? |
| [| <u>Y</u> es | No | Cancel | |

When click [Yes], the display is switched to another servo amplifier after saving the edited parameters to servo amplifier which is now running.

When click [No], the display is switched to another servo amplifier without saving the edited parameters. The entered value is cancelled.

When click [Cancel], switch to another servo amplifier is not conducted.

3.7.3. Transmit Parameter [Amplifier->File]

"Transmit Parameter [Amplifier->File]" reads all parameters of servo amplifier and save them in amplifier file together. In this case, the parameters are directly saved in the disk without displaying them.

For operation, see "3.9. Transmit Parameter [Amplifier->File]".

3.7.4. Transmit Parameter [File->Amplifier]

"Transmit Parameter [File->Amplifier]" directly writes the parameters saved in amplifier file to servo amplifier together.

For operation, see "3.10. Transmit Parameter [File->Amplifier]".

3.7.5. Match Parameter

"Match Parameter" matches the parameters of servo amplifier with that of amplifier file and indicates a list of mismatches if applicable.

For operation, see "3.6.6. Match parameter".

3.8. Motor Parameter Setting

When select "<u>P</u>arameter" - "<u>M</u>otor parameter Setting..." in the menu bar of main screen, Motor parameter settings appears. The following can be operated.

- Motor parameter setting of servo amplifier
- Motor parameter setting of amplifier file
- Saving the parameters of servo amplifier in amplifier file together
- Writing the parameters from amplifier file to servo amplifier together.
- Matching the parameters of servo amplifier with that of amplifier file
- Printing a list of parameters

When click [#1] to [#F] on left side of Motor parameter settings, switch to the setting of corresponding servo amplifier. When click [File], switch to Motor parameter settings of amplifier file.

| R Motor P | Parameter Settings | | × |
|-----------------|---|-----------------------|------------------------|
| Eile Amplif | ier <u>D</u> isk <u>P</u> rint | | |
| 📽 🖬 🎕 | 🐗 👀 💱 🗣 👫 🖨 🗅 | | |
| #1 #2 | Model Motor : P50B07020D Amp. : R | SILOIAA | |
| #3 | System | | |
| #4 | Name | Present Value | |
| #5 | Amplifier Capacity | 15_Ampere | |
| #6 | Motor Motion | Rotary_Motor | |
| | Main Power, Input Voltage | 200V_Class | |
| #7 | Motor Encoder Type | 00:_Incremental_ENC | |
| #8 | Incremental Encoder, Function Setting | 00:_Standard | |
| #19 | Incremental Encoder, Resolution Setting | 2000 | |
| ++3 | Absolute Encoder, Function Setting | 04:PA035C-2.5MH_Manu | |
| #A | Absolute Encoder, Resolution Setting | 00:_2048_FMT | |
| #B | I | | |
| #10 | | | Motor select from list |
| | ⊢ Motor Setting | | |
| #D | Name | Present Value | Input Value |
| #E | Motor Tupe | P50B07020D(0000-0288) | input value |
| ++T | interior rype | | |
| | | | |
| File | | | |

Each function of motor parameter setting can be accessed by selecting it in the menu bar of Motor Parameter Settings.

| R Motor Pa | rameter 9 | iettings - [C:\Data\AmpFile1.ap0] | × |
|----------------|-------------------|-----------------------------------|---|
| Eile Amplifier | r <u>D</u> isk Pi | rint | |
| 🗃 Open | Ctrl+0 | 박 태 밖 음 D. | |
| Save | Ctrl+5 | Amp. : | |
| Bave As | | | |
| Exit | | | |

[<u>F</u>ile]

• <u>Open...</u> : Open the amplifier file to be edited.

%Possible to select it only when setting parameter of amplifier file.

• <u>Save</u> : Write the edited amplifier file over a file and save it.

%Possible to select it only when setting parameter of amplifier file.

• Save <u>As...</u>: Save the edited amplifier file in a file as another name.

 $\ensuremath{\ensuremath{\mathbb{X}}}\xspace^{-1}$ Possible to select it only when setting parameter of amplifier file.

• Exit : Exit Motor Parameter Settings.

| R M | R Motor Parameter Settings | | | |
|------|------------------------------|-----------------|--|--|
| Eile | Amplifier Disk Print | | | |
| 2 | 4 Read from Amplifier | D. | | |
| | Write to Amplifier | | | |
| + | K Communication State Check | Amp. : RS1L01AA | | |

[Amplifier]

• <u>R</u>ead from Amplifier : Read the parameters from servo amplifier.

%Possible to select it only when setting parameter of servo amplifier.

- <u>W</u>rite to Amplifier : Write the edited parameter to servo amplifier.
 - **※**Possible to select it only when setting parameter of servo amplifier.
- Communication State <u>Check...</u> : Check the communication state.
 ※Possible to select it only at online.

| R Motor Para | R Motor Parameter Settings | | | | |
|------------------------|--------------------------------------|---|--|--|--|
| <u>File A</u> mplifier | Disk Print | | | | |
| 📽 🖬 🐐 - | Transmit Parameter [Amplifier->File] | | | | |
| #1 #2 | Transmit Parameter [rile->Amplifier] | A | | | |

[<u>D</u>isk]

• Transmit Parameter [Amplifier-><u>File</u>]... : Read all parameters of servo amplifier and save them in amplifier file together.

%Possible to select it only when setting parameter of servo amplifier.

• Transmit Parameter [File-><u>A</u>mplifier]... : Directly write the parameters saved in amplifier file to servo amplifier together.

%Possible to select it only when setting parameter of servo amplifier.

• <u>Match Parameter...</u> : Match the parameters of servo amplifier with that of amplifier file and display a list of mismatch parameters.

%Possible to select it only when setting parameter of servo amplifier.

| R Motor Parameter Settings | × |
|----------------------------|---|
| Eile Amplifier Disk Print | |
| 🤐 🔄 🐐 ♦ 🚭 Print Ctrl+P 🐧 | |
| Model Q Preview | |

[Print]

- <u>Print...</u> : Print a list of parameters.
- Print Preview ... : Display the print image of parameter list.

3.8.1. Parameter Setting of Servo Amplifier

When displaying the dialog box of Motor parameter setting at online, the following screen appears and reads the parameters from servo amplifier.

| R Motor P | arameter Setting | × |
|-------------|---------------------------|------------------------|
| File Amplif | er Disk Print | |
| 🖻 🖬 🐌 | | |
| #1 | Model Amp. : | |
| #3 | System | 1 |
| #4 | | |
| #5 | Now Reading | |
| #6 | | |
| #7 | Now Reading, Please wait. | |
| #8 | | 6 |
| #9 | | |
| #A. | | 7 |
| #B | | |
| #C | | Motor select from list |
| #D | Motor Setting | t |
| #F | | |
| HF | | |
| | | |
| | | |

When complete reading parameters from servo amplifier correctly, "Now Reading" disappears and a list of parameters to be set is displayed.

When click [Motor select from list...] or double-click the field of "Motor Setting", a dialog box of motor selection appears.



Select the motor parameter file which writes to servo amplifier in the list. When click [OK], return to parameter setting screen. When the model name of selected motor is different from "Present Value", the model name is indicated in "Input Value" in red.

| #9 | Absolute Encoder, Function Setting | 04:PA035C-2.5MH_Manu | |
|----------|--------------------------------------|-----------------------|------------------------|
| #A | Absolute Encoder, Resolution Setting | 00:_2048_FMT | |
| #B #C | | | Motor select from list |
| HD. | Motor Setting | | |
| | Name | Present Value | Input Value |
| #E | Motor Type | P50B07020D(0000-0288) | P50B07030D(0000-0289) |
| #F | | | |
| File | | | |

After parameter editing, select "<u>A</u>mplifier" – "<u>W</u>rite to Amplifier" in the menu bar of parameter setting screen. The following dialog box appears.

| Confirm | X |
|---------|--|
| ? | The parameters are written to the amplifier. Is it all right? |
| | OK Cancel |

When click [OK], the parameters are written to servo amplifier. When click [Cancel], the parameters are not written.

| 9.19 | | | |
|------|--------------------------------------|--------------------------|--------------------------------|
| 1 | Model Amp. : RS1L01AA | | |
| 3 | Sustem | | |
| 4 | Name | Present Value | |
| 5 | Amplifier Capacity | Writing | |
| | Motor Motion | | |
| _ | Main Power, Input Voltage No | ow Writing, Please wait, | |
| 7 | Motor Encoder Type | | |
| 8 | Incremental Encoder, Function | | |
| | Incremental Encoder, Resolutio | | |
| | Absolute Encoder, Function Se | | |
| Δ, | Absolute Encoder, Resolution Setting | 00:_2048_FMT | |
| | | | |
| | | | <u>M</u> otor select from list |
| | Motor Setting | | |
| | | [| L L AVI |
| | INAME | Present Value | Input Value |

When complete writing parameters to servo amplifier correctly, "Now writing" disappears. The value in "Input Value" disappears and indicates the value entered in "Present Value".

Note) If click another Group before writing to servo amplifier or switch to the setting of another servo amplifier or amplifier file after editing parameters, the following dialog box is displayed.

| Confirm | | | | × |
|---------|----------------------------------|------------------------------|------------------------|-----------|
| ? | The parameters Do you want to | were change write the cha | ed. anges to the an | nplifier? |
| | <u>Y</u> es | No | Cancel | |

When click [Yes], the display is switched to another servo amplifier after writing the edited parameters to servo amplifier which is currently communicating.

When click [No], the display is switched to another servo amplifier without writing the edited parameters. The entered value is cancelled.

When click [Cancel], switch to another servo amplifier is not conducted.

3.8.2. Parameter Setting of Amplifier File

When display General parameter setting at offline or click [File], the following screen is displayed. Here the saved parameters of amplifier file can be set.

| - | | | |
|--------------|--------------------------------|---------------|------------------------|
| R Motor P | arameter Settings - [Untitled] | | X |
| File Amplifi | er Disk Print | | |
| 🖻 🖩 🏷 | 41 41 新新新 🔮 🕑 | | |
| #1 | Model | | |
| #2 | Motor : Amp. : | | |
| #3 | System | | _ |
| #4 | Name | Present Value | |
| #5 | | | |
| #6 | | | |
| #7 | | | |
| #8 | | | |
| #9 | | | |
| #A | | | |
| #B | 1 I | | Mater select from list |
| #C | Motor Setting | | |
| #D | Name | Present Value | Input Value |
| #E | | | |
| #F | | | |
| File | | | |

When select "<u>File</u>" - "<u>Open</u>..." in the menu bar of System parameter setting, the following file selection dialog box is displayed.

| Open | | | ? × |
|----------------|------------------------|---------|--------|
| Look in: 🔁 | Data | - + E (| *⊞* |
| 🗋 test | | | |
| AmpFile1.a | φ0 00 | | |
| | - | | |
| | | | |
| | | | |
| I | | | |
| File name: | AmpFile1.ap0 | | Open |
| Files of type: | Amplifier file (*.ap0) | • | Cancel |
| | | | /// |

Select the amplifier file to be set and click [Open]. Display a list of parameters to be set.

| R Motor P | arameter Settings - [C:\Data\AmpFile1 | .ap0] | × | | |
|---------------------|---|-----------------------|------------------------|--|--|
| <u>File Amplifi</u> | ier <u>D</u> isk Print | | | | |
| 🖻 🖬 省 | 세 세 및 및 및 🖶 🕼 | | | | |
| #1 #2 | #1 Model #2 Motor: Amp.: | | | | |
| #3 | System | | | | |
| #4 | Name | Present Value | | | |
| #5 | Amplifier Capacity | 15_Ampere | | | |
| #16 | Motor Motion | Rotary_Motor | | | |
| | Main Power, Input Voltage | 200V_Class | | | |
| #7 | Motor Encoder Type | 00:_Incremental_ENC | | | |
| #8 | Incremental Encoder, Function Setting | 00:_Standard | | | |
| | Incremental Encoder, Resolution Setting | 2000 | | | |
| #9 | Absolute Encoder, Function Setting | 04:PA035C-2.5MH_Manu | | | |
| #A. | Absolute Encoder, Resolution Setting | 00:_2048_FMT | | | |
| #B | | | kinter och staten form | | |
| #C | | | | | |
| #n | Motor Setting | | | | |
| | Name | Present Value | Input Value | | |
| #E | Motor Type | P50B07030D(0000-0289) | | | |
| #F | | | | | |
| File | | | | | |

Edit parameters as well as that of servo amplifier.

After parameter editing, select "<u>File</u>" - "<u>Save</u>" in the menu bar of parameter setting screen. The following dialog box appears.

| Confirm | X |
|---------|---|
| ? | The parameters are saved to the file. Is it all right? |
| | OK Cancel |

When click [OK] to save the edited parameters in amplifier file. When click [Cancel], the parameters are not saved.

When save the edited parameters in another file which is different from the amplifier file which is now running, select "<u>F</u>ile" – "Save <u>A</u>s..." in the menu bar. The following screen of saving file is displayed.

| Save As | ? × |
|--|-----|
| Savejn: 🔁 Data 🗾 🖛 🗈 📸 🎫 | |
| ि test जि AmpFile1.ap0 जि AmpFile2.ap0 | |
| File name: AmpFile1.ap0 Save | |
| Save as type: Amplifier file (*.ap0) | |

Specify the space and name of file and click [Save]. Save the amplifier file as a new name.

Note) If click another Group before saving in amplifier file or switch to the setting of another servo amplifier after editing parameters, the following dialog box is displayed.

| Confirm | | | | X |
|---------|----------------------------|--------------------------------|-------------------------|---------|
| ? | The paramet Do you want | ers were char to save the c | nged. thanges to the | e file? |
| [| <u>Y</u> es | No | Cancel | |

When click [Yes], the display is switched to another servo amplifier after saving the edited parameters to servo amplifier which is currently running.

When click [No], the display is switched to another servo amplifier without saving the edited parameters. The entered value is cancelled.

When click [Cancel], switch to another servo amplifier is not conducted.

3.8.3. Transmit Parameter [Amplifier->File]

"Transmit Parameter [Amplifier->File]" reads all parameters of servo amplifier and save them in amplifier file together. In this case, the parameters are directly saved in the disk without displaying them.

For operation, see "3.9. Transmit Parameter [Amplifier->File]".

3.8.4. Transmit Parameter [File->Amplifier]

"Transmit Parameter [File->Amplifier]" directly writes the parameters saved in amplifier file to servo amplifier together.

For operation, see "3.10. Transmit Parameter [File->Amplifier]".

3.8.5. Match Parameter

"Match Parameter" matches the parameters of servo amplifier with that of amplifier file and indicates a list of mismatches if applicable.

For operation, see "3.6.6 Match parameter".

3.9. Transmit Parameter [Amplifier->File]

"Transmit Parameter [Amplifier->File]" reads all parameters of servo amplifier and save them in amplifier file together. In this case, the parameters are directly saved in the disk without displaying them.

When select "Parameter" — "Transmit Parameter [Amplifier-><u>F</u>ile]..." in the menu bar of main screen or select "Amplifier" — "Transmit Parameter [Amplifier-><u>F</u>ile]..." in the menu bar of General parameter settings / System parameter settings / Motor parameter settings, the following appears.

| . | | | | |
|---|---|-----------------------------|-------------|---------|
| Fransmissio | on source | - | - | |
| | • #1 | C #6 | C #8 | |
| | C #2 | C #7 | ○ #C | |
| | C #3 | C #8 | C #D | |
| | C #4 | C #9 | C #E | |
| | C #5 | C #A | C #F | |
| The servo | amplifier mod | el of a transmis | ssion sourc | e: |
| | | RS1L | .01AA | |
| Fransmissio The file na | on destination me of a transr | mission destina | tion : | Browse |
| Transmissio The file na | on destination me of a transm | mission destina | ition : | Browse. |
| Transmissio The file na | on destination me of a transm parameter to | mission destina | ition : | Browse. |
| Transmission The file nat | on destination me of a transf parameter to f al Parameter | nission destine transmit | ition : | Browse. |
| Transmission The file name The kind of Generation System | on destination me of a transm parameter to t al Parameter) Parameter | nission destina | tion : | Browse. |
| Transmission The file nation The kind of Generation System Motor F | parameter to 1 al Parameter 1 Parameter 2 Parameter 2 Parameter | nission destina | tion : | Browse. |

Transmit the parameters and alarm history from servo amplifier to amplifier file referring to the following procedure.

- 1. Select the axis number of servo amplifier which transmits parameters in "Transmission source".
- 2. When click [Browse...] in "Transmission destination", the following dialog box of saving file appears.

| Save As | | | | | <u>?×</u> |
|--------------------------------------|-----|---|----------------|--------------|-----------|
| Save jn: 🔄 Data | • + | £ | ď . | | |
| test | | | | | |
| AmpFile1.apu | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| File name: AmpFile1.ap0 | | _ | | <u>S</u> ave | , |
| Save as type: Amplifier file (*.ap0) | | • | | Cance | el |
| | | _ | _ | | /// |

Specify the space and name of a file and click "Save".

3. When click [Execute], the following appears and reads parameters and alarm history from servo amplifier.

| Transmit Pa | rameter [Am | plifier->File |] | × |
|-------------|------------------|------------------|----------------|---------------|
| -Transmissi | on source | | | |
| | € #1 | C #6 | C #8 | |
| | C #2 | C #7 | C #C | |
| | C #3 | C #8 | C #D | |
| | C #4 | C #9 | C #E | |
| | C #5 | C#A | C #F | |
| The serve | amplifier mode | el of a transmis | ssion source : | |
| Now Rea | aling | | | |
| | ineauing. Flease | | | |
| The kind of | f parameter to t | ransmit | | |
| 🔽 Gener | al Parameter | | | |
| 🔽 System | n Parameter | | | |
| Motor | Parameter | | | |
| | | E | (ecute | E <u>×</u> it |

4. When complete reading parameters and alarm history to servo amplifier correctly, "Now reading" disappears and "The completion" appears. The read parameters and alarm history are saved in amplifier file.

| Informa | tion | x |
|---------|---------------------------------|---|
| ٩ | The completion of transmission. | |
| | OK | |

3.10.Transmit Parameter [File->Amplifier]

"Transmit Parameter [File->Amplifier]" directly writes the parameters saved in amplifier file to servo amplifier together.

When select "Parameter" — "Transmit Parameter [File-><u>A</u>mplifier]…" in the menu bar of main screen or select "Amplifier" — "Transmit Parameter [File-><u>A</u>mplifier]…" in the menu bar of General parameter settings / System parameter settings / Motor parameter settings, the following appears.

| ransmit Param | eter [Fil | e->Amplifier |] | 2 |
|------------------|---------------------|------------------|--------------|---------|
| -Transmission d | estination | | | |
| | • #1 | C #6 | C #8 | |
| | O #2 | C #7 | C #C | |
| | C #3 | C #8 | C #D | |
| | C #4 | C #9 | C #E | |
| | C #5 | C #A | C #F | |
| The servo amp | lifier mod | el of a transmis | ssion destin | ation : |
| | | RS1L | .01AA | |
| | | | | Browse |
| The kind of para | ameterto rameter | transmit | | |
| Motor Para | meter | | | |
| | | | | |

Transmit the parameters from servo amplifier to amplifier file as the following procedure.

- 1. Select the axis number of servo amplifier which transmits parameters in "Transmission destination".
- 2. When click [Browse...] in "Transmission source", the following dialog box of saving file appears.

| Open | | | | ? × |
|----------------|------------------------|---|-------|-----|
| Look in: 🔁 | Data 💌 🕈 | • | 💣 🎹 - | |
| 🗋 test | _ | | | |
| AmpFile1.a | ap0 | | | |
| | iho. | | | |
| | | | | |
| | | | | |
| | | | | |
| File name: | AmpFile1.ap0 | | Oper | n |
| Files of type: | Amplifier file (*.ap0) | • | Canc | el |
| | 1 | _ | | /// |

Select the amplifier file which writes to servo amplifier together and click [Open].

- 3. Select the class of parameter which is written to servo amplifier in "The kind of parameter to transmit".
- 4. When click [Execute], the following dialog box appears.

| Confirm | × |
|---------|--|
| ? | The parameters are written to the amplifier. Is it all right? |
| | Cancel |

When click [OK], the parameters are written to servo amplifier together.

| Transmit Parameter [Fil | e->Amplifier |] | × |
|---------------------------|------------------|------------------|---------------|
| Transmission destination | 1 | | |
| • #1 | C #6 | C #8 | |
| C #2 | C #7 | ○ #C | |
| C #3 | C #8 | ○ #D | |
| C #4 | C #9 | C #E | |
| C #5 | C #A | C #F | |
| The servo amplifier more | lel of a transmi | ssion destinatio | n: |
| Now Writing | | | |
| | | | |
| ⊢The kind of parameter to | transmit | | |
| General Parameter | | | |
| System Parameter | | | |
| Motor Parameter | | | |
| | E | xecute | E <u>×</u> it |

In case the software version of servo amplifier is different from that of amplifier file or hardware differs, the following dialog box appears.

| Confirm | × |
|---------|---|
| ? | Because the software version of servo amplifier is different, there are parameters which cannot be transmitted. Does it transmit? |
| | Yes No |

The Servo amplifier software version of the transmission source having saved the amplifier file and that of transmission destination are different, or those hardware types are different. Thus, the part of incompatible parameters may not be transmitted.

Click "Yes", and the transmission will be executed except for the incompatible parameters. After the transmission is completed, check the parameters that have not been transmitted by "Match parameter". Set up those parameters in manual if necessary. (For operation, see "3.6.6 Match parameter".)

Click "No", parameters are not transmitted.

When the kind of servo amplifier is different from that of amplifier file, parameters are not written together as the following dialog box.

| Informa | tion X |
|---------|--|
| ٩ | The kind of servo amplifier is different. It cannot transmit. |
| | OK |

5. When complete writing together correctly, "Now Writing" disappears and "The completion" appears.

| Informa | tion | x |
|---------|---------------------------------|---|
| ٩ | The completion of transmission. | |
| | ОК | |

3.11. Verification of parameter file

Selecting "File Match Parameter" from "Parameter" on the menu bar of main screen displays File Match Parameter window, a parameter verification window.

With this window, you can verify parameter files conformity. (←「ファイル同士が適合するかを照合できる」の意味です)

To display this window, select "File Match Parameter" from "Parameter" on the menu bar of main screen.



Selecting a box "___" of File 1 in File Match Parameter window, the flowing file selecting dialog box is displayed.

| Open | | | | <u>? ×</u> |
|----------------|------------------------|---|-------|------------|
| Look in: 🔂 | Data | • | ÷ 🗈 (| * 🎟 • |
| test | -0 | | | |
| AmpFile1.a | ipu ip0 | | | |
| | | | | |
| | | | | |
| | | | | |
| File name: | AmpFile1.ap0 | | | Open |
| Files of type: | Amplifier file (*.ap0) | | • | Cancel |
| | , | | | / |

Click Open after selecting file you want to verify. Select a box "—" of File 2 in the same way.

If there is a difference between the software versions or hardware you selected to verify their conformity, the following dialog is displayed.

| Confirm | × |
|---------|---|
| ? | The software version of servo amplifier is different. Does it continue a matching? |
| | Cancel |

Clicking "OK" initiates parameter verification. Clinking "Cancel" does not perform verification.

- Note) When this dialog displayed, several incompatible parameters may exist depending on software versions. Any incompatible parameters are displayed in verification result (differences) list, regardless of the setting contents. The incompatible parameters names are also displayed in red.
- Note) When this dialog is displayed due to hardware difference.

Several incompatible parameters may exist due to hardware difference, such as difference of encoder interface circuit. Any incompatible parameters are displayed in a verification result (differences) list, regardless of the setting contents. Please carefully operate servo amplifier with multiple hardware in regard to this point.

The following dialog is displayed and then no parameter verification can be performed if different types of servo amplifiers exist between amplifier files.

| Informa | tion 🔀 | 1 |
|---------|--|---|
| ٩ | The kind of servo amplifier is different. It cannot matching. | |
| | OK | |

When parameter verification process completed, the following parameter verification result list is displayed.

| File Ma | itch Pa | rameter | | | | | × |
|---------|---------|--|------------------|---------|----------|--|---------------|
| File 1: | 0 | :¥file1.ap0 | | | | | |
| File 2 | 0 | :¥file2.ap0 | | | <u> </u> | xecute | |
| | | File 1 | | | | File 2 | |
| Mode | Page | Name | Present Value | Mode | Page | Name | Present Value |
| 1 | 13 | Velocity Loop Proportional Gain 1 | 50 | 1 | 13 | Velocity Loop Proportional Gain 1 | 100 |
| 1 | 14 | Velocity Loop Integral Time Constant 1 | 20.0 | 1 | 14 | Velocity Loop Integral Time Constant 1 | 15.0 |
| 1 | 20 | Torgue (Force) Command Filter 1 | 600 | 1 | 20 | Torgue (Force) Command Filter 1 | 450 |
| A | 10 | Digital Monitor, Output Signal | | L . | | Output Signal Selection | 09: S-ON OFI |
| | | Motor Parameter | ion | | | × r | 000A H |
| | | Motor Parameter | Complete compari | con Dif | forence | a was found ar | 3299 H |
| | | Motor Parameter | complete compan | SOLL DI | rerence | 011F H | |
| | | Motor Parameter | | | | er | 1A40 H |
| | | Motor Parameter | [| | | er | 0BB8 H |
| | | Motor Parameter | <u></u> | <u></u> | 15E0 H | | |
| | | Motor Parameter | | | 1 | 0761 H | |
| | | Motor Parameter | 0A2C H | | | Motor Parameter | 0761 H |
| | | Motor Parameter | 09C5 H | | | Motor Parameter | 0B9C H |
| | | Motor Parameter | 4BE4 H | | | Motor Parameter | 3B0F H |
| | | Motor Parameter | OD7E H | | | Motor Parameter | 1157 H |
| | | Motor Parameter | 1050 H | | | Motor Parameter | 0AA0 H |
| | | Motor Parameter | 0405 H | | | Motor Parameter | 0C91 H |
| | | Motor Parameter | 0027 H | | | Motor Parameter | 001C H |
| | | Motor Parameter | 0136 H 🔍 👻 | | | Motor Parameter | 025F H 🔍 |
| • | | | ▶ | | | | • |
| E | rint |] | | | | | <u>C</u> lose |

If any differences in software version, but verification have been performed, different kind of parameters is displayed all in red.

Clicking "Print" starts printing a list of parameters being displayed.

3.12. Monitor Display

When click "<u>M</u>onitor" — "Monitor <u>D</u>isplay..." in the menu bar of main screen, the following screen appears. Here display a list of the status and operation of servo amplifier which is currently connected by the cable.

| R Monitor I | R Monitor Display | | | | | | | |
|-------------|-------------------|----------|---|------------------|-----------|----|--|--|
| Eile | | | | | | | | |
| #1 | Page | Symbol | Name | Present Value | Unit | | | |
| #2 | 00 | STATUS | Servo Amplifier Status | [04] Servo Ready | | | | |
| #2 | 01 | WARNING1 | Warnig Status 1 | 0000-0000 | | | | |
| #3 | 02 | WARNING2 | Warnig Status 2 | 0000-1001 | | | | |
| #4 | 03 | CONT_8-1 | General Purpose Input CONT8 to CONT1 Monitor | 0000-0000 | | | | |
| | 04 | OUT_8-1 | General Purpose Output OUT8 to OUT1 Monitor | 1111-0101 | | | | |
| #5 | 05 | VMON | Velocity Monitor | 0 | min-1 | | | |
| #6 | 06 | VCMON | Velocity Command Monitor | 0 | min-1 | 1 | | |
| | 07 | TMON | Torque (Force) Monitor | 0 | % | 1 | | |
| #7 | 08 | TCMON | Torque (Force) Command Monitor | 0 | % | 1. | | |
| #8 | 09 | PMON | Position Deviation Monitor | 0 | Pulse | | | |
| #9 | 0A | APMON | Actual Position Monitor (Motor Encoder) | 0 | Pulse | 1 | | |
| | 0B | EX-APMON | External Actual Position Monitor (External Encoder) | 0 | Pulse | 1 | | |
| #A. | 0C | CPMON | Command Position Monitor | 0 | Pulse | 1. | | |
| #8 | 0D | VC/TC-IN | Analog Velocity Command/Analog Torque Command Input Volta | 3 | mV | 1 | | |
| | 0E | FMON | Position Command Pulse Input Frequency Monitor | 0 | k Pulse/s | 1 | | |
| #C | OF | CSU | U-Phase Electric Angle Monitor | 90 | deg | 1 | | |
| #D | 10 | PS-H | Absolute Encoder PS Data (High) | 00000000 H | x2^32 P | 1 | | |
| #15 | 11 | PS-L | Absolute Encoder PS Data (Low) | 00000000 H | Pulse | 1 | | |
| m1_ | 12 | RegP | Regenerative Resistor Operation Percentage | 0.00 | % | 1 | | |
| #F | 13 | OPRT | Motor Operating Rate Monitor | 9 | % | - | | |

When click [#1] to [#F] on the left side of Monitor Display, the status of corresponding servo amplifier which is numbered is displayed in monitor.

Each function of Monitor display can be accessed by selecting it in the menu bar of Monitor Display.

| K tonical pipela | × |
|-------------------------------|--------------|
| File | |
| Exit Page Symbol Name Present | /alue Unit 🔺 |

[<u>F</u>ile]

• E<u>x</u>it : Exit Monitor Display.

3.13. Multi-monitor Display

When click "<u>Monitor</u>" — "<u>Multi-monitor Display...</u>" in the menu bar of main screen, the following screen appears. Here displays 16 cases at maximum in the status and operation of servo amplifier which is currently connected by the cable.

| R M | Multi-monitor Display | | | | | | | | |
|--------------|-----------------------|------|--------|--------------------------------|------------------|-------|--|--|--|
| <u>F</u> ile | e | | | | | | | | |
| | Display Setting | | | | | | | | |
| | | | | | | ., | | | |
| No. | Axis No. | page | Symbol | Name | Present Value | Unit | | | |
| 0 | #1 | 00 | STATUS | Servo Amplifier Status | [04] Servo Ready | | | | |
| 1 | #1 | 05 | VMON | Velocity Monitor | 0 | min-1 | | | |
| 2 | #1 | OF | CSU | U-Phase Electric Angle Monitor | 90 | deg | | | |
| 3 | | | | | | | | | |
| 4 | | | | | | | | | |
| 5 | | | | | | | | | |
| 6 | | | | | | | | | |
| 7 | | | | | | | | | |
| 8 | | | | | | | | | |
| 9 | | | | | | | | | |
| 10 | | | | | | | | | |
| 11 | | | | | | | | | |
| 12 | | | | | | | | | |
| 13 | | | | | | | | | |
| 14 | | | | | | | | | |
| 15 | | | | | | | | | |
| | | | | | | | | | |

Each function of Multi-monitor display can be accessed by selecting it in the menu bar of Multi-monitor Display.

| R Multi-m | onitor Display | × |
|-----------|----------------|-----------------|
| File | | |
| Exit | | Display Setting |
| | | |

[<u>F</u>ile]

• Exit : Exit Multi-monitor Display.

3.13.1. Multi-monitor Display Setting

When click "Display <u>S</u>etting" in multi-monitor display screen, the following screen appears. The parameters performing monitor display in multi-monitor display are selected in the servo amplifier which is currently connected.

| Multi-monitor Display Setting | | | | | | | |
|-------------------------------|--------|----------|----------|---------------|--------------------------------|----------|--|
| | Axis N | lo.: | Displ | lay Parameter | : | | |
| No.0: 🔽 | #1 | • | 00 | STATUS | Servo Amplifier Status | - | |
| No.1: 🔽 | #1 | • | 05 | VMON | Velocity Monitor | • | |
| No. 2 : 🔽 | #1 | • | OF | CSU | U-Phase Electric Angle Monitor | • | |
| No.3: 🗖 | í – | - | | | | - | |
| No. 4 : 🗖 | í – | v | | | | - | |
| No.5: 🗖 | í – | _ | | | | - | |
| No.6: 🗖 | í – | - | | | | ~ | |
| No. 7 : 🕅 | í – | - | | | | ~ | |
| No. 8 : 🗖 | í – | - | | | | ~ | |
| No.9: 🥅 | í | - | F | | | _ | |
| No.10 : 🗖 | í – | | í – | | | | |
| No.11 : 🗖 | í – | | í – | | | | |
| No.12 : 厂 | í – | F | í – | | | | |
| No.13 : 🦵 | í – | F | í – | | | | |
| No.14 : 🕅 | i – | F | í – | | | | |
| No.15 : 🗖 | í – | - | | | | - | |
| | , | | , | | С ОК Х | Cancel | |

Give check mark(s) on either one(s) from No. 0 to No. 15 in which multi-monitor display is desired to select axis number and display parameter.

3.14. Alarm History

When click "<u>M</u>onitor" — "<u>A</u>larm History Display..." in the menu bar of main screen, the following screen appears. Here displays an alarm history generated in servo amplifier which is currently connected by a cable.

| RA | Marm H | istory Display | | | × |
|------|-------------|----------------|---------------------------|---|-----------|
| File | Amplifi | ier Print | | | |
| | 6 | ð. | | | |
| | #1 | Current Statu | 18 | | |
| | #2 | | Alarm Content (Symbol) | Alarm Content (Name) | The state |
| 3 | #3 | Now | None | No Alarm (Normal Condition) | 04: S-RDY |
| | #4 | | | | |
| | #5 | Passe | ed time from gene | rating | |
| ; | #6 | | | | |
| 1 | #7 | Alarm Gener | ating History | | |
| | #8 | | Alarm Content | Alarm Content | The state |
| | #9 | Last1 | None | No Alarm (Normal Condition) | |
| | #A | Last2 | None | No Alarm (Normal Condition) | 0F: |
| _ | #17 | Last3 | None | No Alarm (Normal Condition) | 0F: |
| | #8 | Last4 | None | No Alarm (Normal Condition) | 0F: |
| 9 | #C | Last5 | None | No Alarm (Normal Condition) | 0F: |
| ą | #D | Last6 | None | No Alarm (Normal Condition) | 0F: |
| | #= | Last7 | None | No Alarm (Normal Condition) | 0F: |
| | ~~ <u>_</u> | I | | | |
| | #F | | | | |
| F | ile | Software | Version of Servo | Amplifier P0.00.1 - B001 - B001 - B001 - B001 | |

When click [#1] to [#F] in the left of Alarm History Display, the alarm of the corresponding numbered servo amplifier is displayed. When click [File], switch to Alarm History saved in amplifier file.

In order to save the information of servo amplifier alarm history in a file, execute "Transmit Parameter [Amplifier->File]". Refer to "3.9 Transmit Parameter [Amplifier->File]" for the procedure.

Current State

Display the alarm which is currently generated, the state of servo amplifier (current state in case of "No alarm"), and the passed time from generating.

- Alarm Generating History
 Display last seven alarms. This history is updated at any time.
- Software Version of Servo Amplifier
 Display the software version of servo amplifier.

Each function of alarm history display can be accessed by selecting it in the menu bar of Alarm History Display.

| R Alarm History Disp | Alarm History Display - [C:\Data\AmpFile1.ap0] | | | | | | |
|----------------------|--|---------------|---------------|-----------|--|--|--|
| File Amplifier Print | | | | | | | |
| 🗳 Open Ctrl+O | | | | | | | |
| Close | βtatu | IS | | | | | |
| Exit | | Alarm Content | Alarm Content | The state | | | |

[<u>F</u>ile]

• <u>Open...</u> : Open an amplifier file displaying alarm history.

%Possible to select it only at displaying an alarm history of amplifier file.

• Exit : Exit Alarm History Display.

| R Alarm History Display | | | |
|-------------------------|--|--|--|
| Eile Amplifier Print | | | |
| 💕 😽 Alarm Reset | | | |
| Alarm Trace Clear | | | |

[Amplifier]

• Alarm <u>Reset</u> : Reset the current alarm of servo amplifier.

%Possible to select it only at displaying an alarm history of servo amplifier.

 Alarm Trace <u>C</u>lear : Clear the servo amplifier's data of alarm which was generated in the past.

%Possible to select it only at displaying an alarm history of servo amplifier.

| R Alarm History Display | | | |
|-----------------------------|--|--|--|
| <u>File Amplifier</u> Print | | | |
| 学 🎒 🛕 🎒 Print Ctrl+P | | | |
| Q Preview | | | |

[Print]

- <u>Print...</u> : Print a list of alarm history.
- Print Preview ... : Display the print image of parameter list.

3.14.1. Alarm Reset

For "Alarm Reset", reset the current alarm of servo amplifier.

For how to operate, see "3.22. Alarm Reset".

3.14.2. Alarm Trace Clear

For "Alarm Trace Clear", clear the servo amplifier's data of alarm which was generated in the past. Refer to "3.24. Alarm Trace Clear" for the procedure.

3.15. Jogging Operation

Jogging operation can test the servo amplifier and servomotor easily. This function runs the servomotor. Secure the safety of the surroundings. When the alarm generates during jogging operation, motor excitation becomes OFF. Prepare the control equipments which can be readily used.

When select "<u>T</u>est Run and Adjustment" - "<u>J</u>ogging operation" in the menu bar of main screen, the following appears. Here runs the motor in positive/negative directions with the velocity command set by jogging operation.

| | • #1 | C #6 | C #8 | |
|---------|-----------------|------------|-------------|--|
| | C #2 | C #7 | C #C | |
| | C #3 | C #8 | C #D | |
| | C #4 | C #9 | C #E | |
| | C #5 | C #A | C #F | |
| Servo A | Amplifier Model | Name: RS1L | .01AA | |

Jogging operation is performed as follows.

- 1. Select the axis number of servo amplifier performing jogging operation in "Select Servo Amplifier".
- 2. When click "Execute", the following appears.



For the servo amplifier which jogging operation is not functioned, the following dialog box appears when click "OK".



This servo amplifier can not use jogging operation.

When servo amplifier is not ready, the following dialog box appears.



Jogging operation is not ready.

In caser servo amplifier is in alarm state, main power is not supplied, or "Test Run and Adjustment" is executed with digital operator, jogging operation is not ready.

When confirming that jogging operation can be used, click "Execute" again.

In case servo amplifier is ready, the following appears.

| Jogging Operation [#1 : QS1A01A] | X |
|---|----|
| Select the operation at completing | |
| O At completing, "Alarm of Test Run complete" is not selected. | |
| At completing, "Alarm of Test Run complete" is selected. | |
| Parameter Setting | |
| Jogging velocity command : 50 🖨 min-1 Edit | |
| (0-32767) | |
| | |
| Motor Excitation | |
| Servo ON Servo OFF | |
| | |
| Execute Jogging Operation | |
| Positive Move Negative Move | |
| | |
| Note : When use this function, the motor functions. | |
| Likecute uns operation alter securing the safety of surroundings. | |
| <u><u>C</u>lo</u> | se |
| | |

3. Select the operation at completing and set the jogging velocity command.

When generate "Alarm of Test Run complete" at completing jogging operation, click 'At completing, "Alarm of Test Run complete" is selected'. In case of the opposite, click 'At completing, "Alarm of Test Run complete" is not selected'.

When changing jogging velocity command, click "Edit" and switch to editing mode. Enter the value in keyboards and click "Write".

4. In case of generating alarm, the following dialog box appears when click "Servo ON".



In case servo amplifier can not function Servo ON, the following dialog box appears.

| Jogging C | peration [#1 : QS1 A03A 🛛 👘 🚦 | × |
|-----------|--|---|
| 1 | Servo ON cannot be functioned. Check the status of Servo Amplifier. | |
| | C OK | |

When confirming that Servo ON can be used, click "Servo ON" again.

In case of Servo ON, "Positive move" and "Negative move" buttons can be used. While editing velocity command, "Positive move" and "Negative move" buttons can not be used. After click "Write", complete the editing.

| Jogging Operation [#1 : QS1A01A] |
|--|
| Select the operation at completing C At completing, "Alarm of Test Run complete" is not selected. C At completing, "Alarm of Test Run complete" is selected. |
| Parameter Setting Jogging velocity command : 50 imin-1 Edit (0 - 32767) |
| Motor Excitation Servo ON Servo OFF |
| Execute Jogging Operation |
| Positive Move Negative Move |
| Note : When use this function, the motor functions. Execute this operation after securing the safety of surroundings. |

5. While continue to click "Positive move" or "Negative move", jogging operation is being executed.

While Over-travel is confirmed, the following dialog box appears.

| Jogging (| Operation [#1 : QS1 A01 A 📑 💌 |
|-----------|-------------------------------|
| 1 | Over-travel is now going on. |
| | (OK) |

While editing velocity command, the following appears. When click "Write", complete the editing by updating the set value. When click "Edit Cancel", complete the editing without updating the set value.

| ogging Operation [#1 : QS1A01A] | × |
|---|------|
| Select the operation at completing | |
| O At completing, "Alarm of Test Run complete" is not selected. | |
| • At completing, "Alarm of Test Run complete" is selected. | |
| Parameter Setting | |
| Logging velocity command : 50 min_1 Edit Ca | ncel |
| (0. 32767) | |
| (0-32/0/) Writ | e |
| Servo ON Servo OFF | |
| Positive Move Nevertive Move | |
| Розшие моче | |
| | |
| Note : When use this function, the motor functions. | |
| Execute this operation after securing the safety of suffoundings. | |
| C | ose |
| - | |

3.16. Operation for Pulse Feed Jogging

Operation for Pulse Feed Jogging can test the servo amplifier and servomotor easily. This function runs the servomotor. Secure the safety of the surroundings. When the alarm generates during operation for feed Jogging operation, motor excitation becomes OFF. Prepare the control equipments which can be readily used.

When select "<u>T</u>est Run and Adjustment" - "Operation for <u>P</u>ulse Feed Jogging" in the menu bar of main screen, the following appears. Here runs the motor in positive/negative directions with the number of feed pulses and movement speed set by jogging operation.

| | € #1 | C #6 | C #8 | |
|---------|-----------------|-------------|-------|--|
| | C #2 | C #7 | C #C | |
| | C #3 | C #8 | C #D | |
| | C #4 | C #9 | C #E | |
| | C #5 | C #A | C #F | |
| Servo A | Amplifier Model | Name : RS1L | .01AA | |

Operation for pulse feed jogging is performed as follows.

- 1. Select the axis number of servo amplifier performing jogging operation in "Select Servo Amplifier".
- 2. When click "Execute", the following appears.

| Operation | for Pulse Feed Jogging [#1 : QS1A01A] |
|-----------|---|
| 2 | Do you execute for Pulse Feed Jogging? (Executing pulse feed JOG operation clears a position deviation.) |
| | Cancel |

For the servo amplifier which pulse feed jogging operation is not functioned, the following dialog box appears when click "OK".

| Operation | for Pulse Feed Jogging [#1 : QS1 A 🗙 |
|-----------|--------------------------------------|
| 1 | Pulse Feed Jogging cannot be used. |
| _ | (OK) |

This servo amplifier can not use jogging operation.

When servo amplifier is not ready, the following dialog box appears.



Jogging operation is not ready.

In case servo amplifier is in alarm state, main power is not supplied, or "Test Run and Adjustment" is executed with digital operator, jogging operation is not ready. When confirming that jogging operation can be used, click "Execute" again.

In case servo amplifier is ready, the following appears.

| Operation for Pulse Feed Jogging [#1 : QS1A01A] |
|--|
| Select the operation at completing |
| C At completing, "Alarm of Test Run complete" is not selected. |
| C At completing, "Alarm of Test Run complete" is selected. |
| Parameter Setting |
| Number of Feed Pulses : 0 🗲 [Pulse] Edit |
| (0-2147483647) Movement Speed : 50 min-1 |
| (0 - 32/67) During operation of Pulse Feed Jogging, it becomes EGR1 and EGR2 (Electric Gear Ratio) = 1/1, PMUL (Position Command, Pulse Multiplier) = 1. |
| Monitor Display |
| Actual Position Monitor APMON : 0 [Pulse] |
| Position Deviation Monitor PMON : 0 [Pulse] |
| |
| Motor Excitation |
| (During Serve OFF it clears a position deviation) |
| |
| Execute Jogging Operation |
| Positive feed Stop & Deviation Clear Negative feed |
| Note : When use this function, the motor functions. Execute this operation after securing the safety of surroundings. At completing of Pulse Feed Jogging, it clears a position deviation. |

3. Select the operation at completing and set the number of feed pulses and movement speed.

When generate "Alarm of Test Run complete" at completing pulse feed jogging operation, click 'At completing, "Alarm of Test Run complete" is selected'. In case of the opposite, click 'At completing, "Alarm of Test Run complete" is not selected'.

When changing the number of feed pulses and movement speed, click "Edit" and switch to editing mode. Enter the value in keyboards and click "Write".

4. In case of generating alarm, the following dialog box appears when click "Servo ON".



In case servo amplifier can not function Servo ON, the following dialog box appears.

| Operation | for Pulse Feed Jogging [#1 : QS1A 💌 |
|-----------|--|
| ♪ | Servo ON cannot be functioned. Check the status of Servo Amplifier. |
| | <u> </u> |

In case of Servo ON, "Positive move" and "Negative move" buttons can be used.

In case of Servo ON, "Positive Feed", "Negative Feed", and "Stop & Deviation Clear" buttons are enabled. While editing the number of feed pulses and movement speed, "Positive Feed", "Negative Feed", and "Stop & Deviation Clear" buttons can not be used. After click "Write", complete the editing.

| eration for Pulse Feed Joggir | ng [#1 : QS1A01A] |
|--------------------------------|---|
| Select the operation at comple | ting |
| C At completing, "Alarm of Te | est Run complete" is not selected. |
| At completing, "Alarm of Te | est Run complete" is selected. |
| Parameter Setting | |
| Number of Feed Pulses : | 0 [Pulse] Edit |
| Movement Speed : | (0-214/483647) 50 min-1 |
| During operation of Dulog Fee | (0 - 32767) |
| PMUL (Position Command, Pul | Ise Multiplier) = 1. |
| Actual Position Monitor APMO | DN : 0 [Pulse] |
| Position Deviation Monitor PM | ON : 0 [Pulse] |
| Motor Excitation | Servo OFF |
| | (During Servo OFF, it clears a position deviation) |
| Execute Jogging Operation | |
| Positive feed | Stop & Deviation Clear Negative feed |
| Note : When use this fu | inction, the motor functions. after securing the safety of surroundings. |

 When click "Positive feed" or "Negative feed", move the number of feed pulses to be set. In case of stopping before moving the number of feed pulses to be set, click "Stop & Deviation Clear". While Over-travel is confirmed, the following dialog box appears.



When the setting of number of feed pulses or movement speed is inadequate, the following appears. Change the setting.



While editing the number of feed pulses or movement speed, the following appears. When click "Write", complete the editing by updating the set value. When click "Edit Cancel", complete the editing without updating the set value.

| Operation for Pulse Feed Jogging [| #1 : QS1A01A] | × | | | | | |
|--|---|-------------------|--|--|--|--|--|
| -Select the operation at completing | | | | | | | |
| C At completing, "Alarm of Test Run complete" is not selected. | | | | | | | |
| • At completing, "Alarm of Test Run complete" is selected. | | | | | | | |
| Parameter Setting | | | | | | | |
| Number of Feed Pulses : | 0 (Pulse) | Edit Cancel | | | | | |
| | (0-2147483647) | Write | | | | | |
| Movement Speed : | 50 💼 min-1 | | | | | | |
| | (0-32767) | | | | | | |
| During operation of Pulse Feed Jo PMUL (Position Command, Pulse I | ogging, it becomes EGR1 and EGR2 (Electric G Aultiplier) = 1 | ear Ratio) = 1/1, | | | | | |
| | | | | | | | |
| Monitor Display | | | | | | | |
| Actual Position Monitor APMON : | 0 [Pulse] | | | | | | |
| Position Deviation Monitor PMON : | 0 [Pulse] | | | | | | |
| | | | | | | | |
| Motor Excitation | | | | | | | |
| Se | rvo ON Servo OFF | | | | | | |
| | (During Servo OFF, it clears a position | n deviation) | | | | | |
| Europeter Janeiro Occartico | | | | | | | |
| Execute Jogging Operation | Olers & Deviation Olers | | | | | | |
| Positive feed | Stop & Deviation Clear Negative | e teed | | | | | |
| | | | | | | | |
| Note : When use this functi | on, the motor functions. | | | | | | |
| At completing of Pulse Feed Jogging, it clears a position deviation. | | | | | | | |
| | | Close | | | | | |
| | | 1.500 | | | | | |

3.17. Automatic Notch Filter Tuning

Automatic notch filter tuning can readily find the resonance frequency by running servo amplifier and servomotor for a short period. In case resonance frequency exists, set the frequency at command notch filter A (TCNFILA) automatically. This function runs the servomotor. Secure the safety of surroundings. During execution, the holding torque becomes small. At the weight axis and so on, do not use this function.

When select "Test Run and Adjustment" - "Automatic Notch Filter Tuning" in the menu bar of main screen, the following appears. Here executes automatic notch filter tuning.

| <mark>R</mark> Automatic Notch Filte | r Tuning | | : | | | |
|---------------------------------------|----------|-------------|---------------|--|--|--|
| Select Servo Amplifier | | | | | | |
| € #1 | C #6 | C #8 | | | | |
| C #2 | C #7 | ○ #C | | | | |
| C #3 | C #8 | ○ #D | | | | |
| C #4 | C #9 | ○ #E | | | | |
| C #5 | C#A | C #F | | | | |
| Servo Amplifier Model Name : RS1L01AA | | | | | | |
| | E | kecute f | ≣ <u>×</u> it | | | |

Automatic notch filter tuning is performed as follows.

- 1. Select the axis number of servo amplifier performing automatic notch filter tuning in "Select Servo Amplifier".
- 2. When click "Execute", the following appears.



For the servo amplifier which automatic notch filter tuning is not functioned, the following dialog box appears when click "OK".



This servo amplifier can not perform automatic notch filter tuning.

When servo amplifier is not ready, the following dialog box appears.



Automatic notch filter tuning is not ready.

In case servo amplifier is in alarm state, main power is not supplied, or "Test Run and Adjustment" is executed with digital operator, tuning operation is not ready.

When confirming that automatic notch filter tuning can be used, click "Execute" again.

In case servo amplifier is ready, the following appears.

| Automatic Notch Filter Tuning [#1 : QS1 A01 A] | × | | | | |
|--|-----|--|--|--|--|
| Select the operation at completing | | | | | |
| At completing, "Alarm of Test Run complete" is not selected. At completing, "Alarm of Test Run complete" is selected. | | | | | |
| | | | | | |
| Torque command value of tuning : 50 🗲 [%] Edit | | | | | |
| (10-300) | - I | | | | |
| | | | | | |
| Motor Excitation | | | | | |
| Servo ON Servo OFF | | | | | |
| | | | | | |
| Execute Tuning | | | | | |
| Execute | | | | | |
| | | | | | |
| Note : When use this function, the motor functions. | | | | | |
| Execute this operation after securing the safety of surroundings. During execution, the holding torque becomes small. | | | | | |
| At the weight axis and so on, don't use the function | | | | | |
| | | | | | |

Select the operation at completing and set the torque command value of tuning.
 When generate "Alarm of Test Run complete" at completing automatic notch filter tuning, click 'At completing, "Alarm of Test Run complete" is selected'. In case of the opposite, click 'At completing, "Alarm of Test Run complete" is not selected'.
 When changing the torque command value of tuning, click "Edit" and switch to editing mode. Enter the value in keyboards and click "Write".
4. In case of generating alarm, the following dialog box appears when click "Servo ON".



In case servo amplifier can not function Servo ON, the following dialog box appears.



In case of Servo ON, "Execute", button is enabled. While editing torque command value, "Execute" button can not be used. After click "Write", complete the editing.

| Automatic Notch Filter Tuning [#1 : QS1A01A] | ĸ |
|---|---|
| Select the operation at completing C At completing, "Alarm of Test Run complete" is not selected. C At completing, "Alarm of Test Run complete" is selected. | |
| Parameter Setting Torque command value of tuning : 50 (%) (10 - 300) | |
| Motor Excitation Servo ON Servo OFF | |
| Execute Tuning Execute | |
| Note : When use this function, the motor functions. Execute this operation after securing the safety of surroundings. During execution, the holding torque becomes small. At the weight axis and so on, don't use the function | |

5. When click "Execute", the following appears and execute automatic notch filter tuning.



6. When automatic notch filter tuning completes normally, "Execute" disappears and the following dialog box of tuning result appears.

| Automatic Notch Filter Tuning [#1 : QS1 A01 A] | × |
|---|---|
| Automatic Notch Filter Tuning completed normally When click "OK", Servo OFF functions. | |
| Result of Tuning | |
| Torque Command, Notch Filte 1890 Hz | |
| | |
| ОК | |

This tuning result is saved in "Torque (Force) Command, Notch Filter A (TCNFILA)".

When automatic notch filter tuning can not complete normally, the following dialog box appears.



During editing torque command, the following appears. When click "Write", complete the editing by updating the setting value. When click "Edit Cancel", complete the editing without updating the setting value.

| utomatic Notch Filter Tuning [#1 : QS1A01A] | |
|--|-------|
| Select the operation at completing C At completing, "Alarm of Test Run complete" is not selected. | |
| At completing, "Alarm of Test Run complete" is selected. | |
| Parameter Setting | |
| Torque command value of tuning : 50 🔶 [%] Edit Ca | ancel |
| (10 - 300) Wri | ite |
| Servo ON Servo OFF | |
| Execute Tuning Execute | |
| Note : When use this function, the motor functions. Execute this operation after securing the safety of surroundings. During execution, the holding torque becomes small. At the weight axis and so on, don't use the function | |
| 2 | lose |

3.18. Automatic Vibration Suppressor Frequency Tuning

Automatic Vibration Suppressor Frequency Tuning can easily set the vibration suppressor control parameter "Vibration Suppressor Frequency 1 (SUPFRQ1)" by running servo amplifier and servomotor for a short period. After the tuning is executed, the result is automatically set to Vibration Suppressor Frequency 1 (SUPFRQ1). This function runs the servomotor. Secure the safety of surroundings. During execution, the holding torque becomes small. At the weight axis and so on, do not use this function.

When select "<u>T</u>est Run and Adjustment" - "A<u>u</u>tomatic Vibration Suppressor Frequency Tuning" in the menu bar of main screen, the following appears. Here executes Automatic Vibration Suppressor Frequency Tuning.

| R P | utomatic Vibration S | uppressor F | requency Tuning | × |
|-----|-----------------------|-------------|----------------------|---|
| _s | elect Servo Amplifier | | | |
| | #1 | C #6 | C #8 | |
| | C #2 | C #7 | C #C | |
| | C #3 | C #8 | C #D | |
| | C #4 | C #9 | C #E | |
| | C #5 | C#A | C #F | |
| | Servo Amplifier Model | Name : RS1L | _01AA | |
| | | E | kecute E <u>x</u> it | |

Automatic Vibration Suppressor Frequency Tuning is performed as follows.

- 1. Select the axis number of servo amplifier performing automatic vibration suppressor frequency tuning in "Select Servo Amplifier".
- 2. When click "Execute", the following appears.



For the servo amplifier which automatic vibration suppressor frequency tuning is not functioned, the following dialog box appears when click "OK".

| Autom | atic Vibration Suppressor Frequency Tuning [#1 : Q51E03 🗙 |
|-------|---|
| | Automatic Vibration Suppressor Frequency Tuning cannot be used. |
| | OK |

This servo amplifier can not perform automatic vibration suppressor frequency tuning.

When servo amplifier is not ready, the following dialog box appears.



Automatic Vibration Suppressor Frequency Tuning is not ready.

In case servo amplifier is in alarm state, main power is not supplied, or "Test Run and Adjustment" is executed with digital operator, tuning operation is not ready.

When confirming that automatic vibration suppressor frequency tuning can be used, click "Execute" again.

In case servo amplifier is ready, the following appears.

| utomatic Vibration Suppressor Frequency Tuning [#1 : R51L01AA] | × |
|---|-------|
| Select the operation at completing C At completing, "Alarm of Test Run complete" is not selected. | |
| At completing, "Alarm of Test Run complete" is selected. | |
| Parameter Setting | |
| Torque (Force) Command Value of Tuning : 25 🗲 [%] Edit | |
| (10-100) Friction Torque (Force) Compensation Value of Tuning : 5 € [%] (0-50) | |
| Motor Excitation Servo ON Servo OFF | |
| Execute Tuning Execute | |
| Note : When using this function, the motor moves for a maximum of 30 seconds. Execute this operation after securing the safety of surroundings. (The time which is needed to tuning becomes short on the condition.) During execution, the holding torque (force) becomes small. At the weight axixs and so on, don't use the function. | |
| | ise) |

3. Select the operation at completing and set the torque (force) command and friction torque (force) compensation value of tuning.

When generate "Alarm of Test Run complete" at completing automatic vibration suppressor frequency tuning, click 'At completing, "Alarm of Test Run complete" is selected'. In case of the opposite, click 'At completing, "Alarm of Test Run complete" is not selected'.

When changing the torque (force) command and friction torque (force) value of tuning, click "Edit" and switch to editing mode. Enter the value in keyboards and click "Write".

4. In case of generating alarm and servo amplifier can not function Servo ON, the following appears.

| Autom | atic Vibration Suppressor Frequency Tuning [#1 : R51L01AA] | x |
|-------|---|---|
| | Automatic Vibration Suppressor Frequency Tuning cannot be executed. (not ready) | |
| | | |

In case of Servo ON, "Execute", button is enabled. While editing torque (force) command and friction torque (force) compensation value, "Execute" button can not be used. After click "Write", complete the editing.

| utomatic Vibration Suppressor Frequency Tuning [# | 1:R51L01AA] | × |
|---|---|------|
| Select the operation at completing | | |
| C At completing, "Alarm of Test Run complete" is not selected. | cted. | |
| At completing, "Alarm of Test Run complete" is selected | i. | |
| Parameter Setting | | |
| Torque (Force) Command Value of Tuning : | 25 🚖 [%] | Edit |
| | (10-100) | |
| Friction Torque (Force) Compensation Value of Tuning : | 5 🔹 [%] | |
| | (0.50) | |
| Servo ON Se | rvo OFF | |
| Execute | | |
| Note : When using this function, the motor moves for Execute this operation after securing the safety of su (The time which is needed to tunina becomes short o During execution, the holding torque (force) become At the weight axixs and so on, don't use the function | a maximum of 30 secon rroundings. n the condition.) s small. ı. | ds. |

5. When click "Execute", the following appears and execute automatic vibration suppressor frequency tuning.



In auto vibration suppression frequency tuning, the motor operates for maximum of 30 seconds.

If [Cancel] is click, tuning can be interrupted with servo-on.

6. When automatic vibration suppressor frequency tuning completes normally, "Execute" disappears and the following dialog box of tuning result appears.

| Automatic Vibration Suppressor Fr | equency Tuning [#1 : RS1L01AA] 🗙 |
|--|--|
| Automatic Vibration Suppress | sor Frequency Tuning completed normally. |
| Result of Tuning Vibration Suppressor Frequency : | 500 Hz |
| ОК | When click "OK", Servo OFF functions. |

This tuning result is saved in "Vibration Suppressor Frequency 1 (SUPFRQ1)".

When automatic vibration suppressor frequency tuning can not complete normally, the following dialog box appears.

| Automa | tic Vibration Suppressor Frequency Tuning [#1 : R51L01AA] | × |
|--------|---|---|
| ⚠ | Automatic Vibration Suppressor Frequency Tuning ha not been executed. (Completing abnormally) | |
| | CK | |

During editing torque (force) command and friction torque (force) compensation, the following appears. When click "Write", complete the editing by updating the setting value. When click "Edit Cancel", complete the editing without updating the setting value.

| Automatic Vibration Suppressor Frequency Tuning [#1 : R51L01AA] | × |
|--|------|
| Select the operation at completing C At completing, "Alarm of Test Run complete" is not selected. | |
| At completing, "Alarm of Test Run complete" is selected. | |
| Parameter Setting | |
| Torque (Force) Command Value of Tuning : 😰 🛫 [%] Edit Ca | ncel |
| (10 · 100) Writ | e |
| Friction Torque (Force) Compensation Value of Tuning : 5 🚖 [%] | |
| (0.50) | |
| Motor Excitation | |
| Servo ON Servo OFF | |
| | |
| Execute Tuning | |
| Execute | |
| A Note : When using this function, the motor moves for a maximum of 30 seconds | |
| Known and the second of the safety of surroundings. (The time which is second to twing the safety of surroundings. | |
| During execution, the holding torque (force) becomes small. | |
| At the weight axiss and so on, don't use the function. | |
| | ose |

3.19. Fixation Excitation Operation

This functions fixation excitation operation for linear motor. This function runs servomotor. Secure the safety of surroundings.

When select "<u>T</u>est Run and Adjustment" - "Fixation <u>E</u>xcitation Operation" in the menu bar of main screen, the following appears. Here executes fixation excitation operation for linear motor.

| • #1 | C #6 | C #8 | |
|------|------|-------------|--|
| C #2 | C #7 | C #C | |
| C #3 | C #8 | C #D | |
| C #4 | C #9 | C #E | |
| C #5 | C#A | C #F | |

Fixation Excitation Operation is performed as follows.

- 1. Select the axis number of servo amplifier performing fixation excitation operation in "Select Servo Amplifier".
- 2. When click "Execute", the following appears.



For the servo amplifier which fixation excitation operation is not functioned, the following dialog box appears when click "OK".

| Fixation B | Excitation Operation [#1 : QS1 A01 A] | × |
|------------|---|---|
| <u>.</u> | Fixation Excitation Operation cannot be used. | |
| | () | |

This servo amplifier can not execute fixation excitation operation.

When servo amplifier is not ready, the following dialog box appears.



Fixation Excitation Operation is not ready.

In case servo amplifier is in alarm state, main power is not supplied, or "Test Run and Adjustment" is executed with digital operator, jogging operation is not ready.

When confirming that fixation excitation operation can be used, click "Execute" again.

When servo amplifier is ready, the following dialog box appears and execute fixation excitation operation.

| Fixation I | Excitation Operation [#1 : QS1A01A] |
|------------|--|
| 1 | Fixation Excitation Operation is now being executed. |
| | Cancel |

When click "Cancel", fixation excitation operation is cancelled.

3. When fixation excitation operation completes normally, "Now executing" disappears and the following dialog box appears.



When fixation excitation operation can not complete normally, the following dialog box appears.



3.20. Automatic Offset Adjustment of V-REF Terminal

This is the function for offset adjustment of analog velocity command input terminal (V-REF).

When select "<u>T</u>est Run and Adjustment" - "Automatic Offset Adjustment (<u>V</u>-REF)" in the menu bar of main screen, the following appears. Here performs automatic offset adjustment of analog velocity command/torque command.

| Select Serv | o Amplitter | C #6 | C #8 | |
|-------------|----------------|-------------|-------------|---|
| | C #2 | O #7 | C #C | |
| | C #3 | C #8 | C #D | |
| | C #4 | C #9 | C #E | |
| | C #5 | C#A | C #F | |
| Servo A | mplifier Model | Name: RS1L | .01AA | _ |

Automatic offset adjustment of analog velocity command/torque command is performed as follows.

- 1. Select the axis number of servo amplifier performing automatic offset adjustment of analog velocity command/torque command in "Select Servo Amplifier".
- 2. When click "Execute", the following appears.



For the servo amplifier which automatic offset adjustment of analog velocity command/torque command is not functioned, the following dialog box appears when click "OK".



This servo amplifier can not execute automatic offset adjustment of analog velocity command/torque command.

When servo amplifier is not ready, the following dialog box appears.



Automatic offset adjustment of analog velocity command/torque command is not ready. In case "Test Run and Adjustment" is executed with digital operator, automatic offset adjustment of analog velocity command/torque command is not ready.

When confirming that automatic offset adjustment of analog velocity command/torque command is enabled, click "Execute" again.

When servo amplifier is ready, the following dialog box appears and executes automatic offset adjustment of analog velocity command/torque command.



3. When automatic offset adjustment of analog velocity command/torque command completes normally, "Now executing" disappears and the following dialog box appears.



When automatic offset adjustment of analog velocity command/torque command can not complete normally, the following dialog box appears.



3.21.Automatic Offset Adjustment of T-COMP Terminal

This is the function for offset adjustment of analog torque addition command input terminal (T-COMP).

When select "<u>T</u>est Run and Adjustment" - "Automatic Offset Adjustment (<u>T</u>-COMP)" in the menu bar of main screen, the following appears. Here performs automatic offset adjustment of analog torque addition command.

| | | C #6 | C #8 |
|---------|-----------------|-------------|-------|
| | C #2 | C #7 | C #C |
| | C #3 | C #8 | C #D |
| | C #4 | C #9 | C #E |
| | C #5 | C#A | C #F |
| Servo / | Amplifier Model | Name: RS1L | .01AA |

Automatic offset adjustment of analog torque addition command is performed as follows.

- 1. Select the axis number of servo amplifier performing automatic offset adjustment of analog torque addition command in "Select Servo Amplifier".
- 2. When click "Execute", the following appears.



For the servo amplifier which automatic offset adjustment of analog torque addition command is not functioned, the following dialog box appears when click "OK".

| Autom | atic Offset Adjustment of T-COMP Terminal [#1 : QS1 A01 A] | × |
|-------|--|---|
| 1 | Automatic Offset Adjustment of T-COMP Terminal cannot be used. | |
| | ΟΚ | |

This servo amplifier can not execute automatic offset adjustment of analog torque addition command.

When servo amplifier is not ready, the following dialog box appears.



Automatic offset adjustment of analog torque addition command is not ready.

In case "Test Run and Adjustment" is executed with digital operator, automatic offset adjustment of analog velocity command/torque command is not ready.

When confirming that automatic offset adjustment of analog torque addition command is enabled, click "Execute" again.

When servo amplifier is ready, the following dialog box appears and execute automatic offset adjustment of analog torque addition command.



3. When automatic offset adjustment of analog torque addition command completes normally, "Now executing" disappears and the following dialog box appears.

| Automatic | Offset Adjustment of T-COMP Terminal [#1 : QS1 A01 A |] 🗙 |
|-----------|--|------------------|
| į) | Automatic Offset Adjustment of T-COMP Terminal comp | pleted normally. |
| | () | |

When automatic offset adjustment of analog torque addition command can not complete normally, the following dialog box appears.

| Automatic | Offset Adjustment of T-COMP Terminal [#1 : QS1 A01 A] | × |
|-----------|---|---|
| ⚠ | Automatic Offset Adjustment of T-COMP Terminal has not been executed. | |
| | ΟΚ | |

3.22. Save Result of Automatic Tuning

This is the function for saving control gain that automatic tuning function outputs. The control gain are saved as the parameter. Five kinds of parameters are saved.

Position Loop Proportional Gain 1 (KP1)

Velocity Loop Proportional Gain 1 (KVP1)

Velocity Loop Integral Time Constant 1 (TVI1)

Torque (Force) Command Filter 1 (TCFIL1)

Load Inertia Ratio (Load Mass Ratio) 1 (JRAT1)

The saved contents are different according to the setting of "Tuning Mode (TUNMODE)" and "Automatic Tuning Characteristic (ATCHA)".

| | Parameter Name | Setting v | alue / "Paramete | r Monitor Value of Au | itomatic Tuning" (Sav | ving Contents) |
|-------------------------------|--|--|---|---|-------------------------------------|--|
| le of ion | Group0-Page00 TUNMODE Tuning Mode | 00:_A | utoTun | 01:_AutoTu | in_JRAT-Fix | 02:_ManualTun |
| Setting valu Tuning Functi | Group0-Page01 ATCHA Automatic Tuning Characteristic | 00:_Positioning1 01:_Positioning2 02:_Positioning3 03:_Trajectory1 | 04:_Trajectory2 | 00:_Positioning1 01:_Positioning2 02:_Positioning3 03:_Trajectory1 | 04:_Trajectory2 | 00:_Positioning1 01:_Positioning2 02:_Positioning3 03:_Trajectory1 04:_Trajectory2 |
| alue ing" | KP | | Parameter KP1 setting value | | Parameter KP1 setting value | |
| tor Va Tuni | KVP | control gain that | control gain that | Control gain | Control gain | control gain that |
| Monit atic itents | TVI | automatic tuning function outputs | automatic tuning function outputs | corresponding to parameter | corresponding to parameter | automatic tuning function outputs |
| neter utoma | TCFIL | (Note 1) | (Note 1) | JRAT1 | JRAT1 | (Note 1) |
| "Param of Al (Savinę | JRAT | | | Parameter JRAT1 setting value | Parameter JRAT1 setting value | |
| | Remarks | These are the valu They are the same (Monitor Display - I Page1A TCFIL_MO | es while using it by t to Monitor Display v Page16 KP_MON, P DN, Page15 JRAT_M | he control loop. alues. age18 KVP_MON, F ION) | Page19 TVI_MON, | The control loop operates by using the parameter setting value. (Note 2) |

Note 1) After control power turned on, it becomes the gain corresponding to parameter JRAT1 until the gain presumption completion is done.

Note 2) The control loop operates in using the parameter setting value when TUNMODE is "02:_ManualTun". The gain under use changes when Save Result of Automatic Tuning. (It excludes it while switching the gain.) Therefore, there is a possibility that the movement of the motor changes suddenly. Please execute the Save Result of Automatic Tuning by an off servo or the motor halt condition.

The usage of the Save Result of Automatic Tuning is different according to the difference of the saved contents.

(1) TUNMODE = 00:_AutoTun

The control loop use the gain that automatic tuning function outputs. But after control power turned on, it becomes the gain corresponding to parameter JRAT1 until the gain presumption completion is done.

Save Result of Automatic Tuning function can set the initial value.

(2) TUNMODE = 01:_AutoTun_JRAT-Fix

The control loop use the gain corresponding to parameter JRAT1.

Save Result of Automatic Tuning function can save gain corresponding to parameter JRAT1.

(3) TUNMODE = 02:_ManualTun

The control loop use the parameter setting value.

Save Result of Automatic Tuning function can set the gain that automatic tuning function outputs. (When adjusting the parameter setting value, the saved value can be used as reference value.)

Note) The control loop operates in using the parameter setting value when TUNMODE is "02:_ManualTun". The gain under use changes when Save Result of Automatic Tuning. (It excludes it while switching the gain.) Therefore, there is a possibility that the movement of the motor changes suddenly. Please execute the Save Result of Automatic Tuning by an off servo or the motor halt condition.

When select "<u>T</u>est Run and Adjustment" - "Save Result of Automatic Tuning" in the menu bar of main screen, the following appears.

| | #1 | C #6 | C #8 | |
|---------|-----------------|-------------|------|--|
| | C #2 | C #7 | C #C | |
| | C #3 | C #8 | C #D | |
| | C #4 | C #9 | C #E | |
| | C #5 | C #A | C #F | |
| Servo A | Amplifier Model | Name : RS1L | 01AA | |

Save Result of Automatic Tuning is performed as follows.

- 1. Select the axis number of servo amplifier performing Save Result of Automatic Tuning in "Select Servo Amplifier".
- 2. When click "Execute", the following appears.



For the servo amplifier which Save Result of Automatic Tuning is not functioned, the following dialog box appears when click "OK".



This servo amplifier can not perform Save Result of Automatic Tuning.

When servo amplifier is not ready, the following dialog box appears.

| Save Re | sult of Automatic Tuning [#1 : R51L01AA] | 1 |
|---------|---|---|
| ⚠ | Save Result of Automatic Tuning cannot be executed. (not ready) | |
| | <u> </u> | |

Save Result of Automatic Tuning is not ready.

In case "Test Run and Adjustment" is executed with digital operator, Save Result of Automatic Tuning operation is not ready.

When confirming that Save Result of Automatic Tuning can be used, click "Execute" again.

In case servo amplifier is ready, the following appears.

| Save Result of Automa | tic Tunina [# | 1 : R51L01 | AA 1 | | | | × |
|-------------------------------------|-----------------|-------------------------------|--|--------------------------------|---|---|--|
| Tuning Mode TUNMODE : ATCHA : | Ma Pos | nual Tuning itioning Contr | ol 1 | | ATRES car However, saved as a to former s window is | h be changed on the the changed value a parameter. ATRE setting value when closed | nis window. e is not S returns this |
| Setting | | | | - | Eda | 1 | |
| Setting Parameter : | KP | 1,KVP1,TVI | 1,TCFIL1,JRAT1 | 실 _ | Euli | | |
| ATRES : | | | 2 | 0 | | | |
| Parameter Monitor Value | e of Automatic | Tuning | I | Paramete | r Setting Val | ue | |
| KP : | 98 | [1/s] | — | KP1 | : | 30 | [1/s] |
| KVP : | 93 | [Hz] | | KVP | 1: | 50 | [Hz] |
| TVI : | 10.7 | [ms] | 1 | TVI1 | : | 20.0 | [ms] |
| TCFIL: | 689 | [Hz] | Save Monitor Value | TCFI | L1: | 600 | [Hz] |
| JRAT: | 100 | [%] | | JRA | T1: | 100 | [%] |
| Data type of Monitor Va | alue is change | d by Tuning N | , Node (TUNMODE) and Aut | omatic Tunir | ng Character | istic (ATCHA). | |
| Manual Tuning : Prope | er gain by Auto | omatic Tuning | Function. | | | | |
| Automatic Tuning : Re | al using gain i | n control loop |). | | | | |
| - | JRAT | , KVP, TVI, T | CFIL : Proper gain by Auto | matic Tuning | g Function. | | |
| | KP : V | When ATCHA When ATC | is not Trajectory Control 2 CHA is Trajectory Control 2 | 2,Proper gaiı 2, KP1 settin | h by Automa g value. | tic Tuning Function | n. |
| Automatic Tuning (JR | AT fixed) : Rea | al using gain i | n control loop. | | | | |
| | JRAT : JF | RAT1 setting | value. Nonconstanta di | | | | |
| | KVP, KP·V | TVI, TCHL : F Mhen ATCHA | roper gain according to Ji is not Trajectory Control 3 | KAT1. 2 Proper dai | in according | to JRAT1 | |
| | When | ATCHA is Tr | ajectory Control 2, KP1 se | atting Value. | | | |
| | | | | | [| <u>C</u> lose | |

3. Set the "Setting Parameter" (Saving Contents) and the "ATRES" (Automatic Tuning Response).

When changing the "Setting Parameter" and "ATRES", click "Edit" and switch to editing mode. Enter the value in keyboards and click "Write".

Note) ATRES can be changed on this window. The changed value is reflected in the operation of the motor and amplifier. However, the changed value is not saved as a parameter. ATRES returns to former setting value when this window is closed.

• Tuning Mode

It displays general parameter "Tuning Mode (TUNMODE)" setting value.

ATCHA

It displays general parameter "Automatic Tuning Characteristic (ATCHA)" setting value.

Setting Parameter

Select The parameter saving by using this function.

ATRES

Set the General parameter "Automatic Tuning Response (ATRES)"

- Parameter Monitor Value of Automatic Tuning It displays control gain that automatic tuning function outputs.
- Parameter Setting Value
 It displays the saving value as the parameters.

4. Click "Save Monitor Value", save the "Parameter Monitor Value of Automatic Tuning" as the parameter. As a result of the saving, it is displayed "Parameter Setting Value" at the right of the window.

| Setting Parameter : | KP1,KVP1,TV | 11,TCFIL1,JRAT1 | Edit | | |
|--|--|--------------------|---|-------------------------------|-----------------------|
| ATRES : | | 20 | | | |
| arameter Monitor Value of . | Automatic Tuning | | Parameter Setting Value | • | |
| KP : | 98 [1/s] | | KP1 : | 30 | [1/s] |
| KVP : | 93 [Hz] | | KVP1 : | 50 | [Hz] |
| TVI : | 10.7 [ms] | | TVI1 : | 20.0 | [ms] |
| TCFIL: | 689 [Hz] | Save Monitor Value | TCFIL1: | 600 | [Hz] |
| JRAT: | 100 [%] | k | JBAT1: | 100 | [%] |
| | | \prod | | | |
| | | \int | | | |
| ⁹ arameter Monitor Value of | Automatic Tuning | Ţ | -Parameter Setting Value | | |
| Parameter Monitor Value of | Automatic Tuning 98 [1/s] | | Parameter Setting Value | 98 | [1/s] |
| Parameter Monitor Value of KP : KVP : | Automatic Tuning 98 [1/s] 93 [Hz] | | Parameter Setting Value KP1 : KVP1 : | 98 93 | [1/s] [Hz] |
| Parameter Monitor Value of KP : KVP : TVI : | Automatic Tuning 98 [1/s] 93 [Hz] 10.7 [ms] | | Parameter Setting Value KP1 : KVP1 : TVI1 : | 98 98 93 10.7 | [1/s] [Hz] [ms] |
| Parameter Monitor Value of KP : KVP : TVI : TCFIL: | Automatic Tuning 98 [1/s] 93 [Hz] 10.7 [ms] 689 [Hz] | Save Monitor Value | Parameter Setting Value KP1 : KVP1 : TVI1 : TCFIL1: | 98 98 93 10.7 689 | [1/s] [Hz] [Hz] |

During editing [Setting Parameter] and [ATRES], the following appears. When click "Write", complete the editing by updating the setting value. When click "Edit Cancel", complete the editing without updating the setting value.

| Save Result of Automatic Tuni | ng [#1 : R51L01AA] | | × |
|---|---|-------------------------------------|--|
| Tuning Mode TUNMODE : ATCHA : | Automatic Tuning Positioning Control 1 | ATR How save to fo winc | ES can be changed on this window. rever, the changed value is not ed as a parameter. ATRES returns rmer setting value when this low is closed. |
| Setting Setting Parameter : ATRES : | KP1,KVP1,TVI1,TCFIL1,JRAT1 | Edit C Wr | ite |

Note) ATRES returns to former setting value when this window is closed.

3.23.Alarm Reset

This is the function for resetting alarm state of servo amplifier. This function is equivalent to Alarm Reset (AL-RST) with general purpose input terminal. Some alarm may not be reset.

When select "<u>T</u>est Run and Adjustment" - "Alarm <u>R</u>eset" in the menu bar of main screen or select "Amplifier" and "Alarm Reset" in the menu bar of alarm history, the following appears. Here resets the current alarm of servo amplifier.

| R Alarm Reset | | | l |
|------------------------|-------------|-------------|--------------|
| Select Servo Amplifier | | | |
| • #1 | C #6 | C #8 | |
| C #2 | C #7 | C #C | |
| C #3 | C #8 | C #D | |
| C #4 | C #9 | O #E | |
| C #5 | C #A | C #F | |
| Servo Amplifier Model | Name: RS1L | _01AA | |
| | Í E | vecute F | : |
| | | | - <u>A</u> n |

Alarm reset is performed as follows.

- 1. Select the axis number of servo amplifier performing alarm reset in "Select Servo Amplifier".
- 2. When click "Execute", the following appears.



For the servo amplifier which alarm reset is not functioned, the following dialog box appears when click "OK".



This servo amplifier can not execute alarm reset.

When servo amplifier is not ready, the following dialog box appears.



Alarm reset is not ready.

In case "Test Run and Adjustment" is executed with digital operator, alarm reset is not ready.

When confirming that alarm reset is enabled, click "Execute" again.

When servo amplifier is ready, the following dialog box appears and execute alarm reset.



3. When alarm reset completes normally, "Now executing" disappears and the following dialog box appears.



When alarm reset can not complete normally, the following dialog box appears.



3.24. Absolute Encoder Clear

This is a function for absolute encoder clear. This is equivalent to absolute encoder clear (ECLR) function.

When select "<u>T</u>est Run and Adjustment" - "<u>A</u>bsolute Encoder Clear" in the menu bar of main screen, the following appears. Here resets the multi-revolution data and the alarm in absolute encoder.

| | #1 | C #6 | C #8 | |
|---------|----------------------|------------|-------|--|
| | C #2 | C #7 | C #C | |
| | C #3 | C #8 | 🔿 #D | |
| | C #4 | C #9 | C #E | |
| | C #5 | C #A | C #F | |
| Servo A | mplifier Model | Name: RS1L | .01AA | |

Absolute encoder clear is performed as follows.

- 1. Select the axis number of servo amplifier performing absolute encoder clear in "Select Servo Amplifier".
- 2. When click "Execute", the following appears.



For the servo amplifier which absolute encoder clear is not functioned, the following dialog box appears when click "OK".

| Absolute | Encoder Clear [#1 : QS1 A01 A] | × |
|----------|--|---|
| ♪ | Absolute Encoder Clear cannot be used. | |
| | () | |

This servo amplifier can not execute absolute encoder clear.

When servo amplifier is not ready, the following dialog box appears.



Absolute encoder clear is not ready.

In case "Test Run and Adjustment" is executed with digital operator, alarm reset is not ready.

When confirming that absolute encoder clear is enabled, click "Execute" again.

When servo amplifier is ready, the following dialog box appears and execute absolute encoder clear.



3. When absolute encoder clear completes normally, "Now executing" disappears and the following dialog box appears.



When absolute encoder clear can not complete normally, the following dialog box appears.



3.25. Alarm Trace Clear

This is a function for deleting the past alarm saved in servo amplifier.

When select "<u>A</u>mplifier" - "Alarm Trace <u>C</u>lear" in the menu bar of alarm history, the following appears. Here clears the past alarm generated in servo amplifier.

| R Alarm Trace Clear | | | × |
|------------------------|-------------|--------|---------------|
| Select Servo Amplifier | | | |
| ● #1 | C #6 | C #8 | |
| C #2 | C #7 | C #C | |
| C #3 | C #8 | C #D | |
| C #4 | C #9 | C #E | |
| C #5 | C #A | C #F | |
| Servo Amplifier Model | IName: RS1L | .01AA | |
| | Ð | (ecute | E <u>×</u> it |

Alarm trace clear is performed as follows.

- 1. Select the axis number of servo amplifier performing alarm trace clear in "Select Servo Amplifier".
- 2. When click "Execute", the following appears.



For the servo amplifier which alarm trace clear is not functioned, the following dialog box appears when click "OK".

| Alarm Tra | ce Clear [#1 : QS1 A01 A] | × |
|-----------|-----------------------------------|---|
| 1 | Alarm Trace Clear cannot be used. | |
| | (COK | |

This servo amplifier can not execute alarm trace clear.

When servo amplifier is not ready, the following dialog box appears.



Alarm trace clear is not ready.

In case "Test Run and Adjustment" is executed with digital operator, alarm reset is not ready.

When confirming that alarm trace clear is enabled, click "Execute" again.

When servo amplifier is ready, the following dialog box appears and execute absolute encoder clear.



3. When alarm trace clear completes normally, "Now executing" disappears and the following dialog box appears.



When alarm trace clear can not complete normally, the following dialog box appears.

| Alarm Tra | ce Clear [#1 : QS1 A01 A] | × |
|-----------|--|---|
| 1 | Alarm Trace Clear has not been executed. | |
| | (OK) | |

3.26.Trace Operation

When select "Trace <u>Operation</u>" - "Trace <u>Operation</u>" in the menu bar of main screen, the following appears. Here displays and saves the trace operation data.

| R Trace O | R Trace Operation | | | | |
|--------------------|---|---|---|--|--|
| <u>F</u> ile Trace | Operation Print | | | | |
| 🛎 🖥 🛛 | 🔽 🔯 🐗 🚾 😕 🖉 🖆 🖩 🗹 🍂 | i 🖨 🗅. | | | |
| #1 #2 | Horizontal Scale : 200ms [/Div] | t1 : Model Motor : P50B05020D Amp : RS1A01AA | | | |
| #3 | Trigger : CH8 | t1 - t2 : [ms] 1 / (t1 - t2) : [Hz] | | | |
| #4 | Trigger Level : 50 | CH1: CH3: CH5: CH7: | | | |
| #5 | Trigger Edge : Rising Edge | CH2: CH4: CH6: CH8: CH8: CH8: CH8: CH8: CH8: CH8: CH8 | | | |
| #6 | Trigger Position : 80 [%] | | 1 | | |
| #7 | | | | | |
| #8 | CH1 : VMON: Velocity Monitor | | | | |
| #9 | Range : 10 💌 [min-1] 🔺 🔻 | | | | |
| #A. | CH2: VCMON: Velocity Command Monitor | | | | |
| #B | Range : 10 💌 [min-1] 🔺 🔻 | | | | |
| #C | CH3: TCMON: Torque Command Monitor | | | | |
| #D | Range : 10 🔽 [%] 🔺 🔻 | | | | |
| #E | CH4 : OPRT: Motor Operating Rate Monito | ····· | | | |
| #F | Range : 20 🔽 [%] 🔺 🔻 | | | | |
| File | CH5: TLC: Torque (Force) Limiting Opera | | | | |
| | CH6 : S-ON: Motor Excitation | | | | |
| | CH7 : S-RDY: Servo Ready Complete | | | | |
| | CH8: ALM: Alarm Status | | | | |
| | | | | | |

Click either one from [#1] to [#F] in the left of Trace Operation, and the corresponding servo amplifier is displayed. Click [File], and the screen switches to trace operation data saved in the file.

There are two different usages in Trace Operation. There are two changeable modes by trace operation setting.

- Trace mode: Saved data in the servo amplifier is read and displayed in waveform.
- Scroll mode: Data is periodically read from the servo amplifier and displayed in waveform.
- Horizontal scale

Indicates the horizontal setting of the displayed data. The horizontal setting of the displayed data can be changed.

• Sampling period

Indicates sampling period setting of displayed data.

- Trigger Indicates trigger signal (trigger channel) setting of displayed data.
- Trigger level
 Indicates the trigger level setting of displayed data.
- Trigger edge Indicates the trigger edge setting of displayed data.
- Trigger position
 Indicates the trigger position of displayed data.
- CH1, CH2, CH3, CH4

Indicates the data contents, vertical scale, and displayed color per channel. Vertical scale, vertical position, and data display ON/OFF per channel can be changed.

- CH5, CH6, CH7, CH8
 Indicates the data contents and displayed color per channel.
- t1

Indicates the displayed color and horizontal position of t1 cursor.

t 1 cursor can be moved by scroll bar. (When left-click on the data, t1 cursor moves to its position.)

• t2

Indicates the displayed color and horizontal position of t2 cursor.

t 2 cursor can be moved by scroll bar. (When left-click on the data, t2 cursor moves to its position.)

• t1 and t2

Indicates the duration between t1 and t2 cursors.

• 1/ (t1 and t2)

Indicates the reciprocal number of the duration between t1 and t2 cursors.

• CH1, CH2, CH3, CH4, CH5, CH6, CH7, CH8

Indicates the data of t1 cursor in value.

- % In scroll mode, horizontal scale is fixed by sampling period setting.
- ※ In scroll mode, trigger related contents will not be displayed.

% While monitoring scroll mode, there is no numerical display of cursor operation and cursor position.



Each function of trace operation can be accessed by selecting it in the menu bar of Trace Operation.

| R Trace Operation - | [C:\Data\trace.csv] | × |
|----------------------|--|---|
| File Trace Operation | Print | |
| ൙ Open Ctrl+O | | |
| Close | | |
| 🔚 Save As | cale : 200ms 🔽 [/Div] 11 : 💶 🕨 Motor : P50807030D Amp : RS1L01AA | |
| Exit | eriod : 5 [ms] 12 : 1 | |

[<u>F</u>ile]

- <u>Open</u>: Open the trace operation data stored in the file.
 ****Possible to select it only at displaying trace operation data saved in a file.**
- <u>Save</u> : Save the trace operation data which is now being displayed.
- Save <u>A</u>s: Save the trace operation data which is now being displayed as the other name in a file.
- Exit: Exit trace operation.





Left) In Trace mode

Right) In Scroll mode

[Trace Operation]

• <u>Trace Start + Trace Data Read</u> : Directs the trace start (data sampling start) to servo amplifier. Monitors data sampling status of servo amplifier. When completing sampling, read the trace operation data from servo amplifier and indicate it.

%Possible to select it only at displaying trace operation data of servo amplifier.

%Possible to select only at "Trace Mode" for trace mode select in trace operation setting of servo amplifier.

• Trace <u>Start</u> : Directs the trace start (data sampling start) to servo amplifier.

% Possible to select it only at displaying trace operation data of servo amplifier.

%Possible to select only at "Trace Mode" for trace mode select in trace operation setting of servo amplifier.

Trace Data <u>R</u>ead : Monitors data sampling status of servo amplifier. When completing sampling, read the trace operation data from servo amplifier and indicate it. If data sampling keeps, continues to monitor it.

※Possible to select it only at displaying trace operation data of servo amplifier.
※Possible to select only at "Trace Mode" for trace mode select in trace operation setting of servo amplifier.

• <u>M</u>onitor Start : Reads data continuously from the servo amplifier and starts displaying scroll mode data.

※Possible to select it only at displaying trace operation data of servo amplifier.※Possible to select only at "Scroll Mode" for trace mode select in trace operation setting of servo amplifier.

- Monitor Stop : Stops displaying scroll mode data (Stops updating the display).
 **Possible to select it only at displaying trace operation data of servo amplifier.
 **Possible to select only at "Scroll Mode" for trace mode select in trace operation setting inside the servo amplifier.
- <u>C</u>lear Trace Data : Deletes the trace operation data in servo amplifier. Deletes the trace operation data which is being displayed.

%Possible to select it only at displaying trace operation data of servo amplifier.

• Trace Operation Setting : Sets the trace operation for servo amplifier.

%Possible to select it only at displaying trace operation data of servo amplifier.

- <u>D</u>isplay Setting : Sets the trace operation and the color at printing.
- <u>G</u>eneral Parameter Setting... : Can set general parameters. For procedures, refer to "3.6. General Parameter Setting"

%Possible to select it only at displaying trace operation data of servo amplifier.

 Measurement...: The maximum, the minimum, the average, and the effect value of the waveform data under the display can be requested. Refer to "3.25.6. Measurement of Trace Operation"

※Possible to select it only while displaying the waveform data of the servo amplifier or the file that has been preserved.

Note) Some servo amplifiers do not apply to the trace operation function depending on the type and the version. In those not applying, the following screen appears when selecting "Trace Start + Trace Data Read", "Trace Start", "Monitor Start", and "Trace Operation Setting ".

| Warning | × |
|---------|-------------------------------------|
| ⚠ | Trace Operation cannot be executed. |
| | |

| R Trace Operation | 2 | < |
|----------------------------|-------|---|
| File Trace Operation Print | | |
| 📽 🐐 🔯 🐼 📢 Print Ctrl+P | | |
| Print Preview | Model | |

[Print]

• <u>Print</u> : Print the trace operation data which is being displayed.

%Impossible to select it when the trace operation data is not displayed.

 Print Preview : Indicates the print image of trace operation data which is now being displayed.

%Impossible to select it when the trace operation data is not displayed.

3.26.1. Trace Operation Setting

When click "Trace <u>Operation</u>" and "Trace Operation Setting (E)", the following appears. Here sets the contents of trace operation.

| Trace Operation Setting | |
|--|---|
| Trace Mode : Analog 4CH + Digital 4CH | Load the Trace Operation Setting |
| Analog Channel Setting Trace Data CH1: VMON: Velocity Monitor (min- CH2: VCMON: Velocity Command Monitor (min- CH3: TCMON: Torque Command Monitor (%) CH4: OPRT: Motor Operating Rate Monitor (%) | Trigger Sampling Setting -1] C Sampling Period : 20 ◆ × 0.25 [ms] -1] C (1 - 65535) [ms] -C Tracing Time : 1275 [ms] |
| Digital Channel Setting Trace Data | Trigger Setting |
| CH5 : TLC: Torque (Force) Limiting Operation | O Trigger Level : 50 🜩 |
| CH6 : S-ON: Motor Excitation | • |
| CH7 : S-RDY: Servo Ready Complete | C Trigger Edge : Rising Edge |
| CH8 : ALM: Alarm Status | Trigger Position: 80 	 [%] (0 - 100) |
| | Cancel |

When click "OK" after entering the contents, update them and start the trace. Click "Cancel" in case the setting is not updated.

When executing trace setting for the servo amplifiers that do not apply to the trace operation function, the following screen appears. Trace operation function cannot be used.



• Access the setting condition.

Click "Open" and select the stored trace operation data file. Read the stored trace operation data.

• Select the trace mode.

Select the trace operation mode among the following.

Scroll mode

2 channel analog data and 2 channel digital data can be monitored by scroll mode. Possible to obtain 1000 data per channel at the minimum sampling period of 50ms. (Minimum sampling period may be different depending on the servo amplifier type.)

Trace mode : Analog 4CH + Digital 4CH

Trace the analog and digital data of 4 channel. 256 data per channel can be obtained.

Trace mode : Analog 2CH + Digital 2CH

Trace the analog and digital data of 2 channel. 512 data per channel can be obtained.

Trace mode : Analog 1CH+Digital 1CH

Trace the analog and digital data of 1 channel. 1024 data per channel can be obtained.

• Analog setting

Selects the data contents of CH1 to CH4. Selects the trigger signal.

Analog data is classified under two kinds according to its data length.

- 2Byte type (In normal font)
- 4Byte type (In thick font)

4Byte type consumes the memory for 2 channels. Therefore, there are some channels that cannot be set. (In case of setting prohibited, setting contents will be displayed in pale color.) When select the 4Byte type data in CH1 to CH3, the next channel can not be used. (E.g. When selects 4Byte type in CH2, CH3 can not be used.) Cannot set to the largest numbered channel of each mode.

Setting to CH4 prohibited at "Trace Mode : Analog 4CH + Digital 4CH".

Setting to CH2 prohibited at "Trace Mode : Analog 2CH + Digital 2CH".

Setting to CH2 prohibited at "Scroll Mode".

4Byte type data cannot be designated at "Trace Mode : Analog 1CH + Digital 1CH".

• Digital setting

Select the data contents of CH5 to CH8. Selects the trigger signal.

• Sampling setting

Sets the sampling period. Product of the base time and the set value (multiple) becomes the sampling period. The duration enabling trace is displayed according to trace mode selection contents and sampling period setting.

• Trigger condition setting

Set the trigger condition.

- Trigger level : In case the trigger signal is digital data, the setting is not required.
- Trigger edge
- Trigger position

3.26.2. Select Contents of Trace Operation Setting

The table below is the explanation of select contents for standard servo amplifier. Select contents may be different from the ones below depending on the amplifier type.

| Trace mode | Number of monitor channels | | Data points at | Trigger | Sampling | Notes |
|---------------|----------------------------|--------------|----------------|----------|----------------|--------|
| | Analog data | Digital data | file save | setting | period setting | |
| | | - | (per channel) | | | |
| | Note 3 | | | | Note 4 | |
| Scroll Mode | 2 | 2 | 1000points | Not | 50ms or more | Note 1 |
| | (CH1, CH2) | (CH5, CH6) | - | possible | | |
| Trace Mode: | 4 | 4 | 256points | Possible | 0.25ms or | Note 2 |
| Analog 4CH | (CH1, CH2, | (CH5, CH6, | | | more | |
| + Digital 4CH | CH3, CH4) | CH7, CH8) | | | | |
| Trace Mode: | 2 | 2 | 512points | Possible | 0.25ms or | Note 2 |
| Analog 2CH | (CH1, CH2) | (CH5, CH6) | | | more | |
| + Digital 2CH | | | | | | |
| Trace Mode: | 1 | 1 | 1024points | Possible | 0.25ms or | Note 2 |
| Analog 1CH | (CH1) | (CH5) | | | more | |
| + Digital 1CH | | | | | | |

• Trace mode select

Note 1. Data is periodically read from the servo amplifier and waveform is updated. When sampling period is set to blow 200ms, the following environment (CPU operation frequency) is recommended.

Data sampling period setting = 50ms or above, below 100ms.: CPU operation frequency 800MHz or above.

Data sampling period setting = 100ms or above, below 200ms.: CPU operation frequency 350MHz or above.

Data sampling period setting = 200ms or above. : CPU operation frequency 133MHz or above.

Even if recommended environment is met, display sometimes becomes abnormal. This abnormality may be resolved by reducing the load of PC, such as by terminating other applications or stopping some resident program.

Note 2. Data is temporarily saved in the servo amplifier. After trigger generation or sampling stop, data is read and waveform is displayed.

Note 3. The number of monitor channels of analog data is that for monitoring 2Byte type signals. Monitoring 4Byte type signals consumes twice as much the memory for 2Byte type signals (for 2 channels), therefore, the number of monitor channels becomes less. (For details, see the previous page.)

Note 4. The range of sampling period setting may be different depending on the servo amplifier type.

• Analog CH select contents

| Select contents | Data type | Data range | Unit | Notes |
|---|-----------|---------------------|---------|--------|
| Note 2 | (Data | Note 3 | Note 4 | |
| | length) | | | |
| VMON: Velocity Monitor | 2Byte | -32768 \sim 32767 | min-1 | |
| | | | [mm/s] | |
| VCMON: Velocity Command Monitor | 2Byte | -32768 \sim 32767 | min-1 | |
| | | | [mm/s] | |
| TMON: Torque Monitor | 2Byte | -32768 \sim 32767 | % | |
| [TMON: Force Monitor] | | | | |
| TCMON: Torque Command Monitor | 2Byte | -32768 \sim 32767 | % | |
| [TCMON: Force Command Monitor] | | | | |
| PMON: Position Deviation Monitor | 4Byte | -2147483648 | Pulse | |
| | | \sim 2147483647 | | |
| APMON : Actual Position Monitor (Motor | 4Byte | -2147483648 | Pulse | |
| Encoder) | | \sim 2147483647 | | |
| CPMON: Command Position Monitor | 4Byte | -2147483648 | Pulse | |
| | | \sim 2147483647 | | |
| FMON : Position Command Pulse Monitor | 2Byte | -32768 | Pulse | |
| (Position Command Pulse Input Frequency) | | \sim 32767 | | |
| Sine U | 2Byte | -32768 \sim 32767 | | Note 5 |
| PS-H: Absolute Encoder PS (High) | 4Byte | $0 \sim 4294967295$ | x2^32 P | |
| PS-L: Absolute Encoder PS (Low) | 4Byte | $0 \sim 4294967295$ | Pulse | |
| RegR: Regenerative Resistor Operation Ratio | 2Byte | $0\sim 65535$ | 0.01% | |
| OPRT: Motor Operating Rate Monitor | 2Byte | $0\sim 65535$ | % | |
| JRAT_MON : Control Loop Parameter_Load | 2Byte | $0\sim 65535$ | % | |
| Inertia Moment Ratio Monitor | | | | |
| [JRAT_MON : Control Loop Parameter_Load | | | | |
| Mass Ratio Monitor] | | | | |
| TLMON_EST: Load Torque (Estimated Value) | 2Byte | -32768 \sim 32767 | % | |
| [TLMON_EST:Load Force (Estimated Value)] | | | | |
| PMON_S: Position Deviation Monitor (2Byte) | 2Byte | -32768 \sim 32767 | Pulse | Note 6 |

Note 1. The select contents above show when the standard type servo amplifier is combined with R-Setup. For details of each signal, refer to "Explanation of Parameter" in the Servo Amplifier Instruction Manual. Note 2. Words in parentheses are for linear system.

Note 3. Data range in this table shows the range where waveform display is possible.

If servo amplifier deals with smaller range than the above, display is only within the range that servo amplifier can deal with.

Note 4. Unit equivalent to 1LSB. Units in parentheses are for linear system.

Note 5. Outputs Sin U (U phase electric angle).

When U phase electric angle = 0 deg., monitor data = 0.

When U phase electric angle = 90 deg., monitor data = 32767 (Peak at positive direction of sine waveform) When U phase electric angle = 270 deg., monitor data = -32767 (Peak at negative direction of sine waveform) Note 6. When position deviation becomes -32768 or below, data always show -32768.

When position deviation becomes 32767 or above, data always show 32767.

• Digital CH select contents

| Select contents | Explanation of signal | Notes |
|---|---|--------|
| Note 1 | | |
| CONT1: General Purpose Input1 | Indicates input signal state of general purpose input | |
| CONT2: General Purpose Input2 | (CON11 \sim 8) terminal. | |
| CONT3: General Purpose Input3 | "High" | |
| CONT4: General Purpose Input4 | •Input photo coupler ON (CON11 \sim 6) | |
| CONT5: General Purpose Input5 | • During negative logic signal input(CON17,8) | |
| CONT6: General Purpose Input6 | LOW $(CONT1_{\odot}6)$ | |
| CONT7: General Purpose Input7 | • During positive logic signal input (CONT7.8) | |
| CONT8: General Purpose Input8 | | |
| OUT1: General Purpose Output1 | Indicates the state of general purpose output | Note 2 |
| OUT2: General Purpose Output2 | (OUT1 \sim 8) terminal. | |
| OUT3:General Purpose Output3 | "High" | |
| OUT4:General Purpose Output4 | •Output transistor OFF | |
| OUT5: General Purpose Output5 | "LOW" | |
| OUT6: General Purpose Output6 | | |
| OUT7: General Purpose Output7 | | |
| OUT8: General Purpose Output8 | | |
| INP: In-Positioning | "High" during positioning complete state. | |
| NEAR: In-Position Near | "High" during near range state. | |
| VCMP: Speed Matching | "High" during velocity conformity state. | |
| TLC: Torque (Force) Limiting Operation | "High" during torque (force) limit operation. | |
| VLC: Velocity Limiting Operation | "High" during velocity limit operation. | |
| S-ON: Motor Excitation | "High" during motor excitation. | |
| S-RDY: Servo Ready Complete | "High" during operation ready complete. | |
| CMD-ACK: Command Can be Accepted | "High" during command receive permit state. | |
| PCON-ACK : During Velocity Loop | "High" during velocity loop proportional integration | |
| Proportional Control | control state. | |
| EGR-ACK: During Electric Gear Switching | "High" during electric gear switching state. | |
| WNG-OFW: Following Warning | "High" during excessive deviation warning. | |
| WNG-OLW: Over Load Warning | "High" during over load warning. | |
| ALM: Alarm State | "High" during alarm state. | |

Note1. The select contents above show when the standard type servo amplifier is combined with R-Setup.

Note2. Logic is reverse to the monitor display (monitor display page 04 of R-Setup).

| | Q-SETUP | | | |
|----------------------------|------------------------------|--------------------------------------|--|--|
| State of output transistor | Trace Operation digital data | Monitor Display page 04 OUT8-1: | | |
| | OUT*:General Purpose Output* | General Purpose Output OUT8~1Monitor | | |
| Output transistor OFF | "High" | "0" | | |
| Output transistor ON | "Low" | "1" | | |

3.26.3. Trace Operation Display Setting

When click "Trace Operation" - "Display Setting", the following appears. Here sets the data display of trace operation.

| Trace Operation Display Setting | ş | X |
|---------------------------------|-------------|--------------------------|
| Analog CH1 | Digital CH5 | T1 |
| Color : | Color : | Color : |
| Width : 2 | Width: 1 | Width : 2 |
| Mark : | Mark : | |
| Analog CH2 | Digital CH6 | -t2 |
| Color : | Color : | Color : |
| Width : 2 | Width : 1 | Width : 2 |
| Mark : | Mark : | |
| Analog CH3 | Digital CH7 | |
| Color : | Color : | |
| Width : 2 | Width : 1 | |
| Mark : | Mark : | It prints by gray scale. |
| Analog CH4 | Digital CH8 | |
| Color : | Color : | |
| Width: 2 | Width: 1 | |
| Mark : | Mark : | |
| | | OK X Cancel |

When click "OK" after entering the contents, update them and start the trace. Click "Cancel" in case the setting is not updated.

- Analog CH1 to Digital CH8 Select the color, width, and mark in data display.
- t1, t2

Select the color and width in cursor display.

• Print by gray scale.

When check this, display all colors in the tone of black/white at printing.

3.26.4. How to Use Trace Mode of Trace Operation Function

This section explains how to use trace mode of trace operation function.

1. Set the trace operation.

Open the trace operation setting by selecting "Trace <u>Operation</u>" - "Trace Operation Setting (E)" in the menu bar of trace operation. Select "Trade Mode : $\cdot \cdot \cdot$ " at "Trace Mode Select". Set others as necessary. After inputting, click "OK" to update the setting.

2. Start the trace. (In case of using "Trace Start" and "Trace Data Read")

When select "Trace <u>Operation</u>" - "Trace <u>Start</u>" in the menu bar of trace operation, start the trace. Although servo amplifier starts sampling, the display of setup software remains unchanged.

Once servo amplifier starts sampling, it continues until trigger is generated or the control power is shut off. (Sampling continues even after terminating the setup software or cutting off the cable.) After trigger generation, the data can be read by using "Trace Data <u>R</u>ead...".)

- Read the data and display it. (In case of using "Trace <u>Start</u>" and "Trace Data <u>Read</u>")
 When select "Trace <u>Operation</u>" "Trace Data <u>Read</u>" in the menu bar of trace operation, read the trace data.
 - In case of sampling in progress (waiting trigger), the following appears.



Servo amplifier is sampling the data while waiting the trigger.

When click "Sampling <u>Stop</u>", stops sampling. (This detects the trigger falsely.) When click "Cancel", this dialog box is closed. Even if click "Cancel", servo amplifier continues sampling. When the trigger is detected, switch to the dialog box after trigger is generating.

• When sampling in progress (after trigger generating), the following appears.

| Sampling in progress (trigger generating) | × |
|--|---|
| Sampling in progress. The remaining time : 8.500[sec] | |
| X Cancel | |

Servo amplifier is sampling the data. "The remaining time" displays that of sampling. When the remaining time is 0 [sec], switch to "Now Reading".

• When sampling is completed, the following appears.

| Now Reading | |
|---------------------------|--|
| Now Reading. Please wait. | |
| | |
| | |

Reading the sampling data from servo amplifier. When the reading is completed normally, "Now Reading" disappears and trace operation data is displayed.

4. Execute Trace Start and Trace Data Read continuously. (When use "<u>T</u>race Start+Trace Data Read")

When select "Trace <u>Operation</u>" - "<u>Trace Start</u>+Trace Data Read " in the menu bar of trace operation, start the trace. When the trace starts, the following appears.



Servo amplifier is sampling the data while waiting trigger generation.

When click "Sampling Stop", stops sampling. (This detects the trigger falsely.)
When click "Cancel", this dialog box is closed. Even if click "Cancel", servo amplifier continues sampling.

Once servo amplifier starts sampling, it continues until trigger is generated or the control power is shut off. (Sampling continues even after terminating the setup software or cutting off the cable.) After trigger generation, the data can be read by using "Trace Data <u>R</u>ead".)

When the trigger is detected, the following dialog box appears.

| Sampling in progress (trigger generating) | × |
|--|---|
| Sampling in progress. The remaining time : 8.500[sec] | |
| X Cancel | |

Servo amplifier is sampling the data.

"The remaining time" displays the period until the sampling completes. When the remaining time is 0[sec], the following dialog box appears.

| Now Reading | |
|---------------------------|--|
| Now Reading. Please wait. | |
| | |

Reading the sampling data from servo amplifier. When the reading is completed normally, "Now Reading" disappears and trace operation data is displayed.

- Trace operation data display in progress
 When trace operation data read is complete and the data is displayed on the screen, following operations are possible.
- Saving trace operation data.
- Cursor Operation.
- Expanding horizontal range.
- Changing vertical axis range for each channel. ON/OFF of the vertical and data.

3.26.5. How to Use Scroll Mode of Trace Operation Function

This section explains how to use scroll mode of trace operation function.

1. Set the trace operation setting.

Open the trace operation setting by selecting "Trace <u>Operation</u>" - "Trace Operation Setting (<u>E</u>)" in the menu bar of trace operation. Select "Scroll Mode" at "Trace Mode Select". Set others as necessary. After inputting these, click "OK" to update the setting.

 Select "Trace <u>Operation</u>" – "<u>Monitor Start...</u>" in the menu bar of trace operation to start the monitor. Read the data for each sampling period from the servo amplifier and update the data displaying screen. Monitoring operation (data read, updating data displaying screen) continues until monitoring stops or any stop occurs due to communication error.

During monitoring operation, following operations are possible.

• Changing vertical axis range for each channel. ON/OFF of the vertical and data.

Depending on the sampling period setting, data display on the screen may be broken. This phenomena occurs when communication or displaying transaction is not in time for the sampling period setting. Reduce the load of PC by terminating other applications or stop resident program. If not improved by these measures, change the sampling period setting. When broken display (data missing) occurs very frequently, monitoring may stop. Note that display is broken when menu bar is opened during monitor operation.

3. Select "Trace Operation" – "Monitor Stop" to stop monitoring.

During monitor stop, following operations are possible.

- Saving trace operation data.
- Cursor operation.
- Changing vertical axis range for each channel. ON/OFF of the vertical and data.

3.26.6. Measurement of Trace Operation

When click "Trace Operation" - "Measurement", the following appears. Here sets the data display of trace operation. The maximum, the minimum, the average, and the effective value of the waveform data under the display can be requested.

| All Data | aj o e | Between t1 and t2 | t1 - t2: 305 | [ms] |
|------------------------------|--------|-------------------|--------------|------|
| | Max | Min | Ave | RMS |
| сн1 | | | | |
| СН2 | | | | |
| снз 🔽 | | | | |
| СН4 | | | | |
| | Мах | Min | Ave | |
| СН5 | | | | |
| СН6 | | | | |
| снт | | | | |
| сня | | | | |

Measurement Range

Select the measurement data.

"All Data": All the data under the display is measured.

"Between t1 and t2": The data between the cursor t1 and the cursor t2 is measured.

- Measurement Star
 The measurement of waveform data begins, and the measurement result is updated.
- Outputs to File

The measurement result is outputted to a text file.

Print Preview

Indicates the print image of measurement result.

- Max: The maximum value in measurement data is displayed.
- Min: The minimum value in measurement data is displayed.
- Ave: The average value of the measurement data is displayed.
- RMS: The effective value (root mean square value) of the measurement data is displayed.

Note for "Measurement" of "Trace Operation"

- Note for data loss at "Scroll Mode".

In case of data loss resulted form communication environment or setting of sampling frequency etc.

There is a possibility that no data exists.

In the trace operation measurement function, the area where no data exists will be excluded from measurement target.

The measurement function can be used even when data is lost.

* When all the data is lost in the measurement range (no data exists), the measurement result is "0".

- Initial data of "Scroll Mode"

At "Scroll Mode", 1000 point data is always displayed.

When monitoring starts, this 1000 point data is cleared to "0".

Therefore, from monitoring start until the time 1000 times as long as the sampling frequency will have past, initial data "0" exists which is not actual data.

The Measurement function of Trace Operation treats this initial data "0" as measurement target.

- Initial data of "Trace Mode"

At "Trace Mode", data buffer is cleared to "0" when tracing starts.

Therefore, when a trigger is detected and sampling stops before Tracing Time will have past after tracing start, initial data "0" exists which is not actual data.

The Measurement function of Trace Operation treats this initial data "0" as measurement target.

* Specify by cursor the measurement range and make the actual data as measurement target.

3.27. System Analysis

In the system analysis, system can be easily analyzed by operating servo amplifier and servomotor for the duration from hundreds ms to tens seconds. This function operates the servomotor, therefore, take care for safety.

Click "<u>T</u>rial Operation and Adjustment" – "<u>System Analysis...</u>" in the menu bar of main screen, and the following system analysis screen appears. System analysis data is displayed and saved here.

| R System Analysis | | | | | [|
|--------------------------------|--------|------------------------|----------------------------|-----------|-------|
| | | | | | |
| System Analysis Setting | | Axis Model Moto | or : | Amp.: | |
| Analysis Frequency : | | ti : 🗨 🕨 📔 | [Hz] | [dB] | [deg] |
| | | 12: 1 | [Hz] | [dB] | [deg] |
| | | Ratio of torque (force |) limit status during meas | urement : | [%] |
| Control Loop Parameter Monitor | [dB] | | | | |
| JRAT_MON: [%] | | | | | |
| KVP_MON: [Hz] | | | | | |
| TVI_MON : [ms] | Gain | | | | |
| TCNFILA_MON : [Hz] | | | | | |
| TCNFILB_MON : [Hz] | | | | | |
| TCFIL_MON: [Hz] | | | | | |
| | [dea] | | Frequency [Hz] | | |
| | [009] | | | | |
| | | | | | |
| Scale : 10 dB/Divi | Dhase | | | | |
| Auto Default | Fliase | | | | |
| | | | | | |
| | | | | | |
| Cone : [deginiv] | | , | Ereguerou [Hz] | | |

System analysis setting

Displays measurement conditions when analysis data now on display is obtained.

• Control loop parameter monitor

Displays contents of control loop parameter when analysis data now on display is obtained.

Range

Indicates vertical axis range for Gain and Phase.

Gain can change vertical axis and the vertical. "Auto" and "Default" can automatically adjust the vertical axis range and the vertical.

"Auto" : Adjusts the vertical axis range and the vertical to appropriate setting.

"Default" : Returns the vertical axis range and the vertical to initial setting.

• t1

Indicates the color of t1 cursor and the horizontal.

When data is displayed, t1 cursor can be moved by scroll bar. (Left click on the data moves the t1 cursor to the position.) There is numerical display for t1 cursor position data (frequency, gain and phase) at the right of t1 scroll bar.

• t2

Indicates the color of t2 cursor and the horizontal.

When data is displayed, t2 cursor can be moved by scroll bar. (Right click on the data moves the t2 cursor to the position.) There is numerical display for t2 cursor position data (frequency, gain and phase) at the right of t2 scroll bar.

 Generation ratio of torque (thrust) limit state while measuring Indicates the generation ratio of torque (thrust) limit state when obtaining analysis data. If this ratio is high, there is a possibility that result of analysis may be different from actual system.

Each function of the system analysis can be accessed by selecting one in the menu bar of system analysis.

| R System Analysis - | [C:\Data\SystemAnalysis.csv] | × |
|----------------------|-----------------------------------|---|
| File System Analysis | Print Help | |
| 🗃 Open Ctrl+O | 🤊 🔳 🕼 🗋 🕰 | |
| Close | 8 Axis Model File Motor: Amp.: | |
| Exit | 0 [%] | |

[<u>F</u>ile]

- <u>Open...</u>: Opens and displays system analysis data file.
- <u>C</u>lose...: Clears the data while system analysis data file is displayed.
 ※Possible to select only when system analysis data file is displayed.
- Save <u>A</u>s...: Saves the displayed data in the file.
 ***Possible to select only when analysis result data or system analysis data file is displayed.**
- E<u>xit</u> : Exits the system analysis.

| R۶ | ystem Analysis | | × |
|----------|---|--|---|
| Eile | System Analysis Print Help | | |
| 2 | 😤 Measurement & Analysis Start | | |
| C C | Clear Data Display Setting | Axis Model #1 Motor : P50B07030D Amp.: RS1L01AA | |

[System Analysis]

Start Data Measurement & <u>Analysis...</u>: Starts data measurement and analysis.
 ***Possible to select only at online.**

※ In the reduction installed R-Setup, selection is possible, however, data measurement/analysis cannot be performed.

• <u>G</u>eneral Parameter Setting... : Can set general parameters. For procedures, refer to "3.6. General Parameter Setting"

%Possible to select only at online.

- Data <u>Clear</u> : Clears the data on the screen while displaying analysis result.
 ***Possible to select only when analysis result is displayed.**
- <u>D</u>isplay Setting : Sets the system analysis screen and the color for printing.

| R System Analysis | | × |
|--|--------|-------|
| <u>File</u> System Analysis Print Help | | |
| 🛩 🕼 🛛 🞇 📝 🛛 🚔 Print | Ctrl+P | |
| 🛄 Print Preview | w | -Axis |

[Print]

• <u>Print</u> : Prints the displayed system analysis data.

%Do not select this unless system analysis data is displayed on the screen.

• Print Preview (\underline{V}) : Displays the image of the displayed system analysis data.

*Do not select this unless system analysis data is displayed on the screen

| R System Analysis | × |
|--|---|
| <u>File</u> System Analysis Print <u>H</u> elp | |
| 🖙 🕼 🞇 📝 🖉 🚦 Caution | |

[Help]

• <u>Cautions</u> : Opens a file describing cautions on using the system analysis.

%This file is html type, which can be opened where Internet Explorer 4.0 or above is installed.

3.27.1. Data Measurement & Analysis Start

Click "System Analysis" – "Data Measurement & <u>Analysis Start...</u>", and the following screen appears. The motor operates in positive/negative move to measure the data for analysis. After data measurement, analysis can start.

| R Measurement & Analy | /sis | | × |
|------------------------|------------|-------------|---------------|
| Select Servo Amplifier | | | |
| • #1 | C #6 | C #8 | |
| C #2 | C #7 | C #C | |
| C #3 | C #8 | C #D | |
| C #4 | C #9 | C #E | |
| C #5 | C#A | C #F | |
| Servo Amplifier Model | Name: RS1L | _01AA | |
| | E | xecute | E <u>×</u> it |

See the following procedure for Data Measurement & Analysis Start.

- 1. Select the axis number for which data measurement & analysis is to be executed in "Servo Amplifier Select".
- 2. Click [Execute], and the following screen appears.

| Measurem | ent & Analysis [#1 : QS1 A01 A 📑 💦 🔀 | 1 |
|----------|---------------------------------------|---|
| ? | Do you execute Measurement _Analysis? | |
| | Cancel | |

Click [OK], and the following screen appears if the servo amplifier does not apply to the system analysis function. In this servo amplifier, system analysis function cannot be used.



When the servo amplifier is not in ready complete state, the following screen appears.

| Measurem | ent & Analysis [#1 : QS1 A01 A 🛛 🔀 |
|----------|---|
| 1 | Measurement _Analysis cannot be executed. (Not ready) |
| | (OK) |

It is not ready for data measurement for system analysis.

Ready not complete state occurs when servo amplifier is in alarm state, when the main circuit power is not supplied, or when "Trial Operation and Adjustment" is being executed by digital operator. When data measurement becomes ready, click [Execute] again.

When servo amplifier is in ready complete state, the following screen appears.

| Measurement & Analysis [#1 : QS1 A01 A] |
|--|
| Select the operation at measurement completing C At completing, "Alarm of Test Run complete" is not selected. C At completing, "Alarm of Test Run complete" is selected. |
| System Analysis Setting |
| Torque (Force) Command : 25 🚔 [%] (0 - 200) |
| Measurement Frequency : 10.0 to 2000 [Hz] |
| Control Loop Parameter Monitor |
| JRAT_MON : 100 [%] |
| KVP_MON : 50 [Hz] |
| TVI_MON : 20.0 [ms] |
| TCNFILA_MON : 2000 [Hz] |
| TCNFILB_MON : 2000 [Hz] |
| TCFIL_MON : 600 [Hz] |
| Motor Excitation |
| Servo ON Servo OFF |
| Execute Measurement |
| Execute |
| Note: When use this function, the motor functions. Execute this operation after securing the safety of surroundings. |
| |

3. Set options at the end of data measurement and system analysis.

If "Trial Operation End Alarm" is to be generated when data measurement ends (when analysis starts), click "Trial Operation End Alarm at End", and if not, click "No Trial Operation End Alarm at End".

In system analysis setting, torque (thrust) command at data measurement and frequency range to be analyzed are selected.

4. Confirm the control loop parameter that its value is as targeted. (If not, exit "Data Measurement & Analysis Start" once and change the value by general parameter setting.)

5. Click [Servo ON], and the following screen appears during alarm generation.



If servo amplifier cannot become Servo ON, the following appears.

| Measurem | ent & Analysis [#1 : QS1L01A |] | × |
|----------|---|--------------|----|
| ♪ | Servo ON cannot be functioned Check the status of Servo Am | ł. plifie | r. |
| | OK) | | |

After making it possible, click [Servo ON] again.

At Servo ON state, [Execute] button can be used.

| Measurement & Analysis [#1 : QS1A01A] | × | | |
|--|---|--|--|
| Select the operation at measurement completing C At completing, "Alarm of Test Run complete" is not selected. C At completing, "Alarm of Test Run complete" is selected. | | | |
| System Analysis Setting | | | |
| Torque (Force) Command : 10 🚔 [X] (0 - 200) | | | |
| Measurement Frequency : 1.25 to 250 [Hz] | | | |
| Control Loop Parameter Monitor | | | |
| JRAT_MON : 100 [%] | | | |
| KVP_MON : 50 [Hz] | | | |
| TVI_MON : 20.0 [ms] | | | |
| TCNFILA_MON : 2000 [Hz] | | | |
| TCNFILB_MON : 2000 [Hz] | | | |
| TCFIL_MON : 600 [Hz] | | | |
| Motor Excitation Servo ON Servo OFF | | | |
| Execute Measurement | | | |
| Note: When use this function, the motor functions. Execute this operation after securing the safety of surroundings. | | | |
| Close | | | |

 Click [Execute], and the followings are displayed and data measurement is executed. Depending on the selected measurement frequency range, data measurement time varies. Therefore, display of "Data measurement in progress" sometimes lasts long.

| Measurement & Analysis [#1 : QS1A01A] |
|--|
| Now Setting. |
| |
| • • • • • • • • • • • • • • • • • • • |
| STOP Servo OFF |
| |
| |
| Measurement & Analysis [#1: USTAUTA] |
| Now Measuring. |
| |
| |
| X STOP Servo OFF |
| |
| |
| Measurement & Analysis [#1 : QS1A01A] |
| Now Reading. Please wait. |
| |
| |
| STOP Servo OFF |
| |

Click [Stop], and the measurement stops with Servo ON state remaining. Click [Servo OFF], and the measurement stops with Servo OFF.

When data measurement cannot be executed properly due to overtravel generation, the following appears. After removing the cause, execute data measurement again.



7. When data measurement ends normally, the following appears.

| Confirm | × |
|---------|---|
| ? | Data Measurement completed normally. Please Click "OK". Data measurement is completed and analysis is started.(When click "OK", Servo OFF functions.) |
| | OK Cancel |

Click [OK], and the following appears and analysis starts with Servo OFF.

Click [Cancel], and the measured data is canceled to return to the state before data measurement is executed (Servo ON state).



8. When analysis ends normally, the following result is displayed.



3.27.2. General Parameter Setting

Select "<u>System Analysis</u>" – "<u>G</u>eneral Parameter Setting…", and the general parameter setting screen appears. Here, general parameter can be set without closing system analysis screen. For the procedure, refer to "3.10. Transmit Parameter [File -> Amplifier]".

3.27.3. Display Setting

Click "System Analysis" – "Display Setting...", and the following screen appears. Trace operation data display is set here.

| System Analysis Display Settin | e 🔀 |
|--------------------------------|----------------------------|
| Gain | _t1 |
| Color : | Color : |
| Width : 1 | Width : 1 |
| Mark : 📃 💌 | |
| Phase | t2 |
| Color : | Color : |
| Width : 1 | Width : 1 🚖 |
| Mark : 📃 💌 | |
| | |
| | |
| | |
| | 🔲 It prints by gray scale. |
| | OK Cancel |

Click [OK] after inputting every setting, and the contents are updated and data is displayed again. If the setting is not to be updated, click [Cancel].

• Gain, Phase

Color of data display, line width and mark are selected.

• t1, t2

Color and line width for cursor display are selected.

• Print in gray scale

At the time of checking and printing, all the colors are displayed in black/white tone.

3.28.Status History Monitor

This function can monitor the status history recorded in the servo amplifier.

It is used only when combined with the servo amplifier with positioning function.

Select "<u>Monitor – Status History</u> ..." from the menu bar on the main screen, and the following screen appears.

| R Status History Disp | play | | X | | | |
|-------------------------------------|-------------|-------------|------------------|--|--|--|
| -Select Servo Amplifier | | | | | | |
| | C #6 | C #8 | | | | |
| C #2 | C #7 | C #C | | | | |
| C #3 | C #8 | Ċ #D | | | | |
| C #4 | C #9 | C #E | | | | |
| C #5 | C #A | C #F | | | | |
| Servo Amplifier Model Name: RS1L01A | | | | | | |
| | | ecute E | Exit(<u>(</u>) | | | |

The status history is displayed according to the following procedure.

- Select the axis number of the servo amplifier whose status history is to be displayed from "Servo Amplifier Selection".
- ② Click [Execute].

When the target amplifier is not corresponding to the status history monitoring function or ready is not yet complete, the following screen appears.

| Warning | | × |
|---------|-----------------------------------|---|
| ⚠ | Point Data Setting cannot be used | |
| | OK | |

If the target amplifier is the one with positioning function and corresponding to the status history monitoring function, wait for a few seconds and click [Execute] again.

Also the state of ready not complete occurs when "Test Operation and Adjustment" is being executed form the digital operator.

When the servo amplifier is in the ready complete status, the following screen appears.

| R s | tatus History | Display | | | | | × |
|--------------|-------------------|-------------------|----------------|------|-----|----------|---|
| <u>F</u> ile | <u>A</u> mplifier | | | | | | |
| | | | | | | | - |
| -A | wis | Model | | | 7 | | |
| | #1 | Moter: Q1AA06020D | Amplifier: RS1 | LU1A | | | |
| -9 | Status History— | | | | | | - |
| | | | | co | DE | ~ | |
| | | Counter | Status | DEC | HEX | | |
| | Last 1 | | | | | | |
| | Last 2 | | | | | | |
| | Last 3 | | | | | | |
| | Last 4 | | | | | | |
| | Last 5 | | | | | | |
| | Last 6 | | | | | | |
| | Last 7 | | | | | | |
| | Last 8 | | | | | | |
| | Last 9 | | | | | | |
| | Last 10 | | | | | | |
| | Last 11 | | | | | | |
| | Last 12 | | | | | | |
| | Last 13 | | | | | | |
| | Last 14 | | | | | ~ | |
| • | | | | | | | |

Axis

Display of the axis number of the amplifier whose status history is being displayed.

Model

Display of the model numbers of the motor and amplifier.

Status History

Display of the status history. The data is read from the amplifier every few seconds and the contents are automatically updated.

* If the amplifier status changes while the data is being read from the amplifier, wrong contents may be displayed. (Check the counter alignment to confirm that the contents are right.)

Functions of status history display can be accessed from the menu bar in the status history display screen.

| R Status Hi | story Display | × |
|-------------------------------|---------------|---|
| <u>File</u> <u>A</u> mplifier | | |
| <u>S</u> ave As | | |
| <u>E</u> xit | Model | |

[<u>F</u>ile]

• Save <u>As...</u>: Save the displayed status history in a text file.

* I The saved text file cannot be opened in the R-SETUP set-up software. Use other application corresponding to text file (*.txt) to open it.

• Exit : Exit status history display screen.

| R۹ | itatus His | story Display |
|--------------|-------------------|---------------|
| <u>F</u> ile | <u>A</u> mplifier | |
| | <u>S</u> tatus I | History Clear |

[Amplifier]

• Status History <u>Clear...</u>: Clear the status history information recorded in the servo amplifier.

3.28.1. Status History Clear

Click "<u>A</u>mplifier" – "Status History <u>C</u>lear..." in the status history display screen, and the following screen appears. Status history is erased here.

| R Status History Clea | r#1:RS1L01A 🛛 🔀 | | | |
|-------------------------------------|-----------------|--|--|--|
| Do you execute Status Hisoty Clear? | | | | |
| ОК | Cancel | | | |

Click [OK], and the status history information is erased and the following screen appears.



Click [OK] to go back to the status history display screen. If the display contents have been automatically updated, the erased status history will be displayed.

3.29. Point Data Setting

Select "Point Data (S)" – "Point Data Setting.....", and the point data setting screen will appear. Specify the target to be edited and operated in this screen.

| R Point Data Set | ting | | | | | | |
|------------------------|-----------------|-------------|---------|--|--|--|--|
| Select Servo Amplifier | | | | | | | |
| | C #6 | ○ #8 | | | | | |
| C #2 | C #7 | C #C | | | | | |
| C #3 | C #8 | C #D | | | | | |
| C #4 | C #9 | C #E | | | | | |
| C #5 | i 🔿 #A | C #F | | | | | |
| Servo Amplifier Mo | del Name 🛛 🕅 RS | 1L01A | | | | | |
| Select Opera | tion Mode | | | | | | |
| ۰ | EXT. C R | SETUP | | | | | |
| | | | | | | | |
| C Edit File | | | | | | | |
| | | | | | | | |
| | | xecute | Exit(X) | | | | |

• File edit mode

Refer to 3.28. File Edit Mode for details.

Select "File Edit" and click [Execute]. Point data file can be created and edited.

• EXT. mode

Refer to 3.28.2 EXT Mode. Select 1 axis from "#1" to "#F", specify "EXT." in OPERATE selection and click [Execute]. The point data of the servo amplifier on line can be edited. This is possible even while operated from the upper device.

* This can be used when combined with the amplifier with positioning function.

- * This can be selected only while on line.
- R-SETUP mode (Servo amplifier selection + "R-SETUP" selection)

Refer to 3.28.3 R-SETUP Mode, 3.28.4 Test Run (R-SETUP Mode) and 3.28.5 Point Move (R-SETUP Mode).

Select 1 axis from "#1" to "#F", specify "R-SETUP" in OPERATE selection and click [Execute]. The point data editing and point function test run of the servo amplifier on line can be executed. This is not possible while operated from the host unit.

* This can be used when combined with the amplifier with positioning function.

* This can be selected only while on line.

3.29.1. File Edit Mode

Select "Point Data (S)" – "Point Data Setting..." from the menu bar of main screen, and the point data setting screen appears. Select "File Edit", click [Execute], and the following screen appears. Point data file can be created and edited.

| R P | oint Data S | etting | | | | | | | | | | | | | | | | | | | × |
|-------|-------------|------------|----------------|----------|---------|--------|--------|-------------|------------|-------|------------------|---------------|------------------------|-----------------------------|------|---|------------|-----------|---------|------------|---|
| File | Amplifier I | Print Help | | | | | | | | | | | | | | | | | | | |
| | ž 🖬 🍯 | 휘 태 영 | | a | | | | | | | | | | | | | | | | | |
| -Axi: | s Op | erate | Model Motor | : | | | Ar | np : | | | | Amp Actua | lifier Sti I Pos | Status atus : ition : | | | Pulse | | | | |
| Poir | nt Data 🛛 | | | | | | | | | | | | | | | | | | | | |
| | | | | | P | oint M | No. S | earc | h | Searc | n | | C | ру | | | | | | | |
| | 1 | | | | Operati | on Pa | atterr | 1 | | | | | | M Output | | | | | | | ^ |
| No | Feed Rate | Position | gain_selection | DE1 | DE2 | DE3 | S/INC | m./Striking | p/Continue | Accel | Time_of_S_Shaped | Current_Limit | Type | Delay | Code | ₫ | Dwell_Time | loop mode | Jump_No | Repetition | |
| | Pulse/s | Pulse | | OW | MO | OW | ABS | Nor | Stol | Uw/ms | ms | % | | Pulse | | | ms | | | | |
| 0 | | | | | | | | | | | | | | | | | | | | | |
| 1 | | | | | | | | | | | | | | | | | | | | | |
| 2 | | | | _ | | | | _ | _ | | | | _ | | | | | | _ | | |
| 3 | | | | _ | | | | _ | - | | | | _ | | | | | _ | | | |
| 5 | | | | | | | | | - | | | | | | | | | | _ | | - |
| 6 | | | | | | | - | | F | | | | | | | - | - | | | | |
| 7 | | | | | | | | | | | | | | | | | | | | | |
| 8 | | | | | | | | | | | | | | | | | | | | | |
| 9 | | | 1 | | | | | | | | <u></u> | 6 | | | | | | | | | |

Setting

File: File edit mode

Model Number

The servo amplifier model number and combined motor when file was saved.

* Display is only for the file in which the point data read form the servo amplifier is saved, not for a new file created by "File Edit".

- OPERATE, Amplifier status No display in File Edit Mode.
- Point data

The set value can be directly input at the cursor marked in yellow. ("Point Number" cannot be edited.) Edited point data will be displayed in red. Once saved in the file, the point data will be black again.

* If file is not open, point data cannot be edited.

• Point number search

Input the point number to be searched and click [Search]. The cursor will move to the specified point number.

Copy

Point data can be copied to that of other point number.

* Refer to 3.28.8 Copy (R-SETUP / EXT. / File Edit Mode) for details.

Functions of point data setting (File edit mode) can be accessed from the menu bar of the point data setting screen.

| R Point Data | Setting | | | |
|----------------|------------|-------|-------------------|-------|
| File Amplifier | Print Help | | | |
| 🗋 New | | | | |
| 😅 Open | rate Model | | Amplifier Status | |
| 🖬 Save | Motor : | Amp : | Status : | |
| Exit. | 77 | | Actual Position : | Pulse |

[<u>F</u>ile]

• <u>N</u>ew File...: Create a new point data file.

* Refer to 3.28.9 New file (File Edit Mode) for details.

- <u>Open....</u>: Open the point data file.
- <u>Save...</u>: Save the point data being edited in the file.
- Save <u>A</u>s....: Save the point data being edited into a file with another name.
- Exit : Exit the point data setting screen.

| R Point Data Setting | |
|--|------------------|
| File Amplifier Print Help | |
| 🗋 🛛 🖬 Read All Point Data from Amplifier | |
| Axis Alarm Reset | Amplifier Status |

[<u>A</u>mplifier]

Cannot be selected in File Edit Mode.

| R Point Data Setting | |
|---|----------------|
| File Amplifier Print Help | |
| Axis C Print Preview Axis C Print File C Output Text File | Amp : Status : |

[Print]

- Print Preview....: Displays the point data print image.
- <u>Print...</u>: Print the point data.
- <u>T</u>ext output...: Point data is output as a text file (*.txt).

* The saved text file cannot be opened in the R-SETUP setup software. Use other applications corresponding to text file (*.txt) to open it.



Descriptions for point data setting.

3.29.2. Ext. Mode

Select "Point Data (<u>S</u>)" – "Point Data <u>Setting...</u>" from the menu bar of the main screen, and point data setting screen appears. Select 1 axis from "#1" to "#F", specify "EXT." in OPERATE selection, and click [Execute], and then the following screen appears. Point data in the servo amplifier can be edited. This is possible even while operated from the host unit.

| RP | oint Data S | ietting | | | | | | | | | | | | | | | | | | | × |
|-------|-------------|------------|---------------|-----|---------|--------|-------|------------|----------|-------|-----------------|---------------|--------------|------------------|------|---|------------|-----------|---------|------------|---|
| File | Amplifier I | Print Help | | | | | | | | | | | | | | | | | | | |
| D | 2 🖬 🖬 | 휘휘 영 | D. | 8 | | | | | | | | | | | | | | | | | |
| Axi | | erate | Mode Motor | | | _ | Ar | mn · | _ | | _ | Amp | lifier St | Status atus : | | | | | _ | |] |
| | | | | .1 | | | | | 1 | | | Actua | I Pos | ition : | | | Pulse | | | | |
| Deit | | | | | | | | | | | | - | | | | | 12 | | | | - |
| Poir | | | | | P | oint h | | | de . | | | | | | | | | | | | |
| | | | | | ĺ | Uniti | чU. с | eart | <u></u> | Searc | h | | C | ору | | | | | | | |
| | | | | | Operati | on P: | atter | n | | | 75 | | | M Output | . 1 | | | | | | ^ |
| No | Feed Rate | Position | ain_selection | E1 | E2 | E3 | INC | u/Striking | Continue | Accel | ime_of_S_Shaped | Current_Limit | Type | Delay | Code | Ъ | Dwell_Time | loop mode | oN_dmuL | Repetition | |
| | Pulse/s | Pulse | 5 | MOD | MOD | MOD | ABS/ | Norm | Stop/ | Uv/ms | ms | % | | Pulse | | | ms | | | | |
| 0 | | | | | | | | | | | | | | | | | | | | | |
| 1 | | | | | | | | | | | | | | | | | | | | | |
| 2 | | | | | | | | | | | | | | | | | | | | | |
| 3 | | | | | | | | | | | | | | | | | | | | | - |
| 4 | | | _ | | | | | | | | | | | | - | | | _ | _ | | - |
| 5 | | | | _ | | - | - | _ | _ | | | | | | - | | | | - | | - |
| 7 | | - | | | | | | | | | | - | | | - | | | | _ | | - |
| 8 | | | | | | | | | - | | | | | | | | | | | | |
| 9 | | | | | | | | | | | | | | | | | | | | | × |
| Point | No:0 | | | | | | | | | | | | | | | | | | | | |

If the target servo amplifier is not applicable to point data setting function, or in the state of ready not complete, the following screen appears.



If the target amplifier is the one with positioning function and applicable to point data setting function, wait for a few seconds and click [Execute] again.

Also the state of ready not complete occurs when "Test Run and Adjustment" is being executed form the digital operator.

• Axis

The servo amplifier axis number whose point data is being edited.

• OPERATE

EXT. : EXT. mode.

Model number

Servo amplifier model number and combined motor.

• Amplifier status

Amplifier status and actual position.

Point data

The set value can be directly input at the cursor marked in yellow. ("Point Number" cannot be edited.) Edited point data will be displayed in red. Once read in the servo amplifier, the display will be black again.

* Point data cannot be edited unless executing [<u>A</u>mplifier] – [<u>R</u>ead All Point Data from Amplifier].

• Point number search

Input the point number to be searched and click [Search]. The cursor will move to the specified point number.

• Сору

Point data can be copied to that of other point number.

- * Refer to 3.28.8 Copy (R-SETUP / EXT. / File Edit Mode) for details.
- Teaching

This can be set to the data of the point number which specifies actual position.

* Refer to 3.28.7 Teaching (R-SETUP / EXT. Mode) for details.

Write

The point data with the cursor in is written into the servo amplifier. Only one point data can be written.

* When not executing [<u>A</u>mplifier] – [<u>R</u>ead All Point Data from Amplifier], all the point data being edited are in <u>O</u>riginal status. If "Write" is executed in this status, "0" is written in the target point data.

* When the servo amplifier is in busy status (while the point data of the target is being executed), writing is not possible.

Functions of point data setting (EXT. Mode) can be accessed from the menu bar on the point data setting screen.

| R Point Data | Setting | | | | | | |
|-------------------|------------|--------------------|---------------|-------------------------------|------------------|-------|--|
| File Amplifier | Print Help | 1 | | | | | |
| 🗋 New 📽 Open | ti 🗣 🖤 | Model | | - Amplifier Statu: | 8 | | |
| Save G Save As | | Motor : Q1AA06020D | Amp : RS1L01A | Status : Actual Position : | [00] Reset -2 | Pulse | |
| Exit | | | | | 1 | | |

[File]

- Save <u>A</u>s...: Point data being edited is saved in a file.
- Exit : Exit the point data setting screen.
 - * [New], [Open...] and [Save] cannot be used in the EXT. mode.

| R P | oint Data Setting | × |
|-------|---|---|
| File | Amplifier Print Help | |
| | 😵 Read All Point Data from Amplifier | |
| -Avia | 🖓 Write All Point Data to Amplifier | |
| #1 | Alarm Reset Amn RS1L01A Status : [00] Reset | |

[Amplifier]

- <u>R</u>ead All Point Data from Amplifier...: Read the point data from the servo amplifier as a batch.
- <u>W</u>rite All Point Data to Amplifier...: <u>W</u>rite the point data being edited to the servo amplifier as a batch.

* [<u>W</u>rite All Point Data to Amplifier] cannot be used unless executing [<u>A</u>mplifier] – [<u>R</u>ead All Point Data from Amplifier]

* When the servo amplifier is in busy status (while point data of the target is being executed), writing is not possible.

* [Alarm Reset...] cannot be used in the EXT. mode.

| R Point Data | Setting | | |
|----------------|---|------------------|--|
| File Amplifier | Print Help | | |
| | Print Preview Print Print Output Text File | Amplifier Status | |

[Print]

- Print Preview...: Display of point data print image.
- <u>Print</u> : Print the point data.
- <u>T</u>ext Output...: Point data is output as text file (*.txt)

* The saved text file cannot be opened in the R-SETUP setup software. Use other applications corresponding to text file (*.txt) to open it.

| R Po | oint Data | Setti | ng | |
|------|-----------|-------|------|--|
| File | Amplifier | Print | Help | |

[Help]

Descriptions are displayed about setting contents of point data.

3.29.3. R-Setup Mode

Select [Point Data (\underline{S})] – [Point Data \underline{S} etting...]" from the menu bar on the main screen, and point data setting screen appears. Select 1 axis from "#1" to "#F", specify "R-SETUP" in OPERATE selection, and click [Execute], and then the following screen appears. Point data in the servo amplifier can be edited and test run for pointing functions can be executed. This is not possible while operated from the host unit.

| R P | oint Data S | ietting | | | | | | | | | | | | | | | | | | | × |
|------------|----------------|--------------|---------------|------------|-----------|--------|--------|-------|-------|--------|--------|-------|--------------|-------------------------|------|-------|-------|------|-------|--------|---|
| File | Amplifier I | Print Help | | | | | | | | | | | | | | | | | | | |
| | * • • | 위 🖏 😵 | Q | 8 | | | | | | | | | | | | | | | | | |
| Axis #1 | S Op | BETUP | Mode Motor | : Q1AA | 06020C |). | Ar | np : | RS1 | L01A | | Amp | lifier St | Status atus : [00] R | eset | | | | | |] |
| | | | | | | | | | | | | Actua | I Pos | ition : -1 | | | Pulse | | | | |
| Poir | nt Data Test | Run Move I | Point | | | | | | | | | | | | | | | | | | |
| | | | | | P | oint N | No. S | earc | h | | - 11 | | | | | | | | | | |
| | | | | | | | | | | Searc | h | | С | ору | Tea | ching | | Data | a Wri | te | |
| | - | 1- | | | Operati | on P: | atterr | n | | | | | | M Output | | | | | | | ^ |
| | | | | | - | | | | | 5 | ped | | | | | | | | | | |
| | | | 5 | | | | | | | | Sha | imit | | | | | e | æ | | - | |
| No | Feed Rate | Position | ecti | | | | | p | e | | ω ω | 뉟 | | Delay | e | | Ē | 00u | 2 | titior | |
| | | | l Sel | | | | 1.2552 | rikir | ntinu | cel | , P | Ture | Type | | Cod | | well | g | dui | epet | |
| | | | gain, | Ē | Ē2 | E3 | N | n./St | /Cor | Ac | lime | ō | | | | Ч | á | 으 | J | œ | |
| | Pulcole | Pulco | | MOL | U U | MOL | ABS. | Por | Stop | Livíme | me | 06 | | Puleo | | | me | 1 | | | |
| | 1 0156/5 | 1 0156 | | _ | _ | _ | | _ | | Owins | 1113 | 70 | | i uise | | | 1113 | | | | |
| 1 | | | | | | | | | | | | | | | | | | | | | |
| 2 | | | | | | | _ | _ | - | | | | | | | | | | | | - |
| 3 | | ÷ | | | | | - | - | - | | | | | | | | | | | | - |
| 4 | 1 | 1 | 1 | | | | | | | | | | | 1 | | | | | | | - |
| 5 | | | | | | | | | | | | | | | | | | | | | - |
| 6 | | | | | | | | | | | | | | | | | | | | | |
| 7 | | | | | | | | | _ | | | | | | | | | | | | |
| 8 | | | | | | | | | | | | | | | | | | | | | - |
| 19 | | | 15 | | <u>s_</u> | ł | | | | | | k | | | | | | | | | |

If the target servo amplifier is not applicable to point data setting function, or in the state of ready not complete, the following screen appears.



If the target amplifier is the one with positioning function and applicable to point data setting function, wait for a few seconds and click [Execute] again.

Also the state of ready not complete occurs when "Test Run and Adjustment" is being executed form the digital operator.

Axis

Servo amplifier axis number whose point data is being edited.

• OPERATE

R-SETUP : R-SETUP mode.

Model number

Servo amplifier model number and combined motor.

Amplifier status

Servo Amplifier status and actual position.

Point data

The set value can be directly input at the cursor. Edited point data will be displayed in red. Once the point data is written in the servo amplifier, the display will be black again.

* Point data cannot be edited unless executing [<u>A</u>mplifier] – [<u>R</u>ead All Point Data from Amplifier].

• Point number search

Input the point number to be searched and click [Search]. The cursor will move to the specified point number.

• Сору

Point data can be copied to that of other point number.

* Refer to 3.28.8 Copy (R-SETUP / EXT. / File Edit Mode) for details.

Teaching

This can be set to the data of the point number which specifies the actual position.

- * Refer to 3.28.7 Teaching (R-SETUP / EXT. Mode) for details.
- Write

The point data with the cursor in is written into the servo amplifier. Only one point data can be written.

* When not executing [<u>A</u>mplifier] – [<u>R</u>ead All Point Data from Amplifier], all the point data being edited are in <u>O</u>riginal status. If "Write" is executed in this status, "0" is written in the target point data.

* When the servo amplifier is in busy status (while the point data of the target is being executed), writing is not possible.

• Tab [Test Run]

Click Tab [Test Run], and the test run screen appears. Test Run can be executed.

• Tab [Point Move]

Click Tab [Point Move], and the point move screen appears. Point move can be executed. Refer to 3.28.5 Point Move (R-SETUP mode) for details.

Functions of point data setting (R-SETUP Mode) can be accessed from the menu bar on the point data setting screen.

| R Point Data | Setting | | | | × |
|-------------------------|------------|--------------------|---------------|---|---|
| File Amplifier | Print Help | | | | |
| D New P Open Save | nate 🐨 | Model | | Amplifier Status | |
| Save As Exit | TUP | Motor : Q1AA06020D | Amp : RS1L01A | Status : [00] Reset Actual Position : -1 Pulse | |

[<u>F</u>ile]

- Save <u>As...</u>: Point data being edited is saved in a file.
- Exit : Exit the point data setting screen.

* [New], [Open...] and [Save] cannot be used in the R-SETUP mode.

| R Point Data Setting | |
|---|---|
| File Amplifier Print Help | |
| Axie * Read All Point Data from Amplifier Axie * Axie * | Amplifier Status Status : [00] Reset |

[<u>A</u>mplifier]

- <u>Read All Point Data from Amplifier...</u>: Read the point data from the servo amplifier as a batch.
- <u>W</u>rite All Point Data to Amplifier...: <u>W</u>rite the point data being edited to the servo amplifier as a batch.

* [<u>W</u>rite All Point Data to Amplifier] cannot be used unless executing [<u>A</u>mplifier] – [<u>R</u>ead All Point Data from Amplifier]

* When the servo amplifier is in busy status (while point data of the target is being executed), writing is not possible.

• Alarm Reset...: Order the amplifier to reset the alarm.

Refer to 3.28.6 Alarm Reset for details.

| R Point Data Setting | | X |
|---------------------------|------------------|---|
| File Amplifier Print Help | | |
| Axis #1 C | Amplifier Status | |

[Print]

- Print Preview...: Display of point data print image.
- <u>Print</u> : Print the point data.
- <u>T</u>ext Output...: Point data is output as text file (*.txt)

* The saved text file cannot be opened in the R-SETUP setup software. Use other applications corresponding to text file (*.txt) to open it.

R Point Data Setting File Amplifier Print Help

[Help]

Descriptions are displayed about setting contents of point data.

3.29.4. Test Run (R-Setup Mode)

Click the tab [Test Run], and the following screen appears. Servo amplifier JOG operation, 1 Step move and homing operation can be executed here.

* Take precautions for safety, since the motor operates in Test Run. If an alarm is issued during Test Run, motor excitation turns OFF. Fully prepare the control device or others prior to Test Run.

* Depending on the amplifier status or setting, the motor cannot stop even if functions of "Stop", "Cancel" or "Resume" are clicked on. Preparation is necessary prior to operation in order that emergency stop can quickly be implemented by shutting off the power of amplifier main circuit.

| R Point Data Setting | | | | × |
|-----------------------------------|-----------------------|-----------------------|------------|----------|
| File Amplifier Print Help | | | | |
| D 🖉 🔲 🖬 💱 🐯 🖪 🗁 | | | | |
| Axis Operate Model | | Amplifier Status | | |
| #1 Q-SETUP Motor : Q1AA06020D | Amp : RS1L01A | Status : | [00] Reset | |
| | | Actual Position : | -1 | Pulse |
| Point Data Test Run Move Point | | | | |
| Parameter Setting | Motor Excitation | <u> </u> | | |
| H_stp 8192 🔶 [Pulse] | Servo ON | Servo OFF | | Teaching |
| L_stp 16 (Pulse) | Current Limit for JOG | Operation | Handshakin | a |
| H_jog 409600 + [Pulse/s] | Limit *Effective of | only at JOG Operation | MSTR | MFIN |
| L_jog 4096 🗘 [Pulse/s] | JOG Operation | | 3 | |
| Override Selection | H_jog+ L_ | jog+ Cance | el Ljog- | H_jog- |
| Edit | -1-Step Movement | | | |
| | H_stp+ | L_stp+ | L_stp- | H_stp- |
| Parameter Display | Cancel | Resume | Continue |] |
| Override Value 100 | Homing | | | |
| | Start | | | |
| Homing Type C-Sig. / Positive-Dir | Cancel | Resume | Continue | Override |
| | | | | |
| Point No:0 | | | | |

×

1) Parameter setting

Clicking [Edit] enables an input to each parameter (during parameter editing).

Clicking [Edit cancel] aborts the value and returns to initial status.

Clicking [Write] writes the input value into the servo amplifier and returns to initial status.

* During test run, parameter setting cannot be changed.

* During parameter editing, test run cannot start, or switching the tab into [Point Data] or [Point Move] is impossible.

* "High speed 1 step move", "Low speed 1 step move", "High speed jogging speed" and "Low speed jogging speed" are the same parameters as the ones included in the general parameters with the same names. Change of settings here is reflected in the general parameter.



2) Parameter display

Contents of setting for override value and homing type are displayed

3) Handshaking

"MSTR" : The status of amplifier output signal MSTR is displayed.

[MFIN] : The same function as amplifier input signal MFIN. However, the status of external signal MFIN cannot be monitored.

4) Motor excitation

Clicking [Servo ON] starts the motor excitation.

Clicking [Servo OFF] cuts the motor excitation.

* When the servo amplifier is in the status of not ready (motor cannot excite), this automatically changes to [Servo OFF].

5) Jog current limit

If jogging operation is executed while current limit is being selected by clicking [current limit], the output current is limited by pre-set limit value. Clicking [current limit] again releases the limit.

6) Jog operation execution

[High speed +] : Starts forward jogging operation at high jogging speed.

[Low speed +] : Starts forward jogging operation at low jogging speed.

[Low speed -] : Starts backward jogging operation at low jogging speed.

[High speed -] : Starts backward jogging operation at high jogging speed.

Clicking [Cancel] cancels the jogging operation.

* During servo off, jogging operation cannot be executed.

* During parameter editing or execution of other test run, jogging operation cannot start.

* During jogging operation execution, parameter editing or other test run cannot be used. Switching the tab into [Point data] or [Point move], or selecting a menu is impossible.

* When servo turns OFF due to alarms or others during jogging operation execution, the jogging operation stops into the servo OFF status.

During Servo ON

| Jogging operation is being stopped. | | |
|--------------------------------------|--------------------------------------|--------|
| JOG Operation | L_jog+ Cancel L_jog- H | _jog- |
| | L_jog+ (H_jog+ , L_jog- , H_jog-) | Cancel |
| Jogging operation is being executed. | | |
| JOG Operation | L_jog+ Cancel L_jog- H | f_jog- |

7) 1 Step move

[High speed +] : Starts forward 1 step move at high jogging speed.

[Low speed +] : Starts forward 1 step move at low jogging speed.

[Low speed -] : Starts backward 1 step move at low jogging speed.

[High speed -] : Starts backward 1 step move at high jogging speed.

Clicking [Cancel] cancels the 1 step move.

Clicking [Resume] suspends the 1 step move.

Clicking [Continue] releases the suspension and resumes the move.

When the specified move is complete, it returns to stop status.

* During servo OFF1 step move cannot be executed.,

* During parameter editing and other test run, 1 step move cannot start.

* While 1 step move is being executed or during suspension, parameter editing and other test run cannot be used. Switching the tab into [Point data] or [Point move], or selecting a menu is impossible.

* When servo turns OFF due to alarms or others during execution, the operation stops into the servo OFF status.



During Servo ON

8) Homing

Clicking [Start] starts the homing operation.

Clicking [Cancel] stops the homing operation.

Clicking [Resume] suspends the homing operation.

Clicking [Continue] releases the suspension and resumes the homing operation.

While clicking [Override], the move speed changes by the specified override ratio.

* During servo OFF, homing cannot be executed.

* During parameter editing and other test run, homing cannot start.

* While homing is being executed or during suspension, parameter editing and other test run cannot be used. Switching the tab into [Point data] or [Point move], or selecting a menu is impossible.

* When servo turns OFF due to alarms or others during execution, the operation stops into the servo OFF status.

| While stopping | |
|---------------------------------|---------------------|
| Homing | |
| Start | |
| Cancel Resume Continue Override | |
| | , |
| While homing | |
| Homing | li sultan |
| Start | Completed |
| Cancel Resume Continue Override | |
| Resume Continue | |
| While suspension Cancel | - |
| Homing | |
| Start | Homing Completed |
| Cancel Resume Continue Override | |
| | |

During servo ON

3.29.5. Move Point (R-Setup Mode)

Click the tab [Move Point] while R-SETUP mode is being executed, and the following screen appears. Servo amplifier point and home position setting are executed here.

* Take precautions for safety, since the motor operates in Move Point operation. If an alarm is issued during operation, motor excitation turns OFF. Fully prepare the control device or others prior to execution.

* Depending on the amplifier status or setting, the motor cannot stop even if functions of "Stop", "Cancel" or "Resume" are clicked on. Preparation is necessary prior to operation in order that emergency stop can quickly be implemented by shutting off the power of amplifier main circuit.

| Q Point Data Setting | | | × |
|--|-----------------------------------|--|----------|
| Eile Amplifier Print Help | | | |
| Axis Operate Model #1 Operate Model Point Data Test Run Move Point | Amp : QS1L01A | Amplifier Status Status : [0D] Servo-Ol Actual Position : -0.5 | mm |
| Setting Point Number 0 | Motor Excitation Servo ON Serv | o OFF | MFIN |
| Parameter Display Override Value 100 | Cancel | Resume Continue | Override |
| History Monitor Counter Status DEC HEX 13 [0C] SV_OFF 997 03E5 | Setting Home Position Start | | |
| Point No.:0 | | | |

1) Setting

Clicking [Edit] enables an input of set value to each item (during set value editing).

Clicking [Edit Cancel] aborts the input value and returns to initial status.

Clicking [Write] writes the input value into the servo amplifier and returns to initial status.

* During point execution, the set value cannot be changed.

* While the set value is being edited, point execution cannot start. Switching the tab into [Point Data] or [Test Run] is impossible.

| Initial status | Sotting |
|-------------------|-------------------------------|
| | |
| | Point Number |
| | Override Selection OverRide00 |
| | Edit |
| Editing set value | Edit Edit Cancel Write |
| | Setting |
| | Point Number 0 |
| | Override Selection OverRide00 |
| | Edit Cancel Write |

2) Parameter display

Operation contents during test run : Parameters are displayed.

3) History monitor

The latest information of status history recorded in the servo amplifier (Last1) is displayed.

4) Handshaking

"MSTR" : The status of amplifier output signal MSTR is displayed.

[MFIN] : The same function as amplifier input signal MFIN. However, the status of external signal MFIN cannot be monitored.

5) Motor excitation

Clicking [Servo ON] starts the motor excitation.

Clicking [Servo OFF] cuts the motor excitation.

* When the servo amplifier is in the status of not ready (motor cannot excite), this automatically changes to [Servo OFF].

6) Point execution

Clicking [Start] starts the point execution.

Clicking [Cancel] cancels the point execution.

Clicking [Resume] suspends the point execution.

Clicking [Continue] releases the suspension and resumes the point execution.

While clicking [Override], the move speed changes by the specified override ratio.

- * During servo OFF, point execution is impossible.
- * During set value editing, point execution cannot start.
- * While pointing is being executed, editing the set value or other test run cannot be used. Switching the tab into [Point data] or [Test Run], or selecting a menu is impossible.

* When servo turns OFF due to alarms or others during point execution, it stops into the servo OFF status.

During servo ON _____ While stopping Move Point Start Continue Cancel Start **During execution** Move Point Start Move Point Completed Override Cancel Resume Resume Continue During suspension Cancel Move Point Start Move Point Completed Cancel Continue Resume

7) Home position setting

Clicking [Start] executes the home position setting.

* Home position setting can only be selected during servo ON.

3.29.6. Alarm Reset (R-Setup Mode)

Select "<u>A</u>mplifier" – "Alarm Re<u>set....</u>" from the menu bar of the point data setting screen, and alarm reset can be executed.

| R Conf | rim | |
|--------|--|------------------------------|
| ? | Do you execute Alarm Reset? Reset the alarm, after remove the | cause and secure the safety. |
| | OK | Cancel |

Click "Yes", and alarm reset is executed.

| R Alarm Reset | | R Alarm Reset | × |
|------------------------------------|---|------------------------|---|
| Alarm Reset is now being executed. | - | Alarm Reset completed. | |

* The display above also appears when there are alarms that cannot be reset. However, the alarm status remains in the servo amplifier side.

3.29.7. Teaching (R-Setup / EXT. Mode)

Click [Teaching] in the tab [Point Data] or [Test Run], the following screen appears. Actual position can be set at point data.

| R Teaching | × |
|--|---------|
| Setup Point Number Actual position is set as one Point Data Point Number: 0 | |
| C Actual position is set as two or more Point Data Point Number: | |
| Amplifier Status | |
| Status: [0D] Servo-OFF Actual Position: 1234 | (Pulse) |
| Execute Close | 1 |

1) Point number

When actual position is to be set at only 1 point data, select "Actual Position is set as one point data" and specify the point number of the destination.

When actual position is to be set at multiple point data, select "Actual position is set as two or more point data", and specify the point numbers of the destination. Point numbers in consecutive areas can be specified. (There must be the smallest point number in the left and the biggest in the right.)

2) Amplifier status

Servo amplifier status and actual position are displayed. This actual position is set. (If the motor is not stopped completely, there may be a slight difference between the motor actual position, display of actual position and the value set by teaching.

3) Execution

Click [Execute], and actual position is set. The only data to be set is the position in the point data.

3.29.8. Copy (R-Setup / EXT. / File Edit Mode)

Click [Copy] in the tab [Point Data], the following screen appears. Point data can be copied to other point data.

| R Copy of Point Data | × |
|---|---|
| Copy to Copy to one Point Data Number of a copy Destination: 0 | |
| Copy to two or more Point Data Number of a copy Destination: | |
| | |
| Copy from | |
| Source Point number 0 | |
| Execute Close | |
1) Copy destination

When the set value of copy source is to be set at only one point data, select "Copy to one point data", and specify the point number of copy destination. When the set value of copy source is to be set at two or more point data, select "Copy to two or more data", and specify the point numbers of the destination. Point numbers in consecutive areas can be specified. (There must be the smallest point number in the left and the biggest in the right.)

2) Copy source

Specify the point number of the point data to be copied from.

3) Execution

Click [Execute], and the point data is copied. All the set values including speed, position and move mode are copied.

3.29.9. New (File Edit Mode)

Select "<u>File</u>" – "<u>N</u>ew...." From the menu bar of the point data setting screen, and a new point data file can be created in OFF line status.

| R New Point Data File | × |
|---|---|
| Select Unit C Unit Pulse C Unit mm D_dpo 0 | |
| 🗸 OK 🛛 🗶 Cancel | |

- Select Unit: Select the unit from "Unit Pulse" and "Unit mm".
- D_dpo (Number of decimal places of position and speed): Set the number of decimal places of the position and the speed set at point data.

Click [OK], and the following screen appears. Input a new file name and click [Save], and point data of the new file can be edited.

| Save As | | | ? | × |
|---------------|-----------------|-------|--------|---|
| Save in: 🔁 | Desktop | • + 1 | 📸 🎹 | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| File name: | | | Save | |
| Save as type: | CSV File(*.csv) | • | Cancel | |

* Only a file name is specified here. A new file will be formally created by executing [Save] or [Save<u>As</u>] on the point data setting screen.

3.30.Transmit Point Data [Amplifier -> File]

At "Transmit Point Data [Amplifier -> File]", all the point data of the amplifier are read and saved in a file as a batch.

Select "Point Data (<u>S</u>)" – "Transmit Point Data [Amplifier -> File] (<u>F</u>) ...", and the screen of transmit point data [Amplifier -> File] appears.

| R Transmit Point Da | ita [Amplifi | ier->File] | × | | |
|---|--------------------|-------------|---------|--|--|
| Transmission source- | | | | | |
| ● #1 | C #6 | C #8 | | | |
| C #2 | C #7 | ○ #C | | | |
| C #3 | ○ #8 | ○ #D | | | |
| C #4 | C #9 | C #E | | | |
| C #5 | C#A | C #F | | | |
| Servo amplifier model : RS1L01A | | | | | |
| Transmission destina The file name of tran | ion smission de | stination | | | |
| | | | Browse | | |
| | | | | | |
| | E | xecute | Exit(X) | | |

See the following procedure of data transmission from the servo amplifier to the point data file. 1. Select the axis number of the transmission source servo amplifier from "Transmission

- source". 2. Click [Browse] in "Transmission destination", and the following file saving dialog appears.
- Click [Browse] in "Transmission destination", and the following file saving dialog appears Specify the place to save in and file name, then click [Save].

| Save As | | | | <u>?</u> × |
|-----------------------|-----------------|-------|--------------|------------|
| Save jn: 🔂 | Data | - 🗢 🖻 | -111 🔁 | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| | | | | |
| I | | | | _ |
| File <u>n</u> ame: | Pointdata1 | | <u>S</u> ave | |
| Save as <u>t</u> ype: | CSV File(*.csv) | • | Cance | <u>ا ا</u> |

3. Click [Execute], and the following screen appears. The point data is read from the servo amplifier.

| R Transmit F | Point Da | ta [Amplifi | er->File] | X |
|---------------|-------------|-------------|-------------|--------|
| ⊓Transmissior | n source- | | | |
| | ● #1 | C #6 | ○ #8 | |
| | C #2 | C #7 | C #C | |
| Now Rea | ling | 0.00 | | |
| Now Rea | ding.Pleas | e wait. | | |
| | | | | |
| The file nan | ne of trans | smission de | stination | |
| C:\test\Point | data1.csv | | | Browse |
| | | | | |
| | | E | xecute | Exit⊗ |

4. When point data reading from the amplifier is complete normally, the display of "Now Reading" disappears and the following screen appears. The read point data of the servo amplifier is saved in the file.



If the target amplifier does not correspond to the point data setting function, or in the status of ready not complete, the following screen appears.

| Warning | | x |
|---------|-----------------------------------|---|
| ⚠ | Point Data Setting cannot be used | |
| | OK | |

If the target amplifier is the one with positioning function and applicable to point data setting function, wait for a few seconds and click [Execute] again.

Also the state of ready not complete occurs when "Test Run and Adjustment" is being executed from the digital operator.

3.31.Transmit Point Data [File -> Amplifier]

At "Transmit Point Data [File -> Amplifier]", the point data saved in the file are directly written in the servo amplifier as a batch.

Select "Point Data (<u>S</u>)" – "Transmit Point Data [File -> Amplifier] (<u>A</u>) ...", and the following screen appears.

| R Transmit Point Da | ata[File->A | mplifier] | × | | |
|---|-------------|-------------|---------|--|--|
| _ Transmission destina | ion | | | | |
| ● #1 | C #6 | C #8 | | | |
| C #2 | C #7 | C #C | | | |
| C #3 | C #8 | ○ #D | | | |
| C #4 | C #9 | O #E | | | |
| C #5 | C #A | C #F | | | |
| Servo amplfifer model : RS1L01A | | | | | |
| Transmission source The file name of trans | mission sou | rce : | | | |
| | | | Browse. | | |
| | | | | | |
| | E | xecute | Exit(X) | | |

See the following procedure of point data transmission from file to servo amplifier.

1. Select the axis number of the transmission destination servo amplifier from "Transmission destination".

2. Click [Browse] in "Transmission source", and the following file selecting dialog appears.

Specify the place to save in and file name, then click [Save].

| Open | | | ? × |
|------------------------|-----------------|-------|--------------|
| Look in: 🧲 | Data | - + 🗈 | -111 * |
| 🖹 Pointdata | 1.csv | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| File <u>n</u> ame: | | | <u>O</u> pen |
| Files of <u>t</u> ype: | CSV File(*.csv) | • | Cancel |

Select the file whose point data is to be read in the servo amplifier, and click [Open]. 3. Click [Execute], and point data batch writing starts.

| Transı | mit Point Da | ta[File->A | mplifier] | | × |
|----------------|--------------------|--------------|-------------|------------|----|
| Hansin | ssion desuna #1 | C #6 | ○ #8 | | |
| | C #2 | C #7 | ○ #0 | | |
| | • 10 | A 10 | • 10 | | |
| Now | Writing | | | | |
| Nov | v Writing.Please | e wait. | | | |
| -T The file | name of trans | miesion sou | rce : | | - |
| C:\Docu | iments and Se | ettings\Kosu | ge Hiroyuki | My [Brows | se |
| , | | - | | | |
| | | E | xecute | Exit(X) | 1 |

If the specified file is not a point data file, the following screen appears. In this case, point data transmission cannot be executed.

| Informa | tion 🔀 |
|---------|-------------------------------|
| • | The kind of file is different |
| | ОК |

If the settings of file and the servo amplifier are different, the following screens appear.

In these cases, point data transmission cannot be executed.

* Modify the servo amplifier settings (for unit, speed, decimal places for position) to make them the same as the file settings, and then transmit again.





If the target amplifier does not correspond to the point data setting function, or in the status of ready not complete, the following screen appears.



If the target amplifier is the one with positioning function and applicable to point data setting function, wait for a few seconds and click [Execute] again.

Also the state of ready not complete occurs when "Test Run and Adjustment" is being executed from the digital operator.

When the servo amplifier is in busy status (while the target point data is being executed), the following screen appears. In this case, writing is impossible.

4. When writing as a batch is complete normally, the display "Now Writing" disappears and the following screen appears.



- Note

In the servo amplifier with positioning function, the following functions cannot be performed on the composition of hardware; 3.14 Jogging operation, 3.15 Operation for pulse feed jogging, 3.19 Automatic offset adjustment of analog velocity command/torque, 3.20 Automatic offset adjustment of analog torque addition command, etc.

4. Appendix

4.1. Wiring

4.1.1. Wiring when Connecting 1 Unit



• Use shield wire for the cable.

RI

9

- The shield wire of the cable must be connected to the case of amplifier connector. Do not connect to the case of PC connector (D-Sub9 pin).
- Wire only pins which the connecting destination is specified in wiring diagram.

4.1.2. Wiring when Connecting Some Units

The following is a wiring diagram when connecting 3 units. In case of connecting 4 or more units, add "the 2^{nd} unit to the $(N-1)^{th}$ unit" for the number of units. The last servo amplifier must be as "the Nth connection". (15 units at maximum can be connected.)



- Each cable length must be within 3m.
- Use shield wire for the cable.
- The shield wire of the cable must be connected to the case of amplifier connector.

Do not connect to the case of PC connector (D-Sub9 pin).

 Wire only pins which the connecting destination is specified in wiring diagram.

4.2. Version List

The list of Servo Amplifier and its corresponding R-SETUP – Setup Software.

| Servo Amplifier | | R-SETUP - Setup Software version | | | Remarks | | |
|-----------------|---------------------|----------------------------------|----------------|--|---------|--|-----------------|
| Type | Software Version | 1.0.0 – 1.00.0 | 1.0.2 – 1.07.8 | | | | |
| SANMOTION R | P0.00.1 | ✓ | ✓ | | | | AC Servo System |
| Type S | ~P0.00.8 | | | | | | |
| SANMOTION T | P1.00.0, | | \checkmark | | | | DC Servo System |
| Type S | P1.00.1 | | | | | | |

✓ : corresponded

4.3. Instruction Manual Revision History

| Revision/ Revised Date | Revised contents |
|--------------------------|---|
| A Revision 2005/4/1 | First edition |
| B Revision 2006/3/9 | 3.25 Trace Operation Addition of Measurement function 4.2 Version List Addition of version of Setup Software 4.4.1 Trouble Shooting Addition of No4, "Failure of control power" 4.4.2 Trouble Shooting Addition of No3, "Failure of control power" |
| C Revision 2007/07/11 | 3.25.2 Select Contents of Trace Operation Setting Digital CH select contents are revised.(PCON-ACK) |
| D Revision 2008/11/27 | 3.27 The addition of Status History Monitor 3.28 The addition of the point data setting 3.29 The addition of Transmit Point Data [Amplifier -> File] 3.30 The addition of Transmit Point Data [File -> Amplifier] |
| E Revision 2009/12/14 | Added the operating system "Windows Vista" to the OS support list in 1.1 Operating Environment. Added the explanatory note to the installation process and corrected minor errors in 1.2.2 How to Install. |
| F Revision 2010/11/4 | 1.1 Hardware requirements1.2 Windows 7 added as an applicable OS.3.11 Verification on parameter filesMinor corrections to the others |

4.4. Trouble Shooting

4.4.1. Troubles when connecting to the Servo Amplifier (During communication status check)

| No. | Abnormal operation/ Message | Major cause | Check/ Corrective measures | |
|-----|---|--|---|--|
| 1 | "The communication port cannot be used. (COM*)" Setting error of the communication port Check if the "communication port" connecting with cable (PC s matches to the one set by [Communication Setting]. Communication port can not be used for been used for other applications. | | Check if the "communication port" connecting with cable (PC side) matches to the one set by [Communication <u>Setting]</u> . | |
| | | | Check if the "communication port" connecting with cable (PC side) has been used for other applications. | |
| | | R-SETUP. | Check if more than two R-SETUP have been activated. | |
| | | Abnormal operation of communication port | Check if the "communication port" connecting with cable (PC side) operates correctly. | |
| 2 | "The communication cable is not connected" | Connecting failure of the communication | Check if the communication cable (PC side/ D-sub 9 pin) is connected correctly. | |
| | | cable (PC side) | Check if the communication cable has any breakage. | |
| 3 | The communication | Control power supply | Check if control power is supplied to the Servo amplifier. | |
| | status check results in "Not connected". | Connecting failure of the communication | Check if the communication cable (Amplifier side) is connected to the Amplifier correctly. | |
| | | cable (Amplifier side) | Check if the communication cable has any breakage. | |
| | | Setting error of the communication relations. | Check if the communication baud rate setting of the Servo amplifier conforms to the one set by [Communication <u>Setting].</u> *Note 1 | |
| | | | Check if the communication axis number setting of the Servo amplifier conforms to the one set by [Communication <u>Setting]</u> . *Note 1 | |
| | | Setting error of the communication port | Check if the "communication port" connecting with cable (PC side) matches to the one set by [Communication <u>Setting]</u> . | |
| 4 | The communication status check results in "Error". | Wrong operation due to the setting failure. | Check if the communication baud rate setting of the Servo amplifier conforms to the one set by [Communication <u>Setting]</u> . *Note 1 | |
| | | Failure of control power | Check if control power is supplied to the Servo amplifier. This abnormality occurs when the control power supply is a low voltage. | |
| | | Wrong operation due to noise. | *Note 2 | |
| 5 | The communication status check results in "Overlap" *Note 3 | Setting error of the communication relations (when plural Amplifiers are connected). | Check if the communication axis number settings overlap among connected Amplifiers. *Note 1 | |
| | | Wrong operation due to noise. | *Note 2 | |
| 6 | The communication status check results in "Not-corresponding". | Version mismatch | The R-SETUP is not corresponding to the Servo amplifier software version. Install the latest version R-SETUP. | |
| | | Software mismatch | The R-SETUP cannot communicate to Q series Servo Amplifier. | |
| | | | R series Servo Amplifier cannot communicate Q-SETUP. | |

*Note 1 The communication axis number and the communication baud rate of the Servo amplifier can be set at parameter. Refer to the Appendix "4.5 Communication Setting of the Servo Amplifier" for the details. Note that the setting procedure is different or the setting can not be changed depending upon Amplifier types.

*Note 2 In case that the communication can not be executed correctly due to noise, the noise influence should be reduced by the countermeasures as follows:

- Ground the Servo amplifier and PC appropriately.
- Keep the Servo amplifier and PC away from the noise cause.
 Install noise filter

*Note 3 In case that "Overlap" remains after countermeasures are implemented, take one of the following measures: • Turn off the control power of the Servo amplifier and turn it on.

- Plug off the communication cable (Amplifier side) and reconnect it.
- Execute [Communication] [Communication Reset].

| No. | Abnormal operation/ Message | Major cause | Check/ Corrective measures | |
|-----|--|---|---|--|
| 1 | "The communication port cannot be used. | Communication port can not be used for | Check if the "communication port" connecting with cable (PC side) has been used for other applications. | |
| | (COM*) " | R-SETUP. | Check if more than two R-SETUP have been activated. | |
| | | Abnormal operation of communication port | Check if the "communication port" connecting with cable (PC side) operates correctly. | |
| 2 | "The communication cable is not connected" | The communication cable (PC side) is not | Check if the communication cable (PC side/ D-sub 9 pin) is connected correctly. | |
| | | connected. | Check if the communication cable has any breakage. | |
| 3 | "Communication is abnormal (Axis number | Failure of control power | Check if control power is supplied to the Servo amplifier. This abnormality occurs when the control power supply is a low voltage. | |
| | [#`].) | | Control power supply was turned off, and it was turned on again. Please execute [Offline->Online] or [Communication Check] again. | |
| | | Connecting failure of the communication | Check if the communication cable (PC side/ D-sub 9 pin) is connected correctly. | |
| | | cable. | Check if the communication cable (Amplifier side) is connected to the Amplifier correctly. | |
| | | | Check if the communication cable has any breakage. | |
| | | "Parameter lock function" by pass ward is set. | When using the following functions under the Parameter lock function setting (editing parameter is prohibited), communication error occurs and the communication will be shut down. "Write to Amplifier" of "General/ System/ Motor parameter setting" "Transmit parameter [File->Amplifier] " Functions of "Test running and adjustment" "Operational Trace" "Alarm Reset" "Alarm Trace Clear" | |
| | | Wrong operation due | *Note 2 | |
| 4 | "Communication | to noise. | Check if control power is supplied to the Sonie amplifier | |
| 4 | timeout (Axis number | | Control power supplied to the Server ampliner. | |
| | [#*]) " | | Please execute [Offline->Online] or [Communication Check] again. | |
| | | | Connecting failure of the communication | Check if the communication cable (Amplifier side) is connected to the Amplifier correctly. |
| | | cable (Amplifier side) | Check if the communication cable has any breakage. | |
| 5 | "The axis number overlaps (Axis number [#*1)" *Noto 3 | Wrong operation due to the setting failure. | Check if the communication baud rate setting of the Servo amplifier conforms to the one set by [Communication <u>Setting]</u> . *Note 1 | |
| | [#]) Note 5 | Wrong operation due to noise. | *Note 2 | |
| | | Others | It might be generated by the hardware of the PC. Please use another PC. | |
| | | | After taking measures, execute "Turn off and on again the control power of the Servo amplifier" or "Communication reset". Communication can be reset by selecting [Communication] – [Communication <u>Reset</u>] from menu bar of the main screen. | |
| 6 | "The Servo amplifier that can communicate does not exist." | The online Amplifier does not exist. | There is no communicable online Servo amplifier due to communication error or timeout. Execute "Communication status check". | |
| 7 | "The amplifier file has broken." | The Amplifier file to be operated (*.ap0) has broken. | The contents of the Amplifier file to be operated (*.ap0) has broken. The file can not be opened. | |

4.4.2. Troubles in use

| No. | Abnormal operation/ Message | Major cause | Check/ Corrective measures |
|--|---|---|--|
| 8 | Even if the amplifier file (*.ap0) is opened, parameters are not displayed. (Or alarm history data is not displayed) | The amplifier file (*.ap0) was saved from Q series Servo Amplifier. | [General Parameter Setting], [System Parameter Setting], [Motor Parameter Setting], [Alarm History Display] R-SETUP cannot not display and operate saved amplifier file (*.ap0) from Q series Servo Amplifier. |
| *Note 1 The communication axis number and the communication baud rate of the Servo amplifier can be set a parameter. Refer to the Appendix "4.5 Communication Setting of the Servo Amplifier" for the details. Note that the setting procedure is different or the setting can not be changed depending upon Amplifier types. *Note 2 In case that the communication can not be executed correctly due to noise, the noise influence should be reduced by the countermeasures as follows: | | | ommunication baud rate of the Servo amplifier can be set at munication Setting of the Servo Amplifier" for the details. Note etting can not be changed depending upon Amplifier types. executed correctly due to noise, the noise influence should be |

- $\boldsymbol{\cdot}$ Ground the Servo amplifier and PC appropriately.

• Keep the Servo amplifier and PC away from the noise cause. • Install noise filter In case that "Overlap" remains after countermeasures are implemented, take one of the following measures: *Note 3

- Turn off the control power of the Servo amplifier and turn it on.
 Plug off the communication cable (Amplifier side) and reconnect it.
- Execute "Communication (C)" and "Communication Reset (R)".

4.4.3. Transmit Parameter [File->Amplifier] Alarm

| No. | Alarm Contents/ Message | Explanation/ Corrective Measures | |
|-----|---|--|--|
| 1 | "Because the software version of servo amplifier is different, there are parameters which cannot be transmitted. Dose it transmit?" | The Servo amplifier software version of the transmission source having saved the amplifier file and that of transmission destination are different, or those hardware types are different. Thus, the part of incompatible parameters may not be transmitted. | |
| | | the incompatible parameters. After the transmission will be executed except for completed, check the parameters that have not been transmitted by "Match parameter". Set up those parameters in manual if necessary. | |
| 2 | "The kind of servo amplifier is different. It cannot transmit." | The Servo amplifier software version of the transmission source having saved the amplifier file and that of transmission destination are different. Because of the low compatibility between them, the parameter transmission can not be executed. | |

4.4.4. Match Parameter Alarm

| No. | Alarm Contents/ Message | Explanation/ Corrective Measures | |
|-----|--|---|--|
| 1 | "The software version of servo amplifier is different. Dose it continue a matching?" | The Servo amplifier software version of the transmission source having saved the amplifier file and that of transmission destination are different, or those hardware types are different. For this reason, non-compatible parameter may exist. | |
| | | Click "Yes", and match parameter starts including the incompatible parameters. Those incompatible parameters, regardless of its setting values, will be indicated their names in red as "not matching". | |
| 2 | "The kind of servo amplifier is different. It cannot match." | The Servo amplifier software version of the transmission source having saved the amplifier file and that of transmission destination are different. Because of the low compatibility between them, the Match Parameter can not be executed. | |

| No. | Alarm Contents/ Message | Explanation/ Corrective Measures | |
|-----|--|--|--|
| 1 | "JOG Operation cannot be used." | [JOG Operation], [Pulse Feed JOG], [Automatic Notch Filter Tuning], [Automatic Vibration Suppressor Frequency Tuning] | |
| | "Pulse Feed JOG cannot be used." | | |
| | "Automatic Notch Filter Tuning cannot be used." | [System Analysis], [Fixation Excitation Operation], | |
| | "Automatic Vibration Suppressor Frequency Tuning cannot be used." "Measurement & Analysis cannot be used." [System Analysis Function] | [Automatic Offset Adjustment of Analog Velocity Command/ Torque Command], [Automatic Offset Adjustment of Analog Torque Additional Command], [Save Result of Automatic Tuning], [Alarm Reset], [Absolute Encoder Clear], [Alarm Trace Clear] The Servo amplifier is not corresponding to the functions and | |
| | "Fixation Excitation Operation cannot be used." | | |
| | "Automatic Offset Adjustment of V-REF Terminal cannot be used." | | |
| | "Automatic Offset Adjustment of T-COMP Terminal cannot be used." | those functions in R-SETUP can not be used. | |
| | "Save Result of Automatic Tuning cannot be used." | The functions that can be used in the "Test Operation and Adjustment" of R-SETUP differs depending upon the Servo | |
| | "Alarm Reset cannot be used." | amplifier software version and the Servo amplifier types. | |
| | "Absolute Encoder Clear cannot be used." | | |
| | "Alarm Trace Clear cannot be used." | | |
| 2 | "Jogging Operation cannot be executed. (Not ready)" | [JOG Operation], [Pulse Feed JOG], | |
| | "Pulse Feed Jogging cannot be executed. (Not ready)" | [Automatic Notch Filter Tuning], [Automatic Vibration Suppressor Frequency Tuning], | |
| | "Automatic Notch Filter Tuning cannot be executed. (Not ready)" | [System Analysis], [Fixation Excitation Operation] | |
| | "Automatic Vibration Suppressor Frequency Tuning cannot be executed. (Not ready)" "Measurement & Analysis cannot be executed. (Not | The Servo amplifier is not ready and those functions can not be executed. | |
| | ready)" [System Analysis Function] | Check the followings: | |
| | "Fixation Excitation Operation cannot be executed. (Not | • if in the alarm status. | |
| | Teauy) | if the main circuit power is supplied. if "Test Operation and Adjustment" and "Alarm Trace Clear" | |
| | | are implemented from digital operator. | |
| | | During control mode switching. (Note7) | |
| | | Excitation Operation, other test operation cannot be used. | |
| 3 | "Automatic Offset Adjustment of V-REF Terminal cannot be executed. (Not ready)" | [Automatic Offset Adjustment of Analog Velocity Command/ Torque Command], [Automatic Offset Adjustment of Analog Torque Additional | |
| | "Automatic Offset Adjustment of T-COMP Terminal cannot be executed. (Not ready)" | Command], [Save Result of Automatic Tuning], [Alarm Reset], | |
| | "Save Result of Automatic Tuning cannot be executed. (Not ready)" | [Absolute Encoder Clear], [Alarm Trace Clear] | |
| | "Alarm Reset cannot be executed. (Not ready)" | be executed. | |
| | "Absolute Encoder Clear cannot be executed. (Not ready)" | Check if "Test Operation and Adjustment" and "Alarm Trace | |
| | "Alarm Trace Clear cannot be executed. (Not ready)" | Clear are implemented from digital operator. | |
| 4 | "This function cannot be used in R-SETUP by which | [System Analysis] | |
| | reduced installation was carried out." [System Analysis Function] | In the reduced installed R-SETUP, the system analysis function shall not be used. Use a complete version installer and implement the complete installation. | |
| 5 | "Over-travel is now going on." | [JOG Operation], [Pulse Feed JOG] | |
| | | Over-travel occurs in the JOG operational direction. | |

4.4.5. Test Operation and Adjustment/ Alarm Trace Clear Massage

| No. | Alarm Contents/ Message | Explanation/ Corrective Measures | |
|-----|---|---|--|
| 6 | "The setting value will not allow Pulse Feed Jogging. | [Pulse Feed JOG] | |
| | Change the setting value." | Correct feed pulse value and setting value of travel velocity. | |
| | | Appropriate setting range (Note 1) Feed pulse value: 1 to 214748364 pulse Travel velocity: 1 to approx. 1000min ⁻¹ (Rotary) 1 to approx. 200mm/s (Linear) | |
| 7 | "Automatic Notch Filter Tuning has not been executed. (Completing abnormally)" | [Automatic Notch Filter Tuning], [Automatic Vibration Suppressor Frequency Tuning] | |
| | "Automatic Vibration Suppressor Frequency Tuning has not been executed. (Completing abnormally)" | Tuning process has been interrupted (abnormal termination). Check the causes as follows: Over-travel has occurred. After Servo OFF → Servo ON, tuning is implemented during holding brake release delay time (BOFFDLY). (Note2) Torque limitation is effective. (Note 3) Alarm has occurred. (Note 4) The main circuit power has not been supplied. | |
| 8 | "Measurement & Analysis can not be executed | [System Analysis] | |
| 0 | (Completing abnormally)" [System Analysis Function] | Data measurement process has been interrupted (abnormal termination). | |
| | | Check the causes as follows: • Over-travel has occurred. • After Servo OFF → Servo ON, tuning is implemented (or started) during holding brake release delay time (BOFFDLY). (Note2) • Alarm has occurred. • The main circuit power has not been supplied. | |
| 9 | "It is not a system analysis file." | [System Analysis] | |
| | | The specified file is not a system analysis data file. | |
| 10 | "Fixation Excitation Operation has not been executed." | [Fixation Excitation Operation] | |
| | | The Fixation Excitation Operation can not be implemented normally. | |
| | | Check the causes as follows:• Rotary Servo system.(Note5)• Alarm has occurred.(Note4, Note6)• The main circuit power has not been supplied. | |
| 11 | "Automatic Offset Adjustment of V-REF Terminal has not been executed." | [Automatic Offset Adjustment of Analog Velocity Command/ Torque Command], [Automatic Offset Adjustment of Analog Torque Additional | |
| | "Automatic Offset Adjustment of T-COMP Terminal has not been executed " | Command] | |
| | | Automatic Offset Adjustment can not be executed normally. Check the cause as follows: • Voltage of over±4V has been implied into analog input terminal. | |
| 12 | "Alarm Reset has not been executed." | [Alarm Reset] | |
| | | Alarm can not be reset normally. | |
| | | Check the causes as follows:The alarm that can not be reset has occurred.Since the alarm cause has not been removed, the alarm cannot be reset. | |

| *Note 1 | The maximum travel velocity that can be set in the Puise Feed JOG function differs depending upon the encoder resolution (if resolution is higher, the maximum travel velocity setting value shall be lower). The maximum travel velocity setting value in general encoder is as follows: (when setting beyond the over-speed setting value of the motor, over-speed error occurs.) Take extra care since JOG operation in the high speed is dangerous. | | | | |
|---------|---|---|--|--|--|
| | Rotary Servo System | | | | |
| | Incremental Encoder (2000PPR) | :32767min-1 | | | |
| | Wiring-saved Absolute Encoder (131072FMT) | :2746min-1 | | | |
| | Linear Servo System | | | | |
| | Incremental Encoder (10000P/mm) | :600mm/s | | | |
| | Incremental Encoder (1000P/mm) | :6000mm/s | | | |
| *Note 2 | Tuning/ data measurement can not be implemented normally during holding brake release time. After Servo | | | | |
| | OFF \rightarrow Servo ON, wait holding brake release time (BOF | FDLY) process. And then click "Execute". | | | |
| *Note 3 | In the status of torque limitation, tuning can not be execut | ed normally Enlarge the setting value of the torque | | | |

- In the status of torque limitation, tuning can not be executed normally. Enlarge the setting value of the torque INOTE 3 limitation, or lower the tuning torque command.
- In case that the "Test operation complete alarm (ALM_DF)" occurs, this is a secondary alarm occurring due to the function failure and is not a cause of the "Test Operation and Adjustment" function failure. *Note 4
- In the Rotary Servo System, the Fixation Excitation Function can not be used. *Note 5
- *Note 6 In case that the "Fixation Excitation Error (ALM_44) occurs, this is a secondary alarm occurring due to the function failure and is not a cause of the "Fixation Excitation" operational failure. The test operation might not be able to be used during switching the control mode.
- *Note 7

| No. | Alarm Contents/ Message | Explanation/ Corrective Measures | | |
|---|--|--|--|--|
| 1 | "Trace Operation cannot be executed." | The Servo amplifier is not corresponding to the Trace Operation Function and this function can not be used. It differs depending upon the Servo amplifier software version and the Servo amplifier types if the Servo amplifier is corresponding to the Trace Operational Function. | | |
| 2 | "It is not an operational trace file." | The specified file is not an operational trace data file. | | |
| 3 | "A sampling period is outside the setting range." | [Trace Operation Setting] | | |
| | "A trigger level is outside the setting range." | The set value is out of specification. | | |
| | "A trigger position is outside the setting range." | | | |
| 4 "In the now baud rate and communication environment | | [Scroll Mode] | | |
| | the set-up sampling period is unrealizable. | This alarm occurs in case of high frequency of the display interruption (data elimination). The following causes are considered: | | |
| | | Menu bar opens during monitoring operation. (Note 1) The relation between the sampling period setting value and CPU operational frequency are not appropriate. (Note 2) Other application operates in the background. The application with large load exists. | | |
| | | Lower the load on PC. If no improvement, readjust the sampling period setting value. | | |
| *N | ote 1 Data update stops during the menu bar opens. | When this data update stop becomes long, the alarm will | | |
| *N | *Note 2 The recommended conditions (CPU operational frequency) when using scroll mode of the Trace Operational | | | |

4.4.6. Trace Operation Massage

s (Cr oper q١ ;y) γμ Function are as follows: •

| \cdot 50ms \leq Data sampling period < 100ms | :CPU operational frequency \geq 800MHz |
|--|--|
| 100ms ≦Data sampling period < 200ms | :CPU operational frequency \geq 350MHz |
| 200ms ≦Data sampling period | :CPU operational frequency \geq 133MHz |

158

4.5. Communication Setting of Servo Amplifier

4.5.1. Parameter

Communication setting of the servo amplifier can be changed by operating parameter of

the servo amplifier.

| Setup Software, Communication Axis Number | COMAXIS | [Group A – Page 20] |
|---|---------|---------------------|
| Setup Software, Communication Baud Rate | COMBAUD | [Group A – Page 21] |

By making this parameter setting identical with the communication setting of the R-SETUP ([Communication] – [Communication Setting...] in the menu bar of the main screen), communication can be executed at the objective setting. The default settings are as follows:

| Servo amplifier | (Standard setting v | alue at ex-factory | /) |
|-----------------|---------------------|--------------------|----------------------------|
| Communication | Axis Number | : #1 | : COMAXIS = "01:_#1" |
| Communication | Baud Rate | : 38400bps | : COMBAUD = "05:_38400bps" |
| R-SETUP - Setup | Software (Sta | ndard setting valu | ue after installation) |
| Communication | Axis Number | : #1 | |
| Communication | Baud Rate | : 38400bps | |
| | | | |

Setup Software, Communication Axis Number COMAXIS [Group A - Page 20]

| S | Select Value | Remarks |
|----|--------------|---------------------------------------|
| 01 | #1 | Standard setting value at ex-factory. |
| 02 | #2 | |
| 03 | #3 | |
| 04 | #4 | |
| 05 | #5 | |
| 06 | #6 | |
| 07 | #7 | |
| 08 | #8 | |
| 09 | #9 | |
| 0A | #A | |
| 0B | #B | |
| 0C | #C | |
| 0D | #D | |
| 0E | #E | |
| 0F | #F | |

| Setup Software, Communication Baud Rate | COMBAUD | [Group A – Page 21] |
|---|---------|---------------------|
|---|---------|---------------------|

| Select Value | | Remarks |
|--------------|-----------|---------------------------------------|
| 00 | 1200 bps | |
| 01 | 2400 bps | |
| 02 | 4800 bps | |
| 03 | 9600 bps | |
| 04 | 19200 bps | |
| 05 | 38400 bps | Standard setting value at ex-factory. |

- Note 1) Depending upon the Amplifier types, "initial value/ ex-factory setting value may differ," or "setting procedure may differ," or "the setting value may not be able to change." Refer to the individual Instruction Manual or Specifications.
- Note 2) In case of changing COMAXIS and COMBAUD setting, the setting change will be valid by turning ON the Amplifier control power again.

4.5.2. Communication Setting Procedure by Digital Operator

Communication setting of the Servo amplifier can be checked and changed by using digital operator in the following procedure:

Note that "setting procedure may differ" or "the setting value may not be able to change" depending upon the Amplifier types. Refer to the individual Instruction Manual or Specifications.

- 1. Switching digital operator mode.
 - (1) Turn ON the control power. Then the digital operator is in the status display mode.
 - (2) Press the MODE Key sometimes until Basic Mode (or Parameter Editing Mode).
- 2. Checked and Changed the communication settings at Basic Mode (or Parameter Editing Mode)

| MODE | Page | Name | | Corresponding group and page in Parameter Editing Mode. (General Parameter Setting) |
|------|------|---------|---|---|
| bA | 00 | COMAXIS | Setup Software, Communication Axis Number | Group A – Page 20 |
| | 01 | COMBAUD | Setup Software, Communication Baud Rate | Group A – Page 21 |

3. Turn ON the control power again to update communication settings.

| Release | |
|------------|-----------|
| Revision A | Apr. 2005 |
| Revision B | Mar. 2006 |
| Revision C | Jul. 2007 |
| Revision D | Nov. 2008 |
| Revision E | Dec. 2009 |
| Revision F | Oct. 2010 |

Precautions For Adoption

A Cautions

The possibility of moderate or minor injury and the occurrence of physical damage are assumed when the precautions at right column are not observed. Depending on the situation, this may cause serious consequences. Be sure to follow all listed precautions.

- 🕂 Cautions

- Be sure to read the instruction manual before using this product.
- Take sufficient safety measures and contact us before applying this
- product to medical equipment that may involve human lives.
- Contact us before adapting this product for use with equipment that could cause serious social or public effects.
- The use of this product in high motion environments where vibration is present, such as in vehicles or shipping vessels, is prohibited.
- Do not convert or modify any equipment components.

* Please contact our Business Division for questions and consultations regarding the above.

| | http://www.sanyodenki.com |
|---|---------------------------|
| SANYO DENKI CO., LTD. 1-15-1, Kita-Otsuka, Toshima-ku, Tokyo 170-8451, Japan | Phone: +81 3 3917 5157 |
| SANYO DENKI AMERICA,INC. 468 Amapola AvenueTorrance, CA 90501 U.S.A. | Phone: +1 310 783 5400 |
| SANYO DENKI EUROPE SA. P.A. Paris Nord II 48 Allee des Erables-VILLEPINTE BP.57286 F-95958 ROISSY CDG Cedex France | Phone: +33 1 48 63 26 61 |
| SANYO DENKI GERMANY GmbH Frankfurter Strasse 63-69 65760 Eschborn Germany | Phone: +49 6196 76113 0 |
| SANYO DENKI <i>KOREA CO., LTD.</i> 9F 5-2, Sunwha-dong Jung-gu Seoul, 100-130, Korea | Phone: +82 2 773 5623 |
| SANYO DENKI <i>SHANGHAI CO., LTD.</i> Rm2108-2109, Bldg A, Far East International Plaza, No.319, Xianxia Rd., Shanghai, 200051, China | Phone: +86 21 6235 1107 |
| SANYO DENKI <i>TAIWAN CO., LTD.</i> Room 1208, 12F, No.96 Chung Shan N, Rd., Sec.2, Taipei 104, Taiwan, R.O.C. | Phone: +886 2 2511 3938 |
| SANYO DENKI <i>(H.K.)CO., LIMITED</i> Room 2305, 23/F, South Tower, Concordia Plaza, 1 Science Museum Rd., TST East, Kowloon, Hong Kong | Phone: +852 2312 6250 |
| SANYO DENKI SINGAPORE PTE. LTD. 10 Hoe Chiang Road #14-03A/04 Keppel Towers Singapore 089315 | Phone: +65 6223 1071 |

The names of companies and/or their products specified in this manual are the trade names, and/or trademarks and/or registered trademarks of such respective companies. *Remarks : Specifications Are Subject To Change Without Notice.